

Installation and Operation Guide Bubbler

Manual #69-4333-004 of Assembly #60-4334-005 Copyright © 2021. All rights reserved, Teledyne ISCO Revision M, June 2021

Use and Disclosure of Data Information contained herein is classified as EAR99 under the U.S. Export Administration Regulations. Export, reexport or diversion contrary to U.S. law is prohibited.

Foreword - Water and Wastewater Products

This instruction manual is designed to help you gain a thorough understanding of the operation of the equipment. Teledyne ISCO recommends that you read this manual completely before placing the equipment in service.

Although Teledyne ISCO designs reliability into all equipment, there is always the possibility of a malfunction. This manual may help in diagnosing and repairing the malfunction.

If a problem persists, call or e-mail Teledyne ISCO technical support for assistance. Simple

difficulties can often be diagnosed over the phone. For faster service, please have your serial number ready.

If it is necessary to return the equipment to the factory for service, please follow the shipping instructions provided by technical support, including the use of the Return Merchandise Authorization (RMA) specified. Be sure to include a note describing the malfunction. This will aid in the prompt repair and return of the equipment.

Teledyne ISCO welcomes suggestions that would improve the information presented in this manual or enhance the operation of the equipment itself.

Teledyne ISCO is continually improving its products and reserves the right to change product specifications, replacement parts, schematics, and instructions without notice.

Contact Information

Customer Service	
Phone:	(800) 228-4373 (4025 A, Canada, Mexico) 464-0231 (Outside North America)
Fax:	(402) 465-3022
Em ai l:	isco.orders@teledyne.com
Technical Support	
Phone:	Toll Free (866) 298-6174 (Samplers and flowmeters)
Email:	iscowatersupport@Teledyne.com
Return equipment to:	4700 Superior Street, Lincoln, NE 68504-1398
Other Correspondence	
Mail to:	P.O. Box 82531, Lincoln, NE 68501-2531

Warranty and Operation Manuals can be found on our website at: www.teledyneisco.com

General Warnings

Before installing, operating, or maintaining this equipment, it is imperative that all hazards and preventive measures are fully understood. While specific hazards may vary according to location and application, take heed of the following general wa rn ing s:

🔨 WA RNING

Avoid hazardous practices! If you use this instrument in any way not specified in this manual, the protection provided by the instrument may be impaired.

Éviter les usages périlleux! Si vous utilisez cet instrument d'une manière autre que celles qui sont specifiées dans ce manuel, la protection fournie de l'instrument peut être affaiblie; cela augmentera votre risque de blessure.

This manual applies *Hazard Severity Levels* to the safety alerts, These three levels are described in the sample alerts below.

Cautions identify a potential hazard, which if not avoided, may result in minor or moderate injury. This category can also warn you of unsafe practices, or conditions that may cause property dam age.

WA RNING

Warnings identify a potentially hazardous condition, which if not avoided, could result in death or serious injury.

DANGER

DANGER – limited to the most extreme situations to identify an imminent hazard, which if not avoided, will result in death or serious injury.

Hazard Severity Levels

Hazard Symbols	The equipment and this manual use symbols used to warn of hazards. The symbols are explained below.
	Hazard Symbols
Warnings and Cautions	
	The exclamation point within the triangle is a warning sign alerting you of important instructions in the instrument's technical reference manual.
<u>Á</u>	The lightning flash and arrowhead within the triangle is a warning sign alert- ing you of "dangerous voltage" inside the product.
Symboles de sécurité	
	Ce symbole signale l'existence d'instructions importantes relatives au pro- duit dans ce manuel.
<u>Í</u>	Ce symbole signale la présence d'un danger d'électocution.
Warnungen und Vorsichtshinwei	se
	Das Ausrufezeichen in Dreieck ist ein Warnzeichen, das Sie darauf auf- merksam macht, daß wichtige Anleitungen zu diesem Handbuch gehören.
<u>Í</u>	Der gepfeilte Blitz im Dreieck ist ein Warnzeichen, das Sei vor "gefährlichen Spannungen" im Inneren des Produkts warnt.
Advertencias y Precauciones	
	Esta señal le advierte sobre la importancia de las instrucciones del manual que acompañan a este producto.
Ŷ	Esta señal alerta sobre la presencia de alto voltaje en el interior del producto.

Signature® Flow Meter

Table of Contents

Section 1Introduction

1.1Quick Start	
1.3Security	
1.4Compatible Equipment	-3
1.5Identifying Signature Components 1	
1.6Controls and Indicators	
1.6.1Keypad	
1.6.2Display and LED	
1.6.3Backlight and Screen	
1.6.4Display Contrast 1	
1.7Technical Specifications	-7

Section 2Setup and Programming

2.1User Interface
2.1.1Keypad Functions 2-1
2.1.2Connecting to the Signature with Flowlink
2.2The Home Screen
2.3Shortcuts
2.3.1Adjust Level
2.3.2Adjust Velocity
2.3.3Purge
2.3.4Histograph
2.3.5Real-Time Measurement
2.3.6Report View
2.4Programming
2.4.10ff-Screen Content
2.4.2Character Grid
2.4.3Pull Down Menus
2.5Program Steps
(Menu Trees)
2.6Hardware Setup
2.6.1Smart Sensor Setup (TIENet)
2.6.2SDI-12 Setup 2-14
2.6.3Modbus Input Setup
2.6.4Modbus Output Setup 2-18
2.6.5Modem Setup 2-18
2.7Configure Options
2.7.1Site Setup
2.7.2Measurement Setup
2.7.3Adjust
2.7.4Equation/Trigger Setup
2.7.5Data Storage/Push Setup 2-27
2.7.6Sampler Setup
2.7.7 Inputs/Outputs/Alarms
Setup
2.7.8Reset Totalizers

2.7.9Reports/History Setup 2-3	30
2.8Administration	30
2.8.1Language Options 2-3	31
2.8.2Set New Passcode	31
2.8.3Update Firmware	
2.8.4Sensor Diagnostics 2-3	
2.8.5Display Signature Information 2-3	32
2.8.6Display License Information 2-3	32
2.8.7Gather Fault Data 2-3	32
2.8.8Restore to Factory Defaults 2-3	32
2.8.9Home	
2.9USB Options	32
2.9.1Retrieve Text Reports	
2.9.2Retrieve Data	34
2.9.3Update Firmware	
2.9.4Save Current Program	34
2.9.5Load Existing Program	34
2.9.6Save Signature Information 2-3	34
2.9.7Gather Fault Data 2-3	
2.9.8None of the above 2-3	
2.10Signature Data in Flowlink 2-3	
2.10.1Event Viewer 2-3	
2.11Verifying Exported Reports 2-3	36

Section 3Standard Installation

3.1Introduction	
3.3Case Bottom Cable Entries	
3.3.1Cable Fittings	. 3-5
3.3.2Connecting TIENet Devices	
3.4Power	
3.4.1Hard Wiring	
3.4.2Line Cord	
3.4.3Power Connections	
3.5Mounting the Signature	
3.6Outdoor Recommendations.	3-13
3.7The Bubble Line	
3.7.1Standard Bubble Lines	3-14
3.7.2Comparing Vinyl and PTFE Bubble Lines	3-14
3.7.3Bubble Line Length	3-14
3.7.4Attaching the PTFE Bubble Line	3-15
3.7.5Attaching the Vinyl Bubble Line	3-15
3.7.6Installing the Bubble Line	3-15
3.7.7High-Velocity Flow Streams	3-16
3.7.8Stilling Wells	3-17
3.7.9Flume Bubble Line Fittings	
3.7.10Bubble Line Extensions	3-17
3.7.11Open Channel Installation	3-18
3.8Setting the Level.	3-18
3.9TIENet Sensor Installation in a Hazardous Location	

Section 4Portable Installation

4.1Introduction	l
4.2Portable Stand	Ĺ
4.2.1Adjust Signature to Upward Position	2
4.3Power	1

4.3.1Power Connections	4-4
4.3.2Outdoor Recommendations	4-4
4.3.3Battery Installation	4-5
4.4Battery Life Expectancy	
4.4.1 Major Standard Equipment Settings Effecting Battery Life	
4.4.2 Major Optional Equipment Settings Effecting battery Life	
4.4.3Additional Considerations for Battery Life	
4.4.4Calculating Average Current Draw	
4.4.5Battery Life Calculations	
4.4.6Low Battery Cut Off and Battery Care	
4.5Connect to External Devices	
4.5.1Connecting Devices to the TIENet Receptacle	4-13

Section 5Equipment Options

5.1AC Power Cord Kit /AC Wiring (Applies to Permanent Installation Only) 5-2
5.2Battery Backup (Applies to Permanent Installation Only)
5.3Power Loss Alarm
5.4Mechanical Totalizer
5.5External Desiccator
5.6TIENet® Devices
5.6.1Ultrasonic Level Sensor
5.6.2Bubbler Level Sensor
Doppler Velocity Sensor
Nave Doppler Velocity Sensor

(TIENet 304)	5-17
5.6.9Analog Input Card	
(TIENet 307)	
5.6.10Analog Output Card (TIENet 308)	
5.7Reference Port Tubing Kit	
5.8 ISCO Flowlink Software	
5.9Ethernet Modem	
5.9.1Ethernet Modem Configuration	
5.9.2Network Firewall Settings	
5.10Cellular Modems	
5.10.1GGM Modem	
5.10.2LTE Modem	
5.10.3SIM Card	
5.10.4Installing the Cellular Modem	
5.10.5Cellular Modem Configuration	
5.10.6 Antenna Placement.	
5.10.7 Modem Frequency Bands	

Section 6Maintenance and Servicing

6.1Maintenance 6 6.2Cleaning. 6 6.3Firmware Updates 6	-2
6.4Accessing the Interior	
6.5Desiccant	
6.5.1Internal Desiccator	
6.5.2External Desiccator	
6.6Troubleshooting6 6.6.1Signature Flow Meter6	
	0

6.6.2TIENet 300 Connector Case
6.6.3TIENet 301 pH/Temp 6-1
6.6.4TEINet 304 Contact Output Card6-12
6.6.5TIENet 307 Analog Input Card
6.6.6TIENet 306 Sampler Interface6-14
6.6.7TIENet 308 Analog Output 6-14
6.6.8TIENet 310 USLS
6.6.9TIENet 330 Bubbler
6.7330 Bubbler Installation
6.7.1Preparation: Non-Bubbler
6.7.2Preparation: Existing Bubbler 6-2
6.7.3Installation Procedure
6.8Front Cover Replacement
6.9System Reset
6.10Service and Repair
0.105cl vice and Repair

Appendix AReplacement Parts

A.1How to Order.	A-1
A.2Signature Flow Meter.	A-2 A.3 330
Bubbler	

Appendix BOptions and Accessories

B.1Ordering Information. B.2Signature Flow Meter Accessories. B.2Signature Flow Meter Accessories. B.3Power Accessories. B.4TIENet Accessories. B.4.1Internal to Signature B.4.1Internal to Signature B.4.1In	
Unterminated Leads B.4.4301 pH/Temperature Device with Signature Connection Ending in TIENet Plug B.4.5306 Sampler Interface Cable with Signature Connection Ending in Unterminated Leads B.4.6306 Sampler Interface Cable with Signature Connection Ending in TIENet Plug	В-З В-4
 B.4.7310 Ex Ultrasonic Level Sensor with Signature Connection Ending i Unterminated Leads. B.4.8310 Ex Ultrasonic Level Sensor with Signature Connection Ending i TIENet Plug. B.5330 Bubble Options and Accessories. B.5.1350 Area Velocity Sensor with Signature Connection Ending in Unterminated Leads. B.5.2350 Area Velocity Sensor with Signature Connection Ending in TIENet Plug. B.5.3360 LaserFlow Velocity Sensor with Signature connection ending in 	n n B-4 B-4 B-5 B-5 1
unterminated leads	B-5
B.6Modems	B-6
B.7 Sensor Mounting Rings	B-6

Appendix CModbus Output Protocol

C.1Introduction	C-1
C.2Operation	
C.3Configurations	C-2
C.4Glossary of Terms.	C-3
C.5Signature ASCII or RTU Address	
C.6Register Definitions	
C.6.1Modbus Registers	C-4

Appendix DMaterial Safety Data Sheets

List of Figures

 1-1Signature Flow Meter	1-4 1- 1-5 1-
facing position	
facing position	. 1-11
1-7Specification drawing: Signature Bubbler Flow Meter, 1 of 2	. 1-12
1-8Specification drawing: Signature Bubbler Flow Meter, 2 of 2	
2-1Flowlink Connect screen	
2-2Site Info tab	2-4
2-3Devices tab	2-5
2-4Program tab: Accessing the browser	2-6
2-5Home screen (normal operating mode)	2-7
2-6Character grid	
2-7Menu Tree: Top menu	. 2-10
2-8Menu Tree: Hardware Setup	. 2-11
2-9Measurement parameters for each TIENet device	. 2-13
2-10Modbus Input Setup	
2-11Editing Modbus device parameters	. 2-17
2-12Modbus Output Setup	
2-13Menu Tree: Configure	. 2-20
2-14Menu Tree: Flow rate input setup	. 2-23
2-15Menu Tree: Volume Input Setup (total flow)	. 2-24
2-16Menu for Rainfall Input Setup	. 2-24
2-17Example of defining conditions & building equations	. 2-26
2-18Local alarm setup	. 2-28
2-19SMS and Server alarm setup (modem required)	
2-20Menu Tree: Administration	. 2-30
2-21Menu Tree: USB Options	. 2-33
2-22Event Viewer in Flowlink	. 2-35
2-23Report file verifier	. 2-36
3-10pen door and front panel to access interior	
3-2Connector case, connectors, and fuses	3-3
3-3Connector Case cable entries for power and external devices	
3-4Strain relief 3/4 NPT Cord-grip fitting for TIENet devices	3-5
3-5Cord-grip fittings installed	3-5
3-6Diameter-seal plugs for unused ports	
3-7TIENet Device terminal strips	3-7
3-8Installing TIENet cable with a cord-grip fitting	
3-9TIENet Device terminal connections	

3-10Attach wired terminal strip to connector case socket
11Insert the cable reference tubing into the case board reference port
12Position and secure the cable
13Location of power supply
14Signature Flow Meter mounted on wall
15Weather shield - recommended for outdoor installations
(Drawing & Photo courtory of TDACOM Inc.) 213
(Drawing & Photo courtesy of TRACOM, Inc.)
3-16Positioning the Bubble Line in the Flow Stream
3-17Installing the Stainless Steel Bubble Line Extension
3-18Level adjustment
3-19Hazardous Location Installation Control Drawing-ATEX
4-1Signature on portable stand side facing (left) and upward facing (right) 4-1
4-2Pull out the handle latch pins on each side of the stand
4-3One of the eight screws loosened
4-4Signature tilted up in preparation of removal
4-5Signature in upward facing position
4-6Connector E diagram
4-7Notch in stand for the power cable
4-8946 lead-acid battery installed under the Signature Portable
4 Operations and down and there in a signature rollable
4-9Battery hold down and thumb screw
4-10Example of defining conditions and building equations
4-11Measuring flow meter current
4-12Connector case, connectors, and fuses for Signature Portable Flow Meter 4-13
4-13How to connect a TIENet receptacle to the Signature Portable
4-14Removing the plug
4-15Connecting a rain gauge to the Signature receptacle (L) and then to the Signature
connector board (R)
5-1AC Line cord with a cord-grip fitting
5-2Power supply mounting screw 5-2
5-3Power supply removal/replacement
5-4Power supply terminal strip: AC Input and DC Output
5-5Battery backup kit contents 5-5
5-6Attach extension cable to the connector case
5-7Installing the battery backup mounting plate
5-8Backup battery, installed
5-9Disconnect and remove bubbler module
5-9Disconnect and remove bubbler module
5-10Remove totalizer window cover
5-11Optional non-resettable totalizer installation
5-12External desiccator, installed 5-12
5-13Remove red caps before installing external desiccant cartridge
5-14Removing the external desiccant cartridge
5-15Tubing configuration for optimal drying power (Exterior desiccator required) 5-15
5-16TIENet Expansion Box
5-17304 contact output card front and back view
5-18View of two cards installed
5-18view of two cards installed
5-19304 contact output device configuration
5-20304 contact output setup 5-21
5-21307 analog input channel identification and terminal connections
5-22Direction of switch in active and passive modes
5-23307 analog input device configuration
5-24307 analog input setup
5-25DO NOT connect to the ground connection
5-26308 analog output channel identification and terminal connections
5-2009 analog output device configuration and terminal configurations
5-27308 analog output device configuration
5-28308 analog output setup
5-29Reference port kit (full length not shown)
5-30Reference port kit: Remove filter and barb
5-31Reference port kit: Install filter and barb
5-32Reference port kit: Installed on flow meter

5-33Ethernet modem kit contents5-33 5-34Ethernet modem installation5-34 5-35Ethernet modem setup: Communication settings (default settings shown)5-35 5-36Locating the NODE ID (MAC address) on the ethernet modem5-37 5-37LTE antenna-5-37 5-Cellular modem5-37 5-
modem
and location of label on the bottom of Signature case 5-39 5-42Cellular modem kit contents
installation
Communication settings
not included)
19 6-11Remove bubbler module
12330 Bubbler assembly installation
13Remove extra tubing and fitting (if applicable)
14Routing and connections of 330 bubbler tubing
15Front cover (door) replacement
1Configuration example

List of Tables

1-1Signature Flow Meter Technical Specifications1-7 12TIENet 330 Bubbler Module Technical Specifications1-9 21Modbus Setup Worksheet2-15 41Battery Life Expectancy
(default measurement rate of 15 minutes)
4-2Battery Life Expectancy
(measurement rate of 5 minutes, all other parameters use default)
4-3Default Method for Portable Signature
4-4Additional Average Current Draw
5-1Direction of arrows and mode types
6-1Recommended Maintenance (Accessible Locations) 6-1
6-2Recommended Maintenance (Difficult-to-Access Locations)
6-3Troubleshooting: Signature Flow Meter
6-4Troubleshooting: TIENet 300 Connector Case
6-5Troubleshooting: TIENet 301 pH/Temperature Device
6-6Troubleshooting: TIENet 304 Contact Output Card
6-7Troubleshooting: TIENet 307 Analog Input Card
6-8Troubleshooting: TIENet 306 Sampler Interface
6-9Troubleshooting: TIENet 308 4-20mA Analog Output
6-10Troubleshooting: TIENet 310 Ultrasonic Level Sensor
6-11Troubleshooting: TIENet 330 Bubbler Module
C-1Modbus Output Registers for Signature Flow Meter

Signature[®] Flow Meter

Section 1Introduction

The Signature Flow Meter is designed for open channel flow monitoring applications using any combination of flow and parameter measurement technologies and sampling, depending on what is required at the monitoring site.

The bubble line is anchored in the flow stream at the appropriate measuring point in the weir, flume, or other open channel flow situation. Air slowly bubbles out of the line into the flow stream. The pressure in the bubble line is proportional to the liquid level in the flow stream, and the flow meter measures this pressure, sensing the liquid level. The Signature has built-in standard level-to-flow conversions that cover the majority of open channel flow measurement situations. Flow measurement is usually a calculation based on a known relationship between liquid level and flow rate. Additionally, the Signature can calculate flow using standard open channel level-to-flow and area-velocity conversions, as well as equations, or data points, depending upon the measurement device(s) attached to the meter and the program specified by the user.


Note

Recent enhancements have been made to the Signature Flow Meter. Many of these features are standard for all new Signature units which are identifiable by the serial label mounted on the bottom of the unit (PN 60-4304-065).



Figure 1-1 Signature Flow Meter

1.1Quick Start



1.2Data Integrity	What makes the Signature Flow Meter unique is its ability to verify data integrity. This is accomplished by logging four special event data types that cannot be altered, and are designed to alert the user to any trends or anomalies, and to assess compliance. This data can be downloaded from the flow meter and observed in tabular or graphical format alongside regular site data, using Flowlink software (see Section 2.10 <i>Signature Data in Flowlink</i>).
	The data can also be downloaded onto a flash drive via the micro-USB assembly on the front panel of the flow meter, then imported into a spreadsheet or other viewing application (refer to Section 2.9 <i>USB Options</i> for more information).
	The four event data types are:
	Program Report – Tracks changes to the Signature Flow Meter c on f igu rati on
	Summary Report – Documents summaries of data measure- ments (e.g., Min/Max/Avg)
	Diagnostic Report – Tracks results from diagnostic tests
	History Report – Tracks user and meter events (e.g., level adjustments, data push, etc.)
	The Signature Flow Meter can be secured shut with a padlock
1.3 Security	with the hasp on the right side of the housing (refer to Figure 1-3). The program settings and recorded data can be protected by a user-selected passcode (refer to Section 2.8.2 <i>Set New Passcode</i> .
	The Signature Flow Meter can interface with a variety of mea-
1.4Compatible Equipment	surement devices and other system components, depending on site requirements.
Equipment	Measurement devices for flow and water quality can be con- nected to the same Signature Flow Meter and run simultane- ously with TIENet® connectivity (up to nine TIENet devices). The flow meter can also communicate with an optional Teledyne ISCO wastewater sampler and rain gauges.
	For descriptions of interfacing and parameter sensing TIENet devices, refer to Section 5 <i>Equipment Options</i> . Each external TIENet device comes with its own user manual.
	The Signature is capable of receiving data from devices using Modbus ASCII or Modbus RTU protocol.
	A variety of application-specific accessories are available from
	Teledyne ISCO Refer to Appendix B <i>Options and Accessories</i> for a complete list with ordering information.
	A basic Signature system has one or more TIENet devices for flow and/or parameter measurement connected to the Signature Flow Meter (up to nine TIENet devices at once). Other configura- tions may include an enclosure and additional internal or external devices, including analog output cards, analog input cards, contact output cards, a modem, up to two SDI-12 inputs, and Modbus devices.

When connected remotely via modem, the web interface of the Signature Flow Meter provides remote control and data access.



Figure 1-2Multiple options can be used in any combination



Figure 1-3Front and exterior component identification




Figure 1-4Home screen and basic keypad functions

Below the display are three software configured function keys (softkeys) that are used to make selections and navigate through menus. Their specific functions are dependent upon what oper- ation you are performing, and will appear in the display window.

1.6.2Display and LED	The LED on the front panel is aligned next to the Status line on the display screen.
	 A green light indicates that new information is available for viewing in the Status line.
	 A flashing green light indicates low power mode when the screen is off and data traffic on some channels.
	 A red light indicates a warning or a user-defined alarm
	condition, with further details viewable by pressing the Alarm softkey (C).
	Figure1-4 shows the standard home screen, or run screen.
	Displayed menus and programming steps are explained in Section2 Setup and Programming.
1.6.3 Backlight and Screen	There is an option to turn off the backlight and screen.
1.6.4Display Contrast	The contrast of the LCD screen can be adjusted using the keypad.
	To adjust the contrast, hold down the \pm key \pm and repeatedly
	press the down arrow 🚺 (softer) or the up arrow 🚺 (sharper) to achieve the desired appearance.
1.7Technical Specifications	Table1-1 provides technical specifications for the Signature Flow Meter. Table1-2 provides technical specifications for the TIENet 330 bubbler module.

Table 1-1Signature Flow Meter Technical Specificationsa	
Size (HxWxD)	22.6 x 31.0 x 20.9 cm (8.9 x 12.2 x 8.2 in) with mounting bracket & external desiccator
Size with Portable Stand (HxWxD)	42.5 x 34.5 x 26.6 cm (16.74 x 13.58 x 10.48 in)
Weight	
Flow Meter, No Bubbler	Signature w/o options: 4.5 kg (10 lbs) Signature w/ all interior options: 4.9 kg (10.7 lbs) Signature w/ all int. options + mounted battery backup: 7.8 kg (17.3 lbs)
Bubbler Flow Meter	Signature w/o options: 5.9 kg (13 lbs)
	Signature w/ all interior options: 6.1 kg (13.5 lbs) Signature w/ all int. options + mounted battery backup: 9.1 kg (20 lbs)
Weight (Portable Signature)	Base Portable Signature w/ stand, TIENet Receptacle, DC Power Cable, Desiccator: 8.0 Kg (17.5 Lbs.)
	Optioned Portable Signature w/ Bubbler, stand, TIENet Receptacle, DC
	Power Cable, Desiccator, CDMA Modem, 3 option card, rain gauge: 10.1 Kg (22.3 lbs.) Includes antenna.
	Stand only: 3.9 Kg (8.7 lbs.)

Table 1-1Signature F	low Meter Technical Specificationsa (Continued)
Materials	
Housing Window Hardware	PPO Plastic (Noryl) Polycarbonate Stainless Steel
Enclosure	NEMA4X/IP66
Power	100 to 240 VAC, 50/60Hz, 1.3A; Disconnect Device = Line Cord 12VDC (optional battery backup)b 12VDC 4.0A battery standalone power
External Power Connection	DC Power: 12 or 24VDC Solar, DIN Rail, etc 10 to 28.5 VDC nominal 4VDC minimum for disposable battery use 36VDC Maximum 4 amp Time Delay fuse
Connections to Signature Flow Meter	
External TIENet devices	Bottom Cable entry, 1 to 4 position (3/4" NPT user-supplied conduit or optional cord grips); Pluggable screw terminals, 6-position;
Power supply Parameter inputs Analog Input Analog Output Contact Output Cellular Modems Ethernet 330 Bubbler module	Screw terminal, Wire 14-22 AWG Fixed terminals, 3-pin, Wire 14-30 AWG Pluggable screw terminal, 3-position, Wire 14-30 AWG Pluggable screw terminal, 3-position, Wire 14-30 AWG Pluggable screw terminal, 3-position, Wire 14-30 AWG Antenna Custom SMB connector RJ-45 connector Internal, factory-installed
Flow Measurement Technologies	Ultrasonic (TIENet 310) Bubbler (TIENet 330) Laser Doppler Velocity (TIENet 360 LaserFlow) Continuous Wave Doppler Velocity (TIENet 350)
Flow Conversions	Weir, Flume, British Flume, Metering Insert, Manning Formula, Equation, LTF or LTA Data Points (up to 50 pairs), Area Velocity
Data Storage	Non-volatile flash; retains stored data during program updates. Interval: 15 or 30 seconds; 1,2, 5,15, or 30 minutes; or 1, 2, 4, 12, or 24 hrs Capacity: 8M (180 days with 5 parameters logged at 1 minute intervals, reports at 24-hour intervals)
Setup and Data Retrieval	Serial connection to PC via USB; Cellular or Ethernet modem
Ambient Temperature Range (Operation and Storage)	-20 to 60 °C (-4 to 140 °F)c NOTE — The operating ambient temperature range of the optional mechan-
Optional Teledyne ISCO Sampler Interfacing	ical totalizer (see Section5.4) is -10 to 60 °C (14 to 140 °F). TIENet 306 device Output: Flow pacing, Enabling on trigger Input: Event and bottle information
Optional 304 TIENet Contact Output:	
Switching modes Max Load Isolation Outputs per card	Normally open, Normally closed 30 volts 1 amp Galvanic Isolation 2

Table 1-1Signature Flow Meter Technical Specificationsa (Continued)

Optional 307 TIENet Analog Input:	Configurable either active (signature supplying loop power) or passive (rely- ing on loop power, signature is not powering the loop).
Output voltage (in active mode) Range Isolation Maximum Load Outputs per card	17 VDC minimum 4 to 20 mA Galvanic Isolation 40022 maximum (in passive mode at 20 mA) 2
Optional 308 TIENet Analog Output:	
Range Isolation Maximum Load Outputs per card	4 to 20 mA Monolithic Isolation 900 ⁷ 2
Industry Standard Inputs	Two SDI-12, RS485 Modbus ASCII & RTU, 4-20 mA Analog
Industry Standard Outputs	4-20 mA Analog, Modbus ASCII & RTU
Rain Gauge Connectiond	Fixed terminals, 3-pin, Wire 14-30 AWG
Communication Options	Direct USB Serial Connection, CDMA (1XRTT), GSM (GPRS), and Ethernet

a. All specifications are subject to change without notice.

b. Power loss alarm options are available. Refer to 5.3 Power Loss Alarm in Section 5 Equipment Options.


c. Older model 69-4303-024 Connector Case circuit boards limit Ethernet ambient range to +40 °C (104 °F)


d. Optional industry standard rain gauge connector 60-4304-055.


Table 1-2TIENet 330 Bubbler Module Technical Specificationsa

Operation and Storage Temperature	-20 to 60 °C (-4 to 140 °F)
Level Measurement Range	0.003 to 3.05m (0.01 to 10 ft.)
Measurement Accuracy	±0.002m @ 22°C (±0.007 @ 72°F)
Temperature Compensation Range	0 to 60°C (32 to 140°F)
Temperature Coefficient (within compensated range)	±0.0003 x Level (m) x Temperature deviation from 22 °C ±0.00017 x Level (ft) x Temperature deviation from 72 °F
Bubble Line Entry	/8" Hose barb through bottom cable entry

a. All specifications are subject to change without notice.













Figure 1-5Specification drawing: Signature Flow Meter with stand in side facing position










Figure 1-6Specification drawing: Signature Flow Meter with stand in upward facing position




Figure 1-7 Specification drawing: Signature Bubbler Flow Meter, 1 of 2




Figure 1-8 Specification drawing: Signature Bubbler Flow Meter, 2 of 2

Signature[®] Flow Meter

Section 2Setup and Programming

The Signature Flow Meter is shipped from the factory with a default program already configured. The Signature Portable is shipped with different defaults than the Signature. Your particular installation will normally require different program settings, specific to your monitoring site and application.

This section of the manual explains the Signature's operating modes, and provides instructions for site setup and programming. Programming may be performed before transportation to the installation site.

The Signature Flow Meter can be set up, programmed, and inter-

rogated directly through the keypad and display screen, or remotely using a computer equipped with Teledyne Isco's Flowlink® software, with either a USB cable or optional modem.

The Signature Flow Meter has its own browser, accessed via Flowlink, that mirrors the physical keypad and display.

The following briefly explains the basic function of each key.

2.1.1Keypad Functions

2.1User Interface

The numerical keys are for entering values during setup/programming.

TBe arge softkeys (A, B, and C) perform whatever function is currently displayed above them. Note that pressing the BACK softkey (A) will discard any changes you have made without saving.

The arrow keys are for navigating to different areas onand off-screen. The up/down arrows navigate a single line at a time.

From the home screen, the Enter key is used to adjust or configure the currently highlighted parameter.

From programming screens, the Enter key confirms selections

and entries you have made, opens the setup/programming screen for a highlighted parameter, displays the character grid for alphanumeric entry, displays a calendar for date selection, or displays the pull down menu for a highlighted field.

Note

Enter is for selection only. The NEXT softkey is for selection *and* advancement to a subsequent step.

The home key returns the flow meter to the home screen from any other screen.

The delete key clears the last character entry, exits a pull down list, or closes an open window.

In addition to typing the decimal/period, this key can be used to navigate up one screen at a time.

The t key can be used to navigate down one screen at a time, and also to adjust screen contrast, when used with the up/down arrow keys.

2.1.2Connecting to the Signature with Flowlink software version 5.15.XX or later, you can set up, program, and download data from the flow meter through its browser. Connection between the flow meter can be direct, through the micro-USB assembly on the front panel, or remote, with an internal cellular or ethernet modem.

USB Driver for Signature In order for your computer to connect to the Signature flow meter through the micro-USB assembly, you must have the correct driver installed. USB drivers for both 32-bit and 64-bit operating systems are included with your flowlink program.

To install the driver:

After installing Flowlink, navigate to its program directory, and then to the USB Driver folder, typically at C:\Program Files\Flowlink 5.1\USB Driver.

Here you will find two drivers:

4300Driver_x64.msi for 64-bit operating systems and 4300Driver_x86.msi for 32-bit operating systems.

Without the Signature connected to your computer, begin running the appropriate file for your operating system. When prompted, connect the Signature to your computer's micro-USB assembly. You should see a message in the lower right corner stating that new hardware has been found at the appropriate com port number.

Ensure that the Signature flow meter is connected to the computer before launching Flowlink.

Connect window You can connect with the Connect window, or if you have connected with this site before, highlight the Signature site file in the workspace (left column in Flowlink) and select Item>Connect.

In the Connect window, select the Type of connection.

lonnect					
<u>4</u> 100/4200/6700) Instruments	<u>F</u> ield Wizard	2100 Instruments	Pulsed Doppler Instruments	<u>S</u> ignature Series
<u>Т</u> уре:	Oirect	C Modem	C Wireless C TCP		
<u>C</u> OM port: <u>B</u> aud rate:	7 2 3 4		TCP Address: 0		
<u>M</u> odem: <u>P</u> hone number:	10. 2				
Create <u>n</u> ew site	1				
☑ Show this dialo	g on startup				
			X Cancel		🦻 Help

Figure 2-1Flowlink Connect screen


Direct connection is made through the micro-USB assembly. From the COM Port pull down list, select the port associated with the Signature.

TCP connection is made from the computer to the Signature flow meter's optional CDMA, GSM, or Ethernet modem. Enter the correct static IP and port number, separated by a colon, the correct public domain address.

If you do not want the flow meter matched with an existing site

in the database, select the Create new site check box. (If this is the first time the flow meter is connected to Flowlink, a new site will be created automatically.)

Then click the large button under the heading Signature Series.



Site Screen

The Signature site screen has three tabs:

Site: Information specific to this site. Enter all relevant information into the Site Info fields, including the desired Site Name, and save the information by clicking Apply.

Site Info Devices Pro	gram	Connected
Site Name: <mark>Si</mark> te Address:	Isco Test Site 4700 Superior St., N of Cornhusker	Date / Time Device's Time: 9/26/2011 1:58:14 PM Computer's Time: 9/26/2011 2:00:37 PM Timezone: (GMT-06:00) Central Time (US & Canada)
Manhole Number: Site Comments:	H92-7-31 Pipe Dia. 15in.; Avg. 0.62 MGD. Heavy grease/ fats/oils	GPS Information Altitude: 1168 Latitude: 40.81 Longitude: -96.71
	Apply	Click Apply to save the site information you have entered.

Figure 2-2 Site Info tab

Devices lists the name, software version, and hardware version of the flow meter for offline viewing of the site file.

This information, along with that of any connected TIENet devices, can be viewed from the specific flow meter's firmware (refer to *Sensor Diagnostics*, on page 2-31).

ite Info Devices Program				Not Connected
Device information				
Module Name: Signature M	feter	SW/ Version:	1.16.040	
Model Name: Signature M	feter	HW Version:	AO	
Model Number: 4300		Boot Code Version:	3.04	
Serial Number: 211F02172	1			
Type: C Direct COM port: Default	• TCP	Baud rate: De	fault <u>×</u>	

Figure 2-3Devices tab

As define program The programming functions and displayed data in the browser are functions of the flow meter firmware, not Flowlink.

isco Test Site			
Site Info Devices Program			Connected
Isco Test Site			^
Total Flow:	↑		_
41240536 gal			
Total Flow 2: 213 gal	V		
Flow-A: 487 gpm	V		
Flow-B: 0.00000000 gpm			
330 Level: 0.666 ft			
310 Level: 0.827 ft			-
SHORTCUTS MENU [Status: 09/26/2011 14:17]		HELP	
Interrogate (FB) Home			
	Disconnect		Help
Isco Test Site Total Flow 41242481 gal Total Flow 2: 213 gal	†	The Browser Wi view (above) mi the Control display (at left)	
Flow-A: 486 gpm Flow-B: 0.00000000 gpm 130 Level: 0.666 ft 110 Level: 0.827 ft			
Status: 09/26/2011 14:21]			

Figure 2-4Program tab: Accessing the browser

2.2The Home Screen The home screen, or run screen, is displayed when the flow meter is in normal operating mode. This screen shows the current parameter readings and system status or alarm conditions.

A scroll bar on the right of the screen indicates there are more parameters off-screen that can be viewed by scrolling up or

Site Name	e Here	
Total Flow	N	
123456 Flow: 8.55 Level B: pH:		↓ ↓
[Status: 02/	06/2012 15:20]	
SHORTCUTS	MENU	HELP
Ā	В	С

Figure 2-5Home screen (normal operating mode)

2.3 Shortcuts	The Shortcuts menu provides quicker access to most commonly used commands, such as level adjustment or viewing data recorded over a period of time. Not all menu items described in this section will necessarily appear in your Shortcuts menu. The selections available in the Shortcuts menu are determined by what connected devices have been detected by the Signature fineter. To access your shortcuts, press SHORTCUTS (A).
2.3.1 Adjust Level 2.3.2 Adjust Velocity	To set a new level, enter the value in the field next to Level, and select Adjust. To update the current reading, select Update. This selection will open the velocity grid with current readings and laser controls for the TIENet LaserFlow velocity sensor. For complete information about this device, refer to the TIENet 360 LaserFlow user manual. The Signature Bubbler flow meter allows
2.3.3 Purge 2.3.4 Histograph	you to manually purge the bubble line if an obstruction is suspected. The histograph displays the measurements taken of up to three selected parameters in graphical format, beginning at your selected date/time, and spanning one to 48 hours. Enter a value in the Threshold field for a reference line. The measurements available for graphing are determined by what measurements are set up for data storage.
	incusurements are set up for data storage.

2.3.5Real-Time Measurement	The Real-Time Measurement will display the sensor/card options that are available. Once one is selected, a table will be displayed showing the different types of measurements the sensor/card is collecting.
	Reporting is set up from the Configure Options menu. Summary
2.3.6Report View	displays summaries of data measurements (i.e., Min/Max/Avg). History tracks user and meter events. Program tracks changes made to the flow meter's program configuration. To access the setup/program menus, press MENU (
2.4 Brodrommind	
2.4 Programming	B).
	When you press MENU, the four top menu options appear:
	<i>Hardware Setup</i> detects all devices connected to the flow meter, establishes proper communication with them, and allows configuration of each device.
	<i>Configure Options</i> sets up the measurement site and pro- gram parameters.
	Administration dictates operating preferences and perform
	general housekeeping tasks.
	<i>Home</i> returns to the home screen.
	Additionally,
	USB Options appears when a flash drive is connected to
	the micro-USB assembly in the lower left corner of the con- trol panel.
	The program menus consist of steps and substeps. During pro- gramming, available subordinate menu content and steps will be determined by what you have previously entered, and what optional equipment is connected to the Signature flow meter.
2.4.10ff-Screen Content	An arrow in the lower right corner of the flow meter's screen (see symbols at left) indicates that there is additional content on this screen in the direction the arrow is pointing. Use the arrow keys to access this content.
2.4.2Character Grid	A small grid icon in the lower right corner of the flow meter's screen (see symbol at left) indicates that the character grid is av ailable.
	Whenever you need to enter characters, such as letters, numbers, or punctuation, press Enter to display the character grid (Figure 2-6).
	Use the arrow keys to navigate to the desired character and press Enter to select. When you are finished editing, select DONE and press Enter.

Ζ






Figure 2-6Character grid





Fields with a pull down arrow next to them (see example at left) indicate a pull down list. Use the arrow keys to navigate between fields on the screen; when you highlight a pull down field, press Enter to display the items on the list. Then use the arrow keys and Enter to select from the list.









Figure 2-8Menu Tree: Hardware Setup

2.6.1Smart Sensor Setup (TIENet)	This selection will display the most recently detected TIENet devices connected to the Signature flow meter.
Perform Scan	If TIENet devices have been added or removed from the system, highlight Perform Scan and press Enter to detect the current system configuration.
Sensor Differences	If there are any differences in the device configuration since the last scan, a list of Sensor Differences will appear.
	Missing Sensors– The Missing Sensors list will indicate any previously connected devices that are no longer detected. Select Retain to keep the identification information for a previous device; select Remove to delete it.
	Replaced Sensors-The Replaced Sensors list displays any
	newly added sensors that have replaced Missing Sensors that have been Retained.
	Additional Sensors-Displays any newly detected devices.
	Following a scan, selecting NEXT from Sensor Differences will navigate to Configure Measurements.
Configure Measurements	Navigate to Configure Measurements to begin setting up mea- surement parameters for each TIENet device detected.
	To activate a measurement, highlight the radio button next to it
	and press Enter. To change the name of the measurement, high- light the name and press Enter.
	Regardless of what you name them, the measurement provement for the state of the st

position of each measurement for each type of TIENet device.



350 Area Velocity Sensor:

Level	Sense Voltage	Vel Spectrum Ratio
Velocity	Temperature	
Velocity Spectrum	Velocity Signal	

360 LaserFlow Sensor:

Distance	Ultrasonic Signal	Case Temperature	Air Temperature
Velocity	Sense Voltage	X-Axis	
Laser Temperature	Doppler Power	Laser Diode Current	
Y-Axis	Level	Window Temperature	

Figure 2-9Measurement parameters for each TIENet device

2.6.2SDI-12 Setup	Sondes detected since the last scan are displayed, with the activated sondes in the top box. If SDI-12 devices have been added or removed from the system, select Scan to detect the current system configuration. Following the scan, add/remove sondes from the Active list by selecting the sonde and clicking Add or Remove. To begin using an ISCO-Ready sonde with its configured parameters, select Configure.
2.6.3Modbus Input Setup	Connect the external Modbus input device at one of the three TIENet terminal connectors on the Signature case board as described below: Modbus In D1 = Yellow (+) D0 = Brown (-) Gnd = Black
	Table2-1 on the following page provides an example of Modbus settings for a connected DGH analog converter. The letters in the left column correspond to the entry fields shown in Figures2-10 and2-11.
	The multiplier and offset are used to scale the raw number coming from the Modbus register(s) to represent the data in the units of measure you specify, as expressed in the following equation:
	H in units of measure = (register value * J) + K .
	In this example, the current input represents a flow rate where: 4mA = 0cfs, and 20mA = 10,000cfs
	The D1252M documentation states that it produces a register value of 0 at 0mA, and 65535 at 25mA. This means that at 4mA the register will report 10485, and at 20mA it will report 52428.
	The multiplier (J) is calculated as follows: 10,000/(52428 – 10485) = -2500
	Before setting up the Modbus input function, it is recommended that you print Table2-1 and use the empty columns provided on the right to fill in your own Modbus information.

	E xa mµ	ol es:	Table 2-	-1Modbus Setup Worksheet	
	Manufacturer	DGH	Manufacturer	Manufacturer	
	Model	D1252M	Model	Model	
Α	Protocol (ASCII/RTU)	ASCII	Protocol (ASCII/RTU)	Protocol (ASCII/RTU)	
В	Baud Rate	9600	Baud Rate	Baud Rate	
С	Data Bits	8	Data Bits	Data Bits	
D	Parity	None	Parity	Parity	
E	Stop Bits	1	Stop Bits	Stop Bits	
F	Device Name	D1252M	Device Name	Device Name	
G	Address	11	Address	Address	
н	Parameter	Flow Rate X	Parameter	Parameter	
Ι	Addressa (Register)	30001	Address (Register)	Address (Register)	
J	Multiplierb	.238422	Multiplier	Multiplier	
K	Offsetb	-2500	Offset	Offset	\neg
H-	Byte Orderc (Endian)	Little	Byte Order (Endian)		\neg
<u>⊢</u> M-	Data Size (Format)	Unsigned Word	Data Size (Format)	Data Size (Format)	\neg
N −	Data Type	Flow Rate	Data Type	Data Type	\neg
	Units	m3/s	Units	Units	\neg

a. For 2100 update interval in seconds must be written to register 26.

b. For assistance in calculating a multiplier and offset, contact Teledyne ISCO

c. Big Endian = Most significant register first; Little Endian = Least significant register first.

To begin configuring Modbus communication protocol and devices, select MODBUS Input COM Settings and use the pull down menus.

Add/Edit Device

Select Modbus Input Device Settings. Enter the device name, and the device address. For Request Timeout, enter a connection retry interval in milliseconds, and the number of attempts before a connection failure is determined.

Configure Modbus communication protocol using the pull down menus. To add/edit parameter(s) for the device, select Edit Parameters.





Figure 2-10 Modbus Input Setup

Note

External Modbus RTU devices cannot use addresses 1 through 10.

Add/Edit Parameters Select an existing parameter to edit, or select Add to add a new parameter for the device. Enter a name (such as a data type), and the register address. Use the pull down menus to select other par ameters.



If necessary, enter a Multiplier and Offset so the register reports a value in the units specified.




Figure 2-11 Editing Modbus device parameters

2.6.4Modbus Output Setup

The Modbus RS-485 output function enables a SCADA system to retrieve site data from the flow meter. Connection to the flow meter is made via the RS-485 terminal on the Signature case board (shown in Figure2-12 below).

In the **Device ID** field, enter the Signature's address (from 2 to 247) and configure the communication protocol.

Be careful not to assign the same address to more than one flow meter.

For Modbus data register numbers and definitions, as well as a general explanation of Modbus output protocol, refer to TableC-1, in AppendixC *Modbus Output Protocol*.




Figure 2-12 Modbus Output Setup

Note

Power cycle may be required for settings to take effect.

2.6.5Modem Setup	The menu choices displayed for modem setup depend on which modem option is installed in the flow meter. For detailed infor- mation about installation and operation of Ethernet, GSM, and CDMA modems, refer to Sections5.9 <i>Ethernet Modem</i> and 5.10
	and5.10 Cellular Modems.
	ochatal riodento:




Figure 2-13 Menu Tree: Configure

2.7.1 Site Setup	The Site Setup menu sets some basic operating characteristics specific to the site.
	Set Clock–Enter Year, Month, Day, Hour, Minute. Site Name–Press Enter to display the character grid. Select one
	character at a time to create the desired site name.
	Home Display– The Home Display determines how current measurement data is displayed on the Home screen.
	From the Measurements Setup screen, select all measurement
	parameters to be displayed. The parameters available in the pull down menus will be determined by what devices are connected
	to
	the Signature meter. Default Units– To set units of measure for each parameter,
	first select the parameter from the menu list.
	The available units of measure that appear will be determined by
	the parameter you have selected. Under Units, highlight the units of measure and press NEXT. When finished, press NEXT again to save and exit.
	Powlers ppyions allow ever the hope to ask light and the
	screen.
	•Low Battery Cutoff: will allow you to adjust the low battery cutoff. Refer to Section 4-4 for more power infor- mation.
2.7.2Measurement Setup	This menu is for setting up the level measurement (Level Input
	Setup), flow conversion (Flow Input Setup), and flow volume totalizer(s) (Volume Input Setup). Menu items that appear are dependent on what equipment is connected to the Signature flow meter.
	Level Input Setup- Under Level Setup, select the level input. Usually there will only be one listed, unless your system is using more than one level measurement device.For the TIENet 310 ultrasonic sensor, the minimum blanking distance refers to the maximum water level, and the maximum blanking distance refers to zero water level in the channel. For detailed instructions about 310 setup, refer to the TIENet 310 Installation and Oper- ation Guide.
	For the TIENet 330 bubbler, the purge function is a periodic burst of air forced through the bubble line to keep it free of debris. Select the purge interval between 15 minutes and 8hours from the pull down menu
	Flow Rate Input Setup-Measurement settings and flow con-
	version are programmed for the flow rate(s) from this menu (refer to Figure2-14 on the following page). If more than one flow rate data set is being calculated, these settings are programmed separately for each one.
	1.Select the flow rate to configure or select "Add Flow Rate"

1.Select the flow rate to configure or select "Add Flow Rate" when two or more flow rates are present. Adding a flow rate enables calculation of flow rates dependent on condition. The flow rate also allows for configuring standard flow conversions from level inputs (e.g. level from Analog Input).

2.For level-to-flow conversions, from Measurement Settings, select the Level Input to be used in the flow calculation and the Measurement Rate (interval). Enter the name for this flow rate.

3.Select the flow conversion type to be used (Weir, Flume, Metering Inserts, Manning Formula, Area Velocity, Equation, or Data Points); then set up the conversion.

Note

Additional information about flow conversions can be found in the *ISCO Flow Measurement Handbook* included with the Signature Flow Meter.




Figure 2-14 Menu Tree: Flow rate input setup

VolumenInput: **βetup**-to four Total Flow measurements. Select the flow rate(s) used for total volume, the totalizing method (Net, Positive, or Negative), and the interval at which the total flow will be updated (between 30 seconds and 24 h ou rs).

From the Resolution pull down menu, select the degree of resolution required for your total flow (lower = fewer digits to right of decimal; higher = more digits to right of decimal).




Figure 2-15 Menu Tree: Volume Input Setup (total flow)

Rais fait imput Setupou to setup the per tip options for the rain gauge. The Automatic roll-over can be set to the time of day the rollover occurs. Once this number is reached, the roll-over will go back to zero.

300 Rainfall SELECT RAINFALL PER TIP	
● 0.01 inch	
⊖0.1 millimeter	
⊖User Entered 0.00 inches	
Automatic roll-over: 00:00:00)

Figure 2-16Menu for Rainfall Input Setup

2.7.3 Adjust	Adjust levels and/or velocity measurement, and/or calibrate mea- surement values for other connected TIENet devices. Level adjustment instructions can be found in Section <i>Setting the Level</i> , on page 3-18.
	For detailed instructions on calibration of a connected TIENet 301 pH device through this menu selection, refer to the 301 user manual.
	For detailed instructions on laser velocity measurement setup through this menu selection, refer to the LaserFlow (360) user m anual .
2.7.4 Equation/Trigger Setup	<i>Conditions</i> are sets of site-specific, user-defined parameters. Refer to Figure2-17 on the following page.
	<i>Equations</i> are created from various site conditions that can be used to generate alarms, log or push data at secondary rates, trigger a connected sampler, or conserve power by turning on equipment only when needed.
Types of conditions	There are five types of conditions provided:
	Range- TRUE when a measured parameter value is inside or outside specified upper and lower limits. Rate of Change- TRUE
	when a measured parameter changes by a specified amount over a specified time duration.
	Sensor Error– TRUE when a sensor error is present for a spec- ified time duration.
	Threshold –TRUE when a measured parameter reaches or exceeds a user-defined setpoint.
	Time Table –TRUE when the flow meter's internal clock is
	within a defined time duration. This may be a weekly, daily, or specific one-time stop/start time.
	Rain Event- TRUE when threshold is met over a period of time. Meeting threshold during the dry period will reset the Dry Period timer.
Defining conditions	To define a condition:
.,	1.Highlight the desired condition in the lower left corner of the screen (Conditions A-F).
	2.Highlight Edit Condition and press Enter.
	3.Scroll down and press Enter to select the type of condition (listed above). Press NEXT to go to the configuration screen for that condition type. Press NEXT when complete.
	The condition in the left-hand corner of the screen will now show the condition type.

Building equations	Build or modify the equation by navigating to the desired condi- tions and operators. Highlight Select Condition and press Enter again to add it to the equation. Press Enter to add a highlighted operator.
Measurement Interval	Press NEXT when complete. When the screen is off and measurement interval is less than the data storage rate, the readings will be averaged and the battery life will slightly decrease.




Figure 2-17 Example of defining conditions & building equations.

2.7.5Data Storage/Push Setup	Data Storage- Set up data storage rates for a group of mea- surements, or separately for individual measurements. Scroll to the bottom of the screen to set up the primary storage rate, and a secondary one, if needed, with its trigger equation.
	The display can be turned OFF and ON in the configure options, site setup, and power options menu. Turning the display OFF effects the way the data is recorded by the Signature meter.
	•When the display is ON the Signature takes an average of the measurements over the data storage interval and records it.
	 When the display is OFF the Signature takes a reading at the reading interval set in the data storage screen (no average is taken) unless alarms, triggers, or secondary measurements are active.
	•When the display is OFF and if alarms, triggers, or secondary measurements are set up and the intervals are shorter than the data storage rate, the readings recorded by the meter will be an average of readings taken when the alarms, triggers, or secondary measure- ments were taken.
	Data Push – Set up the flow meter to push data to a server running ISCO Flowlink Professional software (internal modem required).
2.7.6Sampler Setup	Program the flow meter to trigger and pace a sampler, and receive sampling information from the sampler.
	Note For detailed instructions on configuring a connected TIENet 306 Sampler Interface through this menu selection, refer to the 306 user manual.
2.7.7 Inputs/Outputs/Alarms Setup	Alarm– Configure Local, SMS text, or Server alarms based on user- defined site conditions. Under Alarm, select an alarm from the list or set up a new alarm.
	Next, select an Alarm Trigger from the pull down list.
	Note The trigger(s) listed in the Alarm Trigger pull down list consist of equations you have already created based on your defined site conditions (refer to Section2.7.4 Equation/Trigger Setup).
Alarms: Local	Local alarms are viewed on the Signature Flow Meter itself. When a programmed alarm condition becomes true, the LED on the front panel glows red.
	To view the alarm message, press the Alarm softkey (). For local alarm setup, refer to Figure2-18 on the following page.

Alarms: SMS / ServerSMS and Server alarms require an optional internal modem. To
configure your modem for communication, refer to Section5.9
Ethernet Modem or Section5.10 Cellular Modems.



Server alarms notify a specified list of contacts in the event that a server running Flowlink Pro fails to receive pushed data from a site within a specified duration.

For SMS and Server alarm setup, refer to Figure2-19.




Figure 2-18 Local alarm setup




Figure 2-19 SMS and Server alarm setup (modem required)

AdataglOutptpt to configure, then select and configure the measurement the output will represent. TIENet 308 option card required (see Section5.6.10).

Analog Input–Select the input to configure, then select and configure the measurement the input will represent. TIENet 307 option card required (see Section 5.6.9).

Contact Output-Select the output to configure, then select and configure the measurement the output will represent. TIENet 304 option card required (see Section 5.6.8).

2.7.8 Reset Totalizers	Select the flow volume totalizer(s) to be reset. Selection resets the totalizer to zero.
2 7 OBananta (Iliatam/ Catum	Reports- Set up report interval and measurements to include
2.7.9Reports/History Setup	for one or two reports. To include all user and meter events in the report, select the option Include history log.
	History– Display user and meter events (i.e., log-ins, adjust- ments, data push, etc.), and/or set up the graphical display for selected measurements over a period of time.
2.8 Administration	Administrative settings (see following page) dictate operating preferences and perform general housekeeping tasks.




Figure 2-20Menu Tree: Administration

2.8.1Language Options Select Devistes Language default lan- guage to be displayed by the Signature flow meter. Available lan- guages include:

English (USA)	Dansk	Português (Brasil)	Deutsch
English (International)	Nederlands	Español (México)	
Français	Türk	Svenskt	

From this screen, you can also set general default Units Of Measure to USA or International. You can still select units of measure for individual measurements through Configure Options > Site Setup.

Note

Power cycle may be required for settings to take effect.

2.8.2Set New Passcode A numerical passcode can be set to protect access to pro- gramming and data. By default, the flow meter is not passcode-protected. To change an existing passcode, enter the current passcode, and then the new passcode. To remove the passcode requirement, enter a new passcode of 0 (zero).

2.8.3Update Firmware To use this function, first connect a flash drive loaded with the correct firmware update file(s) to the micro-USB assembly. Refer to Section 2.9 *USB Options* for complete instructions.

2.8.4Sensor Diagnostics The Signature provides operating data for each connected TIENet device upon request, for site evaluation or trouble-shooting purposes.

To generate a new diagnostic report, select **Retrieve Diag-nostics**. The available devices can then be selected from a list. When the diagnostic data is available, press Enter to view it.

To view past diagnostic reports, select **Review Diagnostics** and select from the list of devices. Each past diagnostic report will be listed by date and time.

Diagnostic reports can also be downloaded to a connected USB flash drive in the form of a text file. Refer to *Retrieve Text Reports*, on page 2-33 for complete information.

Note

If you are running diagnostics on a 360 LaserFlow velocity sensor, the Distance in the text report and graph are relative to the face of the integral ultrasonic transducer, which is located 11.7" above the bottom of the sensor. Subtract 11.7" from the Distance shown to obtain the actual value. For more information about the LaserFlow sensor, refer to Section5.6.3 *Laser Doppler Velocity Sensor* and the Laser- Flow user manual.

2.8.5Display Signature In form at i on	Select this option to view the serial number, model number, software revision, and hardware revision of the Signature flow meter and any connected TIENet devices.
2.8.6Display License In form at i on 2.8.7Gather Fault Data	This selection displays open-source licensing and copyright infor- mation for the Signature firmware. Fault data is a term describing the capture of any user and/or flow meter activity prior to and during a system error or failure. This data can be displayed to assist in troubleshooting. To download the data to a flash drive, connect a flash drive to the micro-USB assembly on the front panel of the Signature and select Gather Fault Data from the USB Options menu that appears (refer to Section2.9 <i>USB Options</i>).
2.8.8 Restore to Factory Defaults	This function returns the Signature Flow Meter to the program that was installed the factory. This is an example program that can be used for reference when designing your own program. If the restore to portable defaults check box is selected, the power savings options will be automatically turned on.
	Be sure to record your own program settings and save all data before restoring the factory defaults.
2.8.9 Home	HOME returns to the home screen. The USB Options menu will
2.9USB Options	only appear when you connect a flash drive to the micro-USB assembly on the front panel of the Sig nat ur e.




Figure 2-21Menu Tree: USB Options

2.9.1 Retrieve Text Reports Select this function to download the Signature data text reports for sensor diagnostics and verification of data integrity.

Select "All reports," or specify a start date or date range, and press NEXT. The reports will be stored on the connected flash drive in a folder called "ISCO."


This folder contains a sub-folder for each site, named with the first eight characters of the site name. The site folder contains one or more sub-folders, named by retrieval date (YYYYMMDD).

Each report file name has a prefix of one or two letters, followed by four digits representing the time of day, e.g., PH0935.TXT is a program report generated at 9:45 a.m.


Each report is contained in a text file, with a .TXT extension, or in a Smart Sensor Diagnostic file, with a .SSD extension. Each report file has a corresponding authentication file, with a .ath extension, for verification purposes. For more information about report verification, refer to *Verifying Exported Reports*, on page 2-36.

The four validation report types are:

	Program Report (PH) — Tracks changes to the Signature Meter's configuration
	Documents summaries of data
	Diagnostic Report – Tracks the occurrence of, and results
	from, diagnostic tests History Report (H) – Tracks user and meter events (e.g. level adjustments, calibration, data push, etc.) The program settings and flow data can be downloaded onto
2.9.2Retrieve Data	
	your flash drive in .ddp (data dump) format. Select "All data," or specify a start date or date range, and press NEXT. The data will be stored on the connected flash drive in a
	folder called "ISCO."
	This file can then be imported into Flowlink, where it can be viewed in regular site file format, with the recorded data and report/graphing capability.
2.9.3Update Firmware	There is a check box that, when checked, will export the .cvs file onto a USB flash drive.
2.7.50puate i iniware	With a USB flash drive connected to the Signature's front panel,
	the Update Firmware option becomes active on both the Admin- istration menu and the USP Options menu.
	For step-by-step instructions for updating the firmware for either the Signature flow meter or connected TIENet devices, refer to <i>Firmware Updates</i> , on page 6-2.
2.9.4Save Current Program	Select this option to save a copy of the Signature's current
	program to your USB flash drive. You can also use this infor- mation to program other meters with the same configuration.
2.9.5Load Existing Program	Select this option to load a saved program from your flash drive.
	Note that selecting this option will cause the current program to be overwritten with the one from the flash drive.
	In order for the Signature to load the correct program, the name of the site must match that of the site program that was saved.
2.9.6 Save Signature In form at i on	This option saves a snapshot of the firmware version(s) and serial number(s) of the Signature and any connected TIENet devic es.
2.9.7Gather Fault Data	Fault data is a term describing the capture of any user and/or
	flow meter activity prior to and during a system error or failure. This data can be viewed and/or downloaded as a file to your flash drive to assist in troubleshooting. This item returns the screen to the top menu.
2.9.8None of the above	However, as long as the flash drive remains connected, the USB Options menu will still be active, and can be reopened from the Administration menu.



E		2/17/2011 11:00:00	Report Signature Site Interval 2011-02-18105:00:00 to 2011-02-18108:42:15 Voltage: 13.527621
	*	2/17/2011 11:00:01	Report Signature Site Interval: 2011-02-18T10:00:00 to 2011-02-18T11:11:34 Voltage: 12.8071290
-	*	2/14/2011 11:00:00	
H	*	2/15/2011 7:20:30 PM	LOGGED_IN
R	*	2/16/2011 1:41:30 PM	LOGGED_IN
R	*	2/16/2011 3:22:50 PM	LOGGED_IN
			2/17/2011 11:00:01 2/14/2011 11:00:00 2/15/2011 7:20:30 PM 2/16/2011 1:41:30 PM



Printing reports	Select one or more rows in the viewer to be printed and then select the Print button.
Exporting reports	To save event data as a text report for future verification, high- light the desired row(s) in the Event Viewer table and click Export (or right-click and select Export).

The default destination is your My Documents folder; however, you can change this to another preferred destination, including a USB drive, if preferred. A message window will notify you when the export is complete.

The files you exported are saved using the following hierarchy: SITENAME \ MODULENAME \ DATE.

Flowlink will only export already verified reports; they can also be verified after being retrieved from the Signature, either via Flowlink export or USB flash drive download.

Verification of exported data reports is done using the **Report Verification tool**, a small application installed separately when Flowlink was installed. This tool is located in the Flowlink program folder, normally at C:\Program Files\Flowlink 5.1, and

is identified with a traffic light icon .



Note that this tool can also be used to verify data exported directly to a USB drive using the USB Options menu (refer to Section2.9).

Use the top Browse... button to navigate to the desired report (*.txt or *.SSD) file. Use the bottom Browse... button to navigate to its corresponding authentication (*.ath) file. Click Verify. The application will quickly return a message showing the verification result.



2.11Verifying Exported Reports

Figure 2-23 Report file verifier

Signature[®] Flow Meter

Section 3Standard Installation

This section contains physical preparation procedures and permanent mounting methods for the Signature Flow Meter and associated Teledyne ISCO equipment. Section 4 will contain the installation information for the Signature Portable Flow Meter.

WA RNING

The installation and use of this product may expose you to hazardous working conditions that can cause serious or fatal injury. Take all necessary precautions before entering a worksite. Install and operate this product in accordance with all applicable safety and health regulations and local ordinances.

3.1 Introduction The Signature Flow Meter is used for permanent installations.

3.2Connecting External Devices

External device cables and mains line cord are passed, usually via conduit or cord-grip fittings, through the port holes in the bottom of the case and wired directly to the connector case.

Cable

fittings are also available for Rain, Ethernet and option card circuits as a 3 hold cord grip.

Trimming unterminated wires prior to installation is recommended.

Tools Requified screwdriver (3.5mm)

#2 Phillips screwdriver

Channel locks

Soldering iron (for tinning wires)

Before opening the case, first ensure that mains power is disconnected from the unit.



Before opening the case, disconnect the optional battery or battery backup power, if used.

Note

Before restoring mains power, ensure that the flow meter's USB connector does not have a cable attached.

Open the door to access the two large screws holding the front panel on the connector case. Remove the two screws, then reinsert them in the front panel and latch the lid so they will not be misplaced.




Figure 3-10pen door and front panel to access interior

Open the front panel to access the connector case. Connectors on the board are identified in Figure 3-2.





Figure 3-2Connector case, connectors, and fuses



3.3Case Bottom Cable Entries

The connections made through the cable entries depend on the application, but their most common uses, in accordance with the connector case layout, are depicted on the following page.

All optional cable entries must use appropriate ID conduit connections or cord-grip fittings to retain the IP66 rating. If you are using non-TIENet or non-Signature cables, you must supply the appropriate ID conduit connections or cord-grip fittings.

If you are using conduit instead of the cord-grip fitting, the conduit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life.




Figure 3-3Connector Case cable entries for power and external devices

3.3.1Cable Fittings

Cord-grip fittings for TIENet devices, line cord, and battery backup option are available from Teledyne ISCO (see Appendix B for ordering information). Cable fittings are also available for rain, ethernet, and optional card circuits as a 3-hole cord grip.

The fitting for the line cord is a special strain-relief fitting, as shown in Figure 3-5.



Figure 3-4Strain relief 3/4 NPT Cord-grip fitting for TIENet devices



Figure 3-5Cord-grip fittings installed

Any unused cable entry holes should be sealed with plugs. Do not overtighten the plugs. When a plug is flush against the outside of the case and held in place by the metal nut inside, the hole is sealed.



Figure 3-6Diameter-seal plugs for unused ports

3.3.2Connecting TIENet Devices

The optional external TIENet devices compatible with the Signature flow meter all connect in the same manner. Multiple TIENet devices can be connected simultaneously to the same Sig- nature Flow Meter.

Mote

The steps that follow include instructions for installing cord-grip fittings. Some applications will use user-supplied 3/4" ID conduit for cable routing.

1.Remove one of the 6-position plug-in terminal strip connectors from the connector case.




Figure 3-7TIENet Device terminal strips

- 2. If using a cord-grip fitting, install the cable nut in the appropriate opening on the bottom of the Signature enclosure, securing it to the wall with the lock nut (concave side facing wall).
- 3.Feed the TIENet device cable end through the sealing nut and seal, and through the cable nut. Lightly tighten the sealing nut, just enough to hold the cable in place while installing the connector.





Figure 3-8Installing TIENet cable with a cord-grip fitting

4.Attach the wire ends to the terminal strip as shown in Figure3-9, then press the terminal strip back down into its socket on the case board, as shown in Figure3-10, taking care not to strain any wire connections. Gently tug each wire when finished, to verify secure connection to the screw terminals.

🗹 Note

The SHIELD wire is the bare drain emerging from the foil shield around the YELLOW and BROWN wires. The BRAID-DRAIN wire is the bare drain emerging from the sur- rounding braided shield inside the cable jacket. It is not neces- sary to prevent the two braids from coming into contact with each other.



D1	YE LL OW
D0	BROWN
Shi el d	S HIEL D
VP	RED
Common	BL ACK
Chassis	BRAID DRAIN

All optional cable entries must use appropriate ID conduit connections or cord-grip fittings to retain the IP66 rating. If you are using non-TIENet or non-Signature cables, you must supply the appropriate ID conduit connections or cord-grip fittings.

Figure 3-9TIENet Device terminal connections




Figure 3-10 Attach wired terminal strip to connector case socket

a. Systems using the LaserFlow or Area Velocity 350 Sensor:

Insert the reference tubing into the REF AIR port on the case board, pushing it down inside the silicon tubing. Be careful not to kink the reference tubing.




Figure 3-11Insert the cable reference tubing into the case board reference port

5. Tighten the cord grip sealing nut.





Figure 3-12 Position and secure the cable

6.Close the front panel and fasten it shut with the two Phillips screws.

If you are using conduit instead of the cord-grip fitting, the conduit must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life.

3.4 Power	The Signature is in compliance with North American and Inter- national safety standards while the input voltage remains within 100-240VAC (50/60Hz).
	For external current protection, a 2A slow-blow or time-lag fuse between mains power and the Signature is recommended to accommodate up to 40A inrush current at power up in applica- tions up to 230VAC.
	The flow meter comes with the internal power supply wired to
	the connector case, and held in place by a screw (see Figure3-13 on the following page). Mains power is wired into the Signature's internal power supply, normally via a standard three-wire line cord or hard-wiring through user-supplied conduit.
	Vote
	The Signature flow meter must be installed in accordance with the National Electric Code (NEC) NFPA70 for installation in the United States, or the Canadian Electric Code (CEC) for instal- lation in Canada, or other local installation codes as applica- ble.
3.4.1Hard Wiring	Cable entries for hard wiring must use appropriate ID conduit connections.
	CAUTION If you are using conduit instead of the cord-grip fitting, the con- duit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life.
	If you are using conduit instead of the cord-grip fitting, the con- duit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal
3.4.2Line Cord	 If you are using conduit instead of the cord-grip fitting, the conduit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life. If the instrument has been hard-wired for power, ensure that a switch or mains circuit breaker is installed near the instrument
3.4.2Line Cord 3.4.3Power Connections	 If you are using conduit instead of the cord-grip fitting, the conduit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life. If the instrument has been hard-wired for power, ensure that a switch or mains circuit breaker is installed near the instrument for easy access to remove power in the event of an emergency. If the instrument has been fitted with a line cord, ensure that its installation is near a mains outlet for easy access to remove power
	 If you are using conduit instead of the cord-grip fitting, the conduit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life. If the instrument has been hard-wired for power, ensure that a switch or mains circuit breaker is installed near the instrument for easy access to remove power in the event of an emergency. If the instrument has been fitted with a line cord, ensure that its installation is near a mains outlet for easy access to remove power in the event of an emergency. Teledyne ISCO offers an AC line cord kit that is installed at the factory when ordered with the Signature. It is also sold sepa-



Connector Case

Figure 3-13Location of power supply

3.5Mounting the Signature

The Signature can lie flat on a horizontal surface, or be attached to a wall using the stainless steel bracket on the back of the case.

It can also be installed inside a console enclosure with other system components. If a console enclosure is used, ensure that it provided proper sealing to protect the flow meter and other equipment from harsh environments and/or moisture.

Because it uses a bubble line, the Signature does not have to be

mounted directly above the primary device, or even particularly close to the flow stream. You will need to mount the unit within 25 feet (7.6 m), or 50 feet (15.3 m) if you are using the 100 foot bubble line. Distances greater than 100 feet are not recommended.

The mounting location should allow for easy removal and rein-

stallation in the event that cleaning, testing, or replacement is required. Refer to the dimensional drawings on the following pages for physical installation specifications.



Figure 3-14 Signature Flow Meter mounted on wall

3.6Outdoor Recommendations

Where the Signature Flow Meter is mounted outdoors, a weather shield for protection from direct sunlight and rain is recommended. The shield should accommodate the flow meter's 18 inch dimensions with the cover opened, as shown below.





Figure 3-15 Weather shield - recommended for outdoor installations (Drawing & Photo courtesy of TRACOM, Inc.)

3.7The Bubble Line	Anchor the bubble line in the flow stream at the appropriate measuring point in the weir, flume, or other open channel flow situation. Air slowly bubbles out of the line into the flow stream. The pressure in the bubble line is proportional to the liquid level in the flow stream, and the flow meter measures this pressure, sensing the liquid level.
3.7.1 Standard Bubble Lines	Three different bubble lines are available for use with the Sig- nature:
	•(1/8" (0.32 cm) OD PTFE, 1/16" (0.17 cm) ID, 25 ft. (7.6 m) long) •(1/4" (0.63cm) OD vinyl, 1/8" (0.32 cm) ID, 50 ft. (15.2 m) long) •(1/4" (0.63 cm) OD vinyl, 1/8" (0.32 cm) ID, 100 ft. (30.5 m) long)
3.7.2Comparing Vinyl and PTFE Bubble Lines	Wherever practical, Teledyne ISCO recommends the vinyl line, which offers significant advantages over the PTFE line. The vinyl line has a longer usable length than the PTFE line. This is due to the small inside diameter of the PTFE tubing, which gen- erates an undesirable friction head at lengths greater than 25 feet. Additionally, experience has shown that the larger ID vinyl line is less likely to clog than the PTFE line when used in flow streams with suspended solids. If the distance between the flow meter and the measuring point exceeds 25 feet, you <i>must</i> use the vinyl bubble line.
	However, for certain installations, the smaller ID PTFE line also has advantages. Due to the small inside diameter, the air volume necessary (and, as a result, battery power) is minimized, a definite advantage for battery-powered installations. Addi- tionally, almost no chemical can attack the PTFE line. Conse- quently, if power consumption is critical, or there are known agents in the flow stream that might attack the vinyl line, the PTFE line may be more suitable.
3.7.3 Bubble Line Length	The bubble line should be kept as short as possible. This will minimize friction head effects in the line and will also minimize the amount of line exposed to cuts, kinks, etc. Shorten the line as necessary by cutting the tubing with a sharp knife. Long Bubble Lines – For certain applications, you may need to use a bubble line with an inside diameter larger than that of the standard lines (for example, where the bubble line exceeds 50 feet, or where the flow stream is extremely dirty and the end of the line might clog). Consult the factory for specific recommendations regarding size of line, special connectors required, etc. In no case should the inside diameter of the bubble line exceed 1/4" (0.64 cm), and you should recognize that a larger bubble line will result in increased power consumption, a concern if you must power the flow meter by battery.

3.7.4 Attaching the PTFE Bubble Line	The PTFE bubble line attaches to the flow meter with the bubble line fitting on the bottom of the case and the silicone rubber tubing connector. The tubing connector is a short length of 0.109 inch (0.20 cm) ID, 0.192 inch (0.49 cm) OD silicone tubing attached to a barbed fitting on the case.
	The 1/8" OD bubble line simply slips inside the silicone tubing, forming a reliable union you can join and separate without tools.
At t ach men t	To attach the PTFE bubble line, first slip the 2 inch (5.1 cm)
	length of 1/4" (0.63 cm) ID vinyl tube included in the instrument accessory package over the end of the bubble line. Grasp the sil- icone tube to stiffen it and insert the end of the bubble line into the silicone tube.
	Slip the short length of vinyl tube over the union and force it over the shoulder of the barbed fitting. The purpose of the short length of vinyl tube is to support the union, preventing fatigue or kinking of the silicone tube.
Removal	To remove the bubble line from the tubing connector, first pull the vinyl tube off of the barbed fitting and slip it down the bubble line. Grasp the end of the silicone tube and then pull the bubble line straight out of the silicone tube.
	Several replacement lengths of the silicone tubing are included
	in the instrument accessory package. Install them on the unit by simply forcing the end of the tube over the barbed connector.
	Note
	Avoid placing tension on the silicone tube where it attaches to the barbed fitting. Direct the PTFE tube straight away from the fitting rather than at an angle. This reduces the likelihood of tubing wear and leakage around the fitting.
3.7.5 Attaching the Vinyl Bubble Line	The vinyl bubble line attaches directly to the barbed fitting. Remove the silicone tube and slip the 1/8" (0.32 cm) tubing over
	the fitting.
3.7.6 Installing the Bubble Line	Install the bubble line at the recommended level measuring point
	in the primary device or other open channel flow situation. If you do not know where this is, consult the manufacturer of the primary device.
	If you are not using a fabricated device, consult the <i>ISCO Open</i>
	Channel Flow Measurement Handbook for suggestions. Many dif- ferent devices are discussed there. Proper location of the bubble line outlet is necessary for accurate measurement. Normally, the bubble line is positioned in the flow stream with the end at a right angle to the flow.
	In many installations, it is not practical to locate the outlet of the
	bubble line precisely at "zero" liquid level. Depending on the situ- ation, the outlet end of the bubble line may be located anywhere within ten feet (3 m) above or below the actual zero level of the primary device. Then set the displayed level using Adjust Options from the Configure menu. Refer to Section 3.8 <i>Setting</i> <i>the Level</i> .



The Signature cannot accurately measure liquid levels that are even with or below the bubble line outlet. If you need to measure the liquid level down to the actual "zero" level of the primary device, Teledyne Isco recommends placing the bubble line outlet at least 1 to 2 inches (2.5 to 5.1 cm)**below** the primary device zero level to avoid measurement failures when the liquid level is even with the outlet. Since the flow meter can display negative measurements, you can com- pensate when you set the level in the flow meter.



End View

Side View

Figure 3-16 Positioning the Bubble Line in the Flow Stream

3.7.7High-Velocity Flow Stre ams The normal position of the bubble line in the flow stream is at a right angle to the flow. However, studies have indicated that at relatively high flow stream velocities (greater than five feet per second [1.5 meters per second]), this location may lead to a mea- sured level lower than actual. This negative level offset is due to localized areas of low pressure near the bubble line outlet; the size of the offset depends upon the velocity of the flow stream and the configuration of the flow stream channel. You can, of course, adjust the level at the flow meter to compensate for the error. However, this is only effective if the flow rate and velocity decreases, the level adjustment you made earlier will be incorrect for the new, lower velocity and flow rate.

	The best way to overcome this problem is to completely isolate the bubble line from the flow stream velocity by placing it in a stilling well, as described below. If this is not possible, you can perhaps create a cavity in the bottom of the channel, and locate the outlet of the bubble line in the depression, again isolating it from the flow stream velocity.
	In flow streams carrying large amounts of solids, however, this may cause problems because of silt collecting in the depression and restricting the bubble line. A third alternative is to put a 90 degree bend in the end of the bubble line, forming a horizontal leg approximately two inches (5 cm) long, and orienting this hori- zontal leg downstream, parallel with the flow. Tests have shown that this orientation of the bubble line minimizes the effect of flow stream velocity.
3.7.8Stilling Wells	If the installation includes a stilling well in the primary mea- suring device, installing the bubble line in the stilling well is rec- ommended. Attach the line securely to the stilling well, using stainless steel and/or plastic mounting hardware. Not all stilling wells are suitable for bubble line installation. If the well is subject to silting or buildup of foreign material, the bubble line may have to be mounted in the flow stream proper.
3.7.9Flume Bubble Line Fittings	The large variety of primary measuring devices and installations makes comprehensive bubble line installation instructions impractical. However, valid general observations on bubble line installation can be made. Flumes can be specified to include a bubbler fitting. In new construction, this is highly recommended. It may even be possible to modify an existing installation to include a permanent bubbler fitting.
3.7.10 Bubble Line Extensions	Teledyne ISCO offers both stainless steel and copper bubble line extensions. The metal extension may be easier to install in the flow stream than the plastic bubble line because of its rigidity. Two different extensions are available to match the two standard bubble lines.
	The extension for the PTFE bubble line includes a silicone rubber tubing connector, and the tubing installation is as described above. The vinyl bubble line attaches by simply slipping the vinyl tube over the end of the extension.




Figure 3-17 Installing the Stainless Steel Bubble Line Extension

3.7.11Open Channel Installation	If you do not use a stilling well, attach the bubble line to the side of the flow channel or flume. Make the attachment so it causes a minimum amount of disturbance to the flow stream. If possible, cut a groove in the side of the channel, place the bubble line in the groove, and then grout over the groove.
	Alternatively, you can attach the bubble line to the side of the channel, and then grout over the line to form smooth, sloped lead-in and lead-out surfaces. However, if neither of these methods is practical, you may simply attach the bubble line to the side of the channel or the upstream side of a weir using stainless steel and/or plastic mounting hardware.
	In any case, always install the bubble line so it causes as little
	disturbance to the flow stream as possible. This usually means an installation on or adjacent to a channel wall where there is a condition of stagnant flow. For temporary survey applications, you can attach the bubble line with waterproof tape or other tem- porary means.
	Although all other programming steps can be performed off-site,
3.8Setting the Level	the liquid level must be set at the measurement site following in stall ation.
	Once the 330 bubble line is installed in the flow stream, or the 310 sensor is installed over the flow stream, measure the present liquid level and enter this value for Level, under Configure > Adjust Options. Highlight "Adjust" and press Enter to confirm.
	From this screen, you can also update the display to show the current level of the stream.




Figure 3-18Level adjustment

3.9TIENet Sensor Installation in a Hazardous Location In applications where the TIENet sensor will operate within a hazardous area, the installation must be performed by trained and qualified personnel, according to the installation control drawing provided in Figure3-19, and in accordance with local r eq uir eme n ts.

Information about hazloc installation specific to the TIENet 310 Ultrasonic Level Sensor is provided in the sensor's user manual.




Figure 3-19 Hazardous Location Installation Control Drawing-ATEX

Signature[®] Flow Meter

Section 4Portable Installation

This section contains physical preparation procedures and portable mounting methods for the Signature Flow Meter and associated Teledyne ISCO equipment. Section 3 will contain the permanent installation information for the Signature Flow Meter.

The Signature Portable is equipped with one TIENet® receptacle.

In the event a connection must be made directly to the board refer to the permanent Signature installation connection to external devices in Section 3.2.

Where additional TIENet devices are deployed with a Signature

Portable, there is an optional TIENet 'Y' connection cable available to expand the number of connections as needed. See Appendix B for ordering information.

The portable stand allows the user to move the Signature to

various locations and without a permanent installation. This Signature has multiple power options and can be in either in an upward facing or side facing position (Figure 4-1). The Signature Portable is shipped from the factory in a side facing position.

4.2Portable Stand

ISCO Side facing

Figure 4-1 Signature on portable stand side facing (left)

and upward facing (right)

Upward facing







Tools

4.2.1 Adjust Signature to Upward Position

#2 Phillips screw driver

To adjust the Signature to be in the upward facing position:

1.Move the handle into the down position by pulling out the handle latch pins on each side of the stand (Figure 4-2)



Figure 4-2 Pull out the handle latch pins on each side of the stand

2.Loosen all of the screws in the top of the stand (2 panhead and 2 flathead per side) with a #2 Phillips screw driver. (Figure 4-3). These screws are captivated, so loosen until they stop turing.



Figure 4-30ne of the eight screws loosened.

3.Once the four flathead screws are loosened, rotate the meter toward the back and lift straight up to remove it from the stand (Figure 4-4).




Figure 4-4Signature tilted up in preparation of removal

4.Align the notches in the Signature mount with the panhead screws on the stand.

- 5.Engage the slots and push the meter toward the back until it stops.
- 6.Tighten all 8 screws (4 on each side) (Figure 4-5).



Figure 4-5Signature in upward facing position

4.3Power	The Signature Portable is designed to be used with 12 VDC lead acid batteries.
4.3.1Power Connections	The standard battery connection on a Signature Portable accepts Teledyne ISCO model 948 or 946 lead acid batteries. Adapting cables can be purchased to connect to a customer sup- plied deep cycle marine battery.
	MA RNING
	Do not set the portable stand directly on the terminals of a battery. Serious injury or permanent damage may occur.
External Power Connection	The External Power connection is for user supplied DC power. Figure 4-11 (below) shows the connector in the case bottom circuit board P9 Pins 1 and 2 of the "Lead Acid Battery" con- nector are used. Pin 1 is "Ext Pwr" and pin 2 is Ground. A minimum of 18 gauge wire is required. This input is intended for Solar power installations both 12 and 24VDC or 24VDC DIN power. 24V solar power systems can reach 35VDC during the "Rejuvenation" cycle. The recommended voltage input is 10 to 28.5VDC nominal. Above 36VDC the 4 amp fuse will open to protect the circuit. For one time use batteries, this input will function down to 4VDC. User must provide protection against discharging rechargeable batteries too far. Follow the Solar Panel installation guide for proper connections. Ensure that the frame of the solar panel is properly tied to Earth ground so the electrostatic discharge is controlled.




Figure 4-6Connector E diagram

4.3.2Outdoor Recommendations The Signature Portable can be mounted to the portable stand in a side facing or upward facing position (Figure 4-1).

When the Signature Portable is used in an unprotected environment it is recommended the screen is in the side facing position so it does not collect water. **4.3.3 Battery Installation** Common battery options for the Signature Portable:

- 946 lead-acid battery
- 948 lead-acid battery

•Lead-acid battery with solar panel

When using the 948 lead-acid battery the portable stand will sit directly on top of the battery case, where the battery is enclosed. There is a notch in the back of the portable stand that will fit over the power cable from the Signature to the battery. (Figure 4-7).




Figure 4-7Notch in stand for the power cable

948 lead-acid battery

When using the 946 lead-acid battery, this battery will fit directly under the Signature inside of the portable stand (Figure 4-8).





Figure 4-8 946 lead-acid battery installed under the Signature Portable

946 lead acid battery

To install the 946 lead-acid battery:

- 1.Remove the battery hold down of the portable stand by loosening the thumb screw.
- 2.Thread the power cable through to the left side of the portable stand and slide the battery in, between the metal tabs, after it. The battery will fit snugly.
- 3.Replace the battery hold down and tighten the thumb screw.

4.Plug the cable into the Signatures power connector.



Battery hold down

Thumb screw

Figure 4-9Battery hold down and thumb screw

4.4Battery Life Expectancy

This section will cover the average battery life as related to the most common applications. For more information about battery life please consult the factory.

CAUTION

The following section on battery life is for information purposes only and does not constitute a guarantee of service or warranty of any kind.

4.4.1Major Standard **Equipment Settings**

Effecting Battery Life	
Display backlight and power	When the front screen is powered off the Signature is no longer taking near continuous readings. The reading interval will be based on the data storage rate and any actively used equations.
Data storage rate	Many options effect the storage rate as related to battery life, see. See 2.7.5 Data storage for a complete explanation.
Equations	Equations used by alarms, triggers, or secondary measurements can effect the battery life of the equipment. The minimum mea- surement setup in the equation should be the data storage interval used for battery calculations.

For example, the data storage rate is set to 15 minutes, an equation is set with a measurement interval of 5 minutes. For battery life calculations it would be more accurate to use the battery life expectancy of 5 minutes.




Figure 4-10Example of defining conditions and building equations

4.4.2Major Optional Equipment Settings Effecting battery Life	
Cell Modem	The longer the call window is open the more it will drain battery.
LaserFlow	The LaserFlow has additional battery life considerations. Please see the Laser 360 manual for more information
Analog Output Card	The analog output card is not a typical component on a battery operated device. The current draw over time is great and hard to predict.
Ethernet Card	With a very high average current, the ethernet card is not recom- mended for most applications using batteries.
Bu bbler	Bubbler purges draw a large amount of current. Lengthen the Purge Interval for improved battery life.

4.4.3 Additional Considerations for Battery Life	
Bubbler Tubing	The longer the bubbler and sensor line the more current draw the meter will have. In most cases the difference in current draw will not be a factor, but exceptionally long lengths will be a factor.
Reading Retries	If the sensor is in a location where reading errors occur, the unit will attempt to retry until a good reading is taken.
Battery Capacity	If the battery is damaged (decreased battery capacity) the Sig- nature will not run as long as the charts and calculations in this section suggest. Batteries loose capacity: as they age
	•as temperatures decreases
	•when stored

•discharged below default or recommended levels

Table 4-1Battery Life Expectancy (default measurement rate of 15 minutes)				
	Ultra Sonic	LaserFlow	A/V	Bubbler
Average current draw in ma	65	68	68	67
Model 946 lead-acid battery, 12 vCD, 6.5 amp-hours	100 hours	96 hours	96 hours	97 hours
Model 948 lead-acid battery, rechargeable, 12 vCD, 45 amp-hours	692 hours	662 hours	662 hours	672 hours


Table 4-2Battery Life Expectancy (measurement rate of 5 minutes, all other parameters use default)			efault)	
	Ultra Sonic	LaserFlow	A/V	Bubbler
Average current draw in ma	65	70	69	67
Model 946 lead-acid battery, 12 vCD, 6.5 amp-hours	100 hours	93 hours	94 hours	97 hours
Model 948 lead-acid battery, rechargeable, 12 vCD, 45 amp-hours	692 hours	643 hours	652 hours	672 hours

Duration/Setting		
Single point measurement		
enabled (but not active)		
4 hours		
15 minutes (for all flow technologies)		
Key press time-out (30 second timeout enabled)		
Key press time-out (5 minute timeout enabled)		
Open daily for 1hr		
None set		

Table 4-4Additional Aver	age Current Draw
Purge interval 15min (if bubbler is present)	7 48 27 No significant
Backlight always on, display always on	increase 45 No
301 PH sensor (15min data storage interval)	significant increase 10
306 Sampler interface assuming	No significant increase
307 Analog input card (active)	88
307 Analog input card (passive)	
304 Contact Output	
Totalizer 1000 count per hour	
Ethernet communication module	

4.4.4Calculating Average Current Draw

If the conditions listed in the average battery life tables and default method do not match your application, you can use the following procedure to calculate the current draw.



A good quality, adjustable, regulated DC power supply can be substituted for the 12-volt battery. The power supply should have at least 3 Amperes output, preferably more, and capable of overcurrent surges.

Figure 4-11Measuring flow meter current

🗹 Note

Do not attempt this procedure unless you have the proper equipment available and know how to make electrical mea- surements.

Many of the power using functions in the Signature vary over time. To measure current for a varying load requires a moresophisticated type of multimeter, one that is capable of averaging high and low readings over a period of time. The Fluke® 87 Multimeter is one example of this type of meter.

You should set the meter on MIN/MAX and let it run with your program for several hours or more. Other manufacturers' meters are also acceptable, but only if they are capable of averaging current draw. The current test should be run long enough to capture all periodic usage. The longer you run the test, the more accurate the average will be.

To calculate battery life expectancy for an installation, you must know two things:
The capacity of the battery you are using
•The average current draw of the flow meter or (other device) powered
Battery capacity is expressed in ampere-hours. The battery man- ufacturer provides this information for each battery. This value is the product of a load current times an arbitrary time period, twenty hours for lead-acid types. ISCO 946 batteries lead acid bat-teries are rated for 6.5 ampere-hours.
To determine battery life for a Signature running on a 946 lead acid battery, convert the battery capacity into milliam- peres/hours and then divide the ma/hrs by the avg current draw. This will give you a number in hours. Divide that figure by 24, and you will have the number of days.
V Note
The published ampere-hour figures do not mean that you can expect to draw 6.5 amperes from the lead-acid battery for one hou r.
To convert ampere-hours to milliamperes, multiply by 1,000.
6.5 ampere-hours × 1,000 = 6,500 mAh
If you divide this figure by the average current of the flow meter, say 65 mA, you will have:
6,500 ÷ 65 = 100 hours
Divide this number by twenty-four to get days:
100 hours ÷ 24 = 4.1 days
For considerations of safety, we suggest you subtract 10% from
this number (100% – 5% for 95% capacity and 5% for a reserve at the end of discharge).
4.1 – .4 = 3.7 days
The 3.7 days is the battery expectancy for a lead-acid battery with a 65 mA continuous average drain, with a 10% derating factor. Remember if the battery fails there will be a period of time during which no measurements will be taken and no data stored (if you are also using Flowlink® software).

Note

Always operate these batteries with a reserve factor.

4.4.6Low Battery Cut Off and Battery Care

Batteries are considered fully discharged well before the terminal voltage drops to zero volts. Operating lead acid batteries below the fully discharged point decreases their capacity and damages the battery. Lead acid batteries, under a constant rate of discharge, are considered fully discharged at 11.5 volts, however; the Signature does not discharge the batteries at a con- stant rate.

Time durations will allow you to get the maximum amount of life and readings out of the battery without damaging it. It can also prevent a short term power dip from causing a premature shutdown. By default, the Signature will turn itself off when the battery voltage is at 11.5v for 2 min. To prevent the unit from cycling OFF and ON the unit will not recover (turn back ON) until the battery voltage is 13.0 for 2 minutes.

WA RNING

Adjusting the low battery cutoff improperly will damage the batteries. Teledyne ISCO assumes no liability for damage done to Teledyne ISCO or third party vendors batteries. Adjust the low battery cut off at your own risk. User assumes all liability for damage done to batteries by altering the low battery cut off.

Using disposable batteries may allow for greater flexibility and possible usage. The low battery cutoff point can be adjusted by the user. The duration the battery must remain at this voltage for shutdown to occur is fixed at 5 min. If the low battery cut off is altered it must remain at the adjusted level for 5 min before the unit will shut down. Altering the low battery cutoff does not alter the recovery settings. No matter what the low battery cutoff is set to the unit will not recover or turn back on until the battery voltage is at 13.0 for 2min.

4.5Connect to External Devices

Connection to TIENet socket.




Figure 4-12Connector case, connectors, and fuses for Signature Portable Flow Meter

4.5.1Connecting Devices to the TIENet Receptacle

The optional external TIENet devices compatible with the Signature Portable all scan in the hardware in the same manner. Multiple TIENet devices can be connected simultaneously to the same Signature Flow Meter. The following TIENet smart sensors/cables will attach to the TIENet receptacle:

М

Ν

Fuse "T" 4.00A

- •Ultrasonic Level Sensor
- •Area Velocity Sensor
- Bubbler
- pH/Temperature
- LaserFlow
- Sampler

To connect the TIENet plug from the sensor to the TIENet Recep-Connecting a TIENet tacle: receptacle to the Signature Portable 1. Align the connectors and push together (Figure 4-13). 2.After the physical connection is made, a scan must be performed (see section 2.6.1) for the device to be recognized. For additional TIENet connections, use the TIENet Y-cable or alternately an expansion box. O-Ring and Lubrication 1.Coat the O-ring's sealing surface with a silicone lubricant. for the TIENet receptacle Do not use petroleum-based lubricants. Petroleum-based lubricants will cause the O-ring to swell and eventually deterio- rate. Aerosol silicone lubricant sprays often use petro- leum-based propellents. If you are using an aerosol spray, allow a few minutes for the propellent to evaporate

> 2.Align and insert the connector. The sensor release will "click" when the sensor connector is fully seated.

3.Connect the two caps together.

before pro- ceeding.



Figure 4-13How to connect a TIENet receptacle to the Signature Portable

Three-Hole Cord Grip

The following device wires/cables are normally connected thru the 3-hole cord grip:

•Rain Gauge

• SDI-12

Modbus output

The wire/cable diameter can be .200 in to .230 in.

Installing a Cable Through a Three-Hole Cord Grip 1.Remove plug to open hole for an additional cable.

Mote

Gland nut must be loose to remove this plug.



Figure 4-14Removing the plug

Vote

When replacing the plug, the rounded side needs to be pushed into the hole, with the flange facing out (see figure below).



2. Thread the cable through the open hole and various connectors.



3.Connect the three-hole cord grip to the Signature.



4.Attach the three-hole cord grip to the Signature port and attach the wires to the appropriate screw terminals.

Drilling holes in the Signature cases is not recommended and may result in water damage. The material of the Signature case is constructed of Noryl and does not lend itself to post molding alterations.

Connecting the Rain Gauge The following shows how to connect the rain gauge to the Signature Portable and how the cables should look when properly connected (Figure 4-15).

1.Remove the rain gauge cap and connect it to the TIENet receptacle.










Figure 4-15Connecting a rain gauge to the Signature receptacle (L) and then to the Signature connector board (R)

Signature[®] Flow Meter

Section 5Equipment Options

Optional equipment is designed to be user-installable. Internal options, when ordered at time of purchase, are installed in the Signature meter at the factory. This section describes each option and provides instructions for its installation and operation.

All optional cable entries must use appropriate ID conduit connections or cord-grip fittings to retain the IP66 rating. If you are using non-TIENet or non-Signature cables, you must supply the appropriate ID conduit connections or cord-grip fittings.

🗹 Note

Installation and operation of exterior TIENet devices is covered in detail in the user manual for that technology.

Many options require interior access for installation. For connector case interior access and TIENet device wiring instructions, refer to *Connecting External Devices*, on page 3-1 and *Connecting TIENet Devices*, on page 3-7.

DANGER

Before opening the case, first ensure that mains power is disconnected from the unit and any battery power is disconnected.

Part numbers for ordering accessories are provided in Appendix B *Options and Accessories*. Optional equipment from Teledyne ISCO includes:

AC Power Cord Kit /AC Wiring (Applies to Permanent Installation Only), on page 5-2

Battery Backup (Applies to Permanent Installation Only), on page 5-4

Sampler Interface, on page 5-15

pH and Temperature Device, on page 5-15

Mechanical Totalizer, on page 5-8 External	Sampler Interface, on page 5-15
Desiccator, on page 5-12 Ultrasonic Level	TIENet Expansion Box, on page 5-15
<i>Sensor</i> , on page 5-13	Reference Port Tubing Kit, on page 5-29
Bubbler Level Sensor, on page 5-14 and	Ethernet Modem, on page 5-31
6-19	Cellular Modems, on page 5-36
Contact Output Card (TIENet 304), on page 5-	Laser Doppler Velocity Sensor, on page 5-14
16	Continuous Wave Doppler Velocity Sensor, on page 5-14
Analog Input Card (TIENet 307), on page 5-21	
Analog Output Card (TIENet 308), on page 5-25	
<i>pH and Temperature Device</i> , on page 5-15	

5.1AC Power Cord Kit /AC Wiring (Applies to Permanent Installation Only)

C The AC power cord kit includes a line cord with a strain relief cord-grip fitting. If ordered with the Signature Flow Meter, it will be shipped from the factory already installed.

Instructions for user installation are provided in this section. Note that these instructions can also be used as guidance for user-supplied or replacement line cord, hard wiring, or replacement power supply.

Open the flow meter housing, following all warnings and instruc-

tions provided in Connecting External Devices, on page 3-1.

1. If a cord-grin fitting is already installed, loosen the sealing nut on the AC line cord. If conduit is installed, remove the sealing material around the AC line cord where it enters the housing. This is to free the cabling for movement or removal.



Figure 5-1AC Line cord with a cord-grip fitting

2.Remove the mounting screw and lift the power supply out of its molded niche, taking care not to strain the wires going to the board.




Figure 5-2Power supply mounting screw




Figure 5-3Power supply removal/replacement

- 3.Remove the clear plastic shield protecting the power supply terminals (Figure5-4). Note that the Signature ground wire ends in a ring terminal so the line cord ground wire can easily be connected to the same terminal.
- 4.*If replacing the power supply*, label all wires according to their terminal connections (i.e., **L**, **N/L**, **Gnd**, **-V**, **+V**), and disconnect them.



Figure 5-4Power supply terminal strip: AC Input and DC Output

5. If installing a cord-grip fitting (refer to Figure 5-1):

a.Remove the lock nut from the cable nut.

- b.Install the cable nut through the line cord cable entry (closest to power supply location) in the bottom of the connector case and secure it to the Signature case wall with the lock nut.
- c.Feed the line cord end through the sealing nut and then through the cable nut, into the case.
- d.Lightly tighten the sealing nut, just enough to hold the line cord in place while connecting it to the power supply.
- 6.Connect the line cord wires to the power supply, as shown in Figure 5-4, and then reinstall the plastic protective shield.

🗹 Note

Double-check to ensure that the terminals labeled **Gnd**, -V, and +V on the Signature circuit board are wired to their corre-sponding terminals on the power supply.

7.Reinstall the plastic shield over the wiring connections.

8.When seating the power supply into its niche, guide the attached wires around in front of the mounting standoff and through the molded slot, so they are not strained or damaged (see Figure 5-3).

9.*If using a line cord*, gently tug the line cord to remove any slack within the enclosure, taking care not to stress the connection, and tighten the cord grip sealing nut.

If you are using conduit instead of the cord-grip fitting, the conduit and wires in the conduit **must be sealed** to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life.

10.Close the front panel and fasten it shut with the two Phillips screws.

The battery backup option consists of a Teledyne ISCO Model

946 lead-acid battery pack and extension cable, with special hardware to mount it on the top of the Signature Flow Meter, or on a wall. The unterminated power cable normally enters the connector case through the second port from the right.

🟹 Note

An optional external power loss alarm is available. See Section 5.3 *Power Loss Alarm*.

5.2Battery Backup (Applies to Permanent Installation Only)

DANGER

Before opening the case, first ensure that mains power is disconnected from the unit.

Before opening the case, disconnect the optional battery backup power, if used.

Do not substitute another battery type for this option. Use only the Model 946 Lead-Acid battery.



Figure 5-5Battery backup kit contents

If you are using conduit instead of the cord-grip fitting, the conduit and wires must be sealed to prevent harmful gases and moisture from entering the Signature enclosure. Failure to seal conduit could reduce equipment life.

Installation

1.Remove line power from the Signature Flow Meter and open the case as previously described in Section3.2.

Do not connect the extension cable to the battery cable until all other steps are completed.

2.At the LEAD-ACID BATTERY terminal strip, connect the extension cable's black wire to the +12 terminal, and the white wire to the ground terminal.




Figure 5-6Attach extension cable to the connector case

3. Install the mounting plate, either on top of the flow meter case using the Torx screws provided, or on the wall nearby.




Figure 5-7Installing the battery backup mounting plate

4.Place the 946 battery on the mounting plate and secure it in place using the two black rubber draw catches.5.Connect the battery cable to the extension cable.



Figure 5-8Backup battery, installed

	Be sure to unplug the battery when intentionally disconnecting from AC power.
5.3Power Loss Alarm	The Signature Flow Meter offers different options to notify you of line power loss.
Contact Output Card (TIENet 304)	The Contact Output Card is an optional card that closes or opens relays at specific thresholds set within the Signature Flow Meter programming. For power loss indication, it is recommended to configure the Signature to activate the contact output to CLOSE when the 300 Sense Voltage drops below 12 VDC. The output relay will deactivate when the 300 Sense Voltage drops below 12 VDC or if the power drops all together.
Analog Output Card (TIENet 308)	The Analog Output Card provides an analog output signal pro- portional to a configured measurement input. For power loss indication, it is recommended to configure the Signature so the analog output is proportional to the 300 Sense Voltage. The external device monitoring the analog output should alarm when the analog signal drops below the equivalent of 12 VDC reported by 300 Sense Voltage.
12 Volt DC Output	The Signature system operates on 12 VDC. A voltage level of 12 VDC at the POWER 12.8V terminal (Figure 5-6) will indicate adequate power supplied to the Signature meter, whereas a voltage level of less than 12 VDC will indicate a power loss.

5.4Mechanical Totalizer	The mechanical totalizer is a seven-digit, non-resettable mechanical counter installed in the front panel. It increments according to programmed totalizer resolution and units of measure. The totalizer can be viewed once the metal shield or bubbler module is removed.
	The volume represented by the mechanical totalizer is always the primary Total Flow programmed in Measurement Setup > Volume Input Setup (refer to <i>Configure Options</i> , on page 2-20).
	The mechanical totalizer increments with the third significant digit of the selected resolution (see Figure2-15 <i>Menu Tree: Volume Input Setup (total flow)</i>), e.g.:
	Resolution 999999999 = Increment every 100 units;
	Resolution 99999999.9 = Increment every 10 units;
	Resolution 9999999999 = Increment every 1 unit, etc.
	The Signature permits a maximum 300 counts per minute; if totalized flow exceeds this rate, remaining volume will be buffered until it can be counted, although buffering over extended time periods is not recommended.
Installation	1.Remove line power from the Signature Flow Meter and open the case as previously described in Section3.2.
	Remove the four mounting screws holding the metal shield in place and set it aside.
	3. To ensure that the bubble line tubing is reconnected cor-
	rectly, label the tubing ends as shown below in Figure5-9, then remove the four mounting screws holding the 330 bubbler in place and set it aside.




Figure 5-9Disconnect and remove bubbler module

4.Using a razor blade or utility knife, carefully cut the six tabs in the control panel label to detach the totalizer window cover.

Note

Be sure to cut all six tabs. Pulling on the cover with some of the tabs still attached will damage the control panel label.




Figure 5-10Remove totalizer window cover

Referring to Figure 5-11:

- 5.Remove the two screws above the totalizer cutout provided in the Main CBA. These screws will be used for mounting the totalizer.
- 6.Install the totalizer in the cutout, attaching the two mounting tabs with the two screws, so that the numbers appear in the window.
 - View the totalizer through the window and adjust the position, if necessary, before tightening the screws.
- 7.Plug the totalizer connector into **P10** on the Main CBA. This two pin connector is keyed to prevent incorrect attachment.



Figure 5-11 Optional non-resettable totalizer installation

5.5External Desiccator

For Signature systems using the 330 or 360 Bubbler Module and/or the TIENet 350 Area Velocity Sensor, the desiccator vents the reference port for a pressure transducer, and the air intake port for the bubbler system air pump, keeping the interior of the flow meter case dry, as well as the sensor reference line.

Note

The desiccant is standard on the portable version of the 330, 350, and 360 Bubbler module. It is not standard on the non-portable 310 Bubbler module.




Figure 5-12 External desiccator, installed

Remove the two red protective end caps from the ports before installing a new cartridge.




Figure 5-13 Remove red caps before installing external desiccant cartridge

The desiccant cartridge is held in place by a spring tab on the side of the flow meter. Press against the front of the cartridge to disengage it from the unit.





Figure 5-14 Removing the external desiccant cartridge

The desiccant cartridge requires periodic maintenance. Refer to Section 6.5.2 *External Desiccator* for instructions.

5.6TIENet® Devices

Teledyne Isco's proprietary TIENet connectivity allows for the combination of multiple flow measurement technologies and other devices with the Signature flow meter.

5.6.1Ultrasonic Level Sensor



The TIENet 310 Ultrasonic Level Sensor mounts directly over the flow stream. The sensor measures level by transmitting an ultrasonic pulse toward the liquid surface and then measuring the time it takes for the echo to return. The 310 is normally used with some type of primary device (typically a weir or flume) to measure flow in an open channel.

The 310 Sensor is ATEX-approved for use in potentially explosive atmospheres when specific conditions are met. Refer to the 310 user manual, as well as the control installation drawing in Section 3.9.

For complete installation and operation procedures, refer to the TIENet 310 sensor's user manual.


5.6.2 Bubbler Level Sensor



5.6.3Laser Doppler Velocity Sensor



5.6.4Continuous Wave Doppler Velocity Sensor



The factory-installed TIENet 330 Bubbler is normally used with some type of primary device (typically a weir or flume) to measure flow in an open channel.

The amount of pressure required to force bubbles from the end of

a submerged bubble line is directly dependent on the hydrostatic pressure of the flow stream over the end of the bubble line. A pressure transducer inside the module senses this pressure and converts it into a level signal that the flow meter uses to calculate flow rate and total flow.

In order to operate with the 330 Bubbler, the Signature must

have an external desiccator installed. For installation of the external desiccator, refer to Section5.5.

Because the 330 Bubbler is a standard component in bubbler Signature meters, installation instructions are located in Section6 *Maintenance and Servicing*, under *330 Bubbler Installation*.

The TIENet 360 LaserFlow[™] velocity sensor remotely measures

flow in open channels with non-contact Laser Doppler Velocity technology and non-contact Ultrasonic Level technology. The sensor uses advanced technology to measure velocity with a laser beam at single or multiple points below the surface of the wastewater stream.

To operate with the LaserFlow, the Signature requires firmware

version **1.18** or later. Firmware update instructions are provided in Section6.3 *Firmware Updates*.

For complete installation and operation procedures, refer to the LaserFlow sensor's user manual.

The TIENet 350 Area Velocity Sensor measures flow stream average area velocity and liquid level. The Signature uses this information to calculate the flow rate and total flow of the stream. To operate with the 350 sensor, the Signature requires firmware version **1.18** or later. Firmware update instructions are provided in Section6.3 *Firmware Updates*.

The sensor is mounted in the flow stream, normally at the bottom of the channel. It measures average velocity using continuous ultrasonic sound waves to produce a Doppler effect. The sensor measures liquid level using an internal differential pressure transducer.

In order to operate with the 350 AV sensor, the Signature must have an external desiccator installed (see Section5.5 *External Desiccator*). Signature bubbler systems will already have a desiccator installed. If you are adding a 350 AV sensor to a nonbubbler system, you will also need to add an external desiccator.

For complete sensor installation and operation procedures, refer to the TIENet 350 sensor's user manual.

5.6.5Sampler Interface



5.6.7TIENet Expansion Box

The TIENet 306 Sampler Interface connects the Signature Flow Meter to a Teledyne ISCO wastewater sampler. Through this connection, the Signature can enable the sampler based on user-specified conditions, pace the sampling routine based on flow volume, and receive sample and bottle information from the sampler.

For complete installation and operation procedures, refer to the TIENet306device'susermanual.

5.6.6pH and Temperature DeviceThe TIENet 301 pH sensor measures the acidity or alkalinity of an aqueous solution by determining the relative quantity of dissociated hydrogen ions in the solution. The normal scale for pH runs from 0 to 14, with 0 being most acidic and 14 being the most alkaline.

For complete installation and operation procedures, refer to the TIENet301device'susermanual. The water-tight expansion box connects to a TIENet terminal strip like other TIENet devices, and contains three additional strips inside, for connecting more devices. The expansion box can be daisy-chained with each box providing two additional cord grip ports. Additionally, the expansion box contains a TIENet connection for an option card (such as the 308 Analog Output option, Section5.6.9). If an option card is used in an expansion box there is room for just one TIENet cable cord grip exiting the box.

Note


For applications requiring reference air moisture protection, please contact the factory.

🗹 Note

The expansion box is not rated for use in hazardous locations.

Enclosure Rating: IP67 (NEMA4X, 6)

All optional cable entries must use appropriate ID conduit connections or cord-grip fittings to retain the IP67 rating. If you are using non-TIENet or non-Signature cables you must supply the appropriate ID conduit connections or cod-grip fittings.







(Cord-grip fittings are ordered separately)

Figure 5-15TIENet Expansion Box

5.6.8Contact Output Card The contact output card provides a contact closure that can be enabled based off of conditions set in the equation builder.

The Signature accepts up to three internal, user-installed TIENet option cards. The 304 contact output card provides two contact outputs per card for connection between the Signature meter and non-ISCO process control equipment that requires a contact output.



	Use proper static dissipation when handling circuit boards.
	Programming menus and data display distinguish each output by serial number and channel number.
Tools required	T-15 Torx driver
	To install a card:
	1.Remove power from the Signature flow meter and open the case, as previously described in <i>Connecting External Devices</i> , on page 3-1.
	2.The option card includes a mounting screw. Remove the tubing retainer from the screw.
	3.Remove the 3-pin header clip from its socket on the board.
	4.Connect the receiving wires to the terminals according to their labeling (positive and ground).
	Note that Contact1 and Contact2 are identified on the back of the board.




Figure 5-16304 contact output card front and back view

Note


• Normally Open (NO): When the condition is met, the circuit will be open.

• Common (C): There is always be a connection to the common.

• Normally Closed (NC): When the condition is met, the circuit will be open.

5.Gently press the card down so that the 4-pin connector **P4** plugs into one of the three analog output jacks on the board (Item 'J' in Figure 3-2).

6.Secure the card in place by tightening its mounting screw with the T-15 Torx driver. Do not overtighten.



Two cards are shown here. The Signature accepts up to three cards at once, for a possible six simultaneous input/output channels.

Figure 5-17 View of two cards installed

7.Feed the clip with receiving wires through the appropriate port on the bottom of the meter, and press the clip down into its socket on top of the card.

Note

Cabling is user-supplied. Shielded cable is recommended. For cord-grip fitting options, refer to AppendixB, SectionB.3. If conduit is used, the conduit and wiring must be sealed to prevent entry of harmful gases and/or moisture.

Configuration

The 304 measurement configuration screen includes the 304 digital output option.




Figure 5-18 304 contact output device configuration





Figure 5-19 304 contact output setup

5.6.9Analog Input Card (TIENet 307)	The 307 analog input card allows the Signature to record an analog signal as a number of data types from several different units.		
	The Signature accepts up to three internal, user-installed TIENet 307 option cards. The 307 analog input card provides two 4-20mA inputs a piece for connection between the Signature meter and non-ISCO process control equipment or other equipment that outputs a 4-20mA current signal.		
	Use proper static dissipation when handling circuit boards.		
	Programming menus and data display distinguish each output by serial number and channel number.		
Tools required	T-15 Torx driver		
	To install a card:		
	1.Remove power from the Signature flow meter and open the case, as previously described in <i>Connecting External Devices</i> , on page 3-1. If the LED is green, a current is flow-ing.		
	2.The option card includes a mounting screw. Remove the tubing retainer from the screw.		
	3.Remove the 3-pin header clip from its socket on the board.		
	4.Connect the receiving wires to the terminals according to their labeling (positive and ground).		
	Note that Channel1 and Channel2 are identified on the		



back of the board.

Channel 2





Back of board

Figure 5-20307 analog input channel identification and terminal connections

CHANN

5.Gently press the card down so that the 4-pin connector **P4** plugs into one of the three analog output jacks on the board (Item 'J' in Figure 3-2).

- 6.Secure the card in place by tightening its mounting screw with the T-15 Torx driver. Do not overtighten.
- 7.Feed the clip with receiving wires through the appropriate port on the bottom of the meter, and press the clip down into its socket on top of the card.

🗹 Note


Cabling is user-supplied. Shielded cable is recommended. For cord-grip fitting options, refer to AppendixB, SectionB.3. If conduit is used, the conduit and wiring must be sealed to prevent entry of harmful gases and/or moisture.

The orientation of the wires is dependent on the setting of the channel. If the channel is set to active, the positive wire is connected to the out arrow. The connection will be reversed for the passive mode.

Table 5-1Direction of arrows and mode types			
Out (arrow pointin away from th b oard)		In (arrow is pointing toward the board)	
Switch is in the active mode (A)	Posit ive	Negative	
Switch is in the passive mode (P)	Negative	Positive	



Active Mode



Passive Mode

NOTE: Active mode supplies power to the loop. Passive relies on another device powering the loop.

Figure 5-21Direction of switch in active and passive modes

Channels





Figure 5-22 307 analog input device configuration



parameters.

are % only.

Figure 5-23 307 analog input setup

5.6.10Analog Output Card (TIENet 308)	The 308 analog output cards convert digital information from the flowmeter to a variable analog output current ranging from 4 to 20 milliamperes. When a parameter measured by the flow meter is converted into an analog output, 4 mA becomes the 0%, or baseline, for the parameter, while 20 mA becomes the 100%, or full-scale, of the parameter. For basic programming steps, refer to Figures 5-18 and 5-19.
	The Signature accepts up to three internal, user-installed TIENet option cards. The 308 analog output card provides two scalable 4-20mA outputs per card for connection between the Signature meter and non-ISCO process control equipment or other equipment that accepts a 4-20mA current signal.
	Use proper static dissipation when handling circuit boards.
	Programming menus and data display distinguish each output by serial number and channel number.
Tools required	T-15 Torx driver
	To install a card:
	1.Remove power from the Signature flow meter and open the case, as previously described in <i>Connecting External Devices</i> , on page 3-1.
	2.The option card includes a mounting screw. Remove the tubing retainer from the screw.
	3.Remove the 3-pin header clip from its socket on the board.
	4.Connect the receiving wires to the terminals according to their labeling (positive and ground) (Figure 5-24).
	V Note
	Channel 1 and Channel 2 are identified on the back of the boa rd .

Note

If your analog signal line has a drain DO NOT connect that to the ground connection of the 308 Analog Output card (Figure 5-24). It can become a source to inject noise into the circuit.

5-25




Figure 5-24DO NOT connect to the ground connection




Figure 5-25308 analog output channel identification and terminal connections

5.Gently press the card down so that the 4-pin connector **P4** plugs into one of the three analog output jacks on the board (Item 'J' in Figure 3-2).

- 6.Secure the card in place by tightening its mounting screw with the T-15 Torx driver. Do not overtighten.
- 7.Feed the clip with receiving wires through the appropriate port on the bottom of the meter, and press the clip down into its socket on top of the card.

Note

Cabling is user-supplied. Shielded cable is recommended. For cord-grip fitting options, refer to AppendixB, SectionB.3. If conduit is used, the conduit and wiring must be sealed to prevent entry of harmful gases and/or moisture.




Figure 5-26 308 analog output device configuration




Figure 5-27 308 analog output setup

5.7Reference Port Tubing Kit

For Signature Bubbler monitoring sites where the flow meter mounting location does not provide adequate reference to atmo- spheric pressure at the measuring point, the reference port tubing kit includes tubing and adaptors to relocate the reference port.

An extra kit can also be used for the bubbler intake, if the air at the flow meter mounting location is excessively humid.

The 25-foot, vinyl 1/4" ID, 3/8" OD tubing should be cut to the shortest length practical for your installation.



Figure 5-28 Reference port kit (full length not shown)

Installation

The tubing attaches to the reference port of the external desiccator. If using two kits, the second tube attaches in the same manner to the intake port of the external desiccator.

To install:

1.Unscrew the hydrophobic filter cap from the reference chamber (smaller chamber) of the external desiccator.



Figure 5-29 Reference port kit: Remove filter and barb

- 2.Screw the hydrophobic filter into the end of the reference port tubing connector.
- 3.Screw the hose barb fitting with o-ring into the reference port of the desiccator.



Figure 5-30 Reference port kit: Install filter and barb

4.Push the open end of the tubing down over the hose barb fitting.



Figure 5-31 Reference port kit: Installed on flow meter

5.8 ISCO Flowlink Software Flowlink® is Teledyne Isco's proprietary software system for



data acquisition, storage, retrieval, and analysis. Using the interface of Microsoft Windows, Flowlink can be used to remotely program the Signature Flow Meter, retrieve data from the flow monitoring system, present site data graphically, and generate statistical information from the site data.

Flowlink helps ensure data integrity by displaying the Signature's tracked configuration changes, data measurement summaries, diagnostic test results, and user events in the program. With these tools, Flowlink provides assurance that the data has not been altered.

USB drivers for computer direct connection to the Signature Flow Meter are included on the Flowlink CD, and must be loaded prior to direct connection between the computer and the Signature.

See Section*Connecting to the Signature with Flowlink*, on page 2-2 for instructions on how to connect to the Signature meter with Flowlink software.

From Flowlink, the event data can be exported and saved in the form of text reports on your computer, searchable by site name, module, and date. For complete information, refer to SectionSignature Data in Flowlink, on page 2-35.

Setup and data retrieval, as well as alarm output configuration,

can be accomplished remotely via TCP/IP communication protocol with a static address, using Flowlink software and the ethernet modem to access the Signature's web browser. The ethernet modem is factory-installed on the connector case.

The ethernet modem can also be installed by the user. Remove line and/or optional battery power from the Signature Flow Meter and open the case as previously described in Section3.2.

Always use proper static dissipation methods when handling circuit boards.

Before opening the case, first ensure that mains power is disconnected from the unit.



Before opening the case, disconnect the optional battery backup power, if used.

5.9Ethernet Modem





Figure 5-32 Ethernet modem kit contents

1.Press the modem assembly down into its socket on the connector case (item G in Figure3-2 *Connector case, connectors, and fuses*), with the row of dots along the bottom left and right edges aligned with the row of circles on the board to ensure proper orientation.

- 2. Place the plastic spacer over the screw hole by the bottom right corner of the modem.
- 3.Place the lock washer on top of the spac er .



4. Place the rectangular retainer over the lockwasher, with the countersink facing up, and attach with the screw.

Figure 5-33 Ethernet modem installation

In order to communicate with the Signature Flow Meter using the ethernet modem, your network must have TCP/IP services installed. A static IP address must be reserved for the Signature, and client network computers must be allowed to access the static IP address.

5.9.1Ethernet Modem Configuration

When installation is complete and power restored, wait one minute for the Signature to recognize the modem before pro- gr ammin g.

Note

The Signature does not support Dynamic Host Configuration Protocol (DHCP). The network communication information (IP, gateway, and subnet mask) must come from your network administrator and be entered manually into the flow meter.

When you select Modem Setup from the Hardware Setup menu, the type of modem installed determines what screen is displayed.

To configure the Signature for ethernet communication, you must have the following information on hand prior to

Hardware Setup:

IP Address-An Internet Protocol (IP) address is the unique numerical label assigned to each device (e.g., computer, printer, flow meter, etc.) on a computer network for interface identification and location addressing. The Signature's Ethernet modem requires a *Static* IP address for remote communication. **TCP**

Port-The default port setting is

1700. This is the communication port associated with the static IP address on your network. **Gateway Address-**The

gateway is the

point of communication that joins two different networks with different base IPs.

Subnet Mask-This is the umbrella

location that allows multiple nodes to communicate within the network.

It designates a subnetwork within the larger network. Traffic between subnetworks is exchanged or routed through the Gateway.

Special network access may be required to

configure these settings. For further assistance, contact your network administrator.




Figure 5-34 Ethernet modem setup: Communication settings (default settings shown)

5.9.2Network Firewall Settings

In order for your network administrator to identify the Signature in the network firewall setup, it must have a node ID (also known as the MAC address). This is the NODE ID printed on the ethernet modem's serial tag (refer to Figure 5-35).



Figure 5-35 Locating the NODE ID (MAC address) on the ethernet modem

5.10Cellular Modems

Setup and data retrieval through the Signature's web browser, as well as alarm outputs, can be accomplished remotely with one of the available cellular modems. The whip-style antenna has a magnetic mounting base.



Figure 5-36 LTE antenna-

5.10.1GSM Modem

The Global System Mobile (GSM) modem can automatically push data to a secure server running ISCO Flowlink Pro software, with HSPA+ data transmission.

Your service parameters, or provider, can be changed by replacing the removable Subscriber Information Module (SIM) card in your modem.



The modems shown do not necessary represent the modems installed.



Figure 5-37 GSM Cellular modem-

5.10.2LTE Modem

The Long Term Evolution (LTE) modems can automatically push data to a secure server running ISCO Flowlink Pro software, with LTE data transmission your service parameters or provider, can be changed by replacing the removable Subscriber Information Module (SIM) card in your modem. There is one modem for North America and one for Europe.



Figure 5-38LTE Cellular modem

5.10.3SIM Card

The data transmission capabilities of the GSM and LTE modems are dependant upon the type of service plan you have through your cell phone service provider. The service parameters, or provider, can be changed by simply replacing the SIM card in your modem. Check with your service provider to verify what data transmission technologies are available for your use. There are three types of SIM cards, but only Micro SIM cards will work in the GSM and LTE modems.

Note

A Micro SIM card is required for any GSM or LTE units including the Signature modems.




Figure 5-39Types of SIM cards

5.10.4 Installing the Cellular Modem

The modem kit includes the modem, power cable, DB9 serial cable, coaxial antenna plug cable and antenna.

Note

Before installing the modem, remove the top label (with the FCC ID and IMEI number on it) taped to the modem and adhere it to the outside of the Signature case on the bottom of the unit, on the left side, in the largest of the three sections (Figure 5-40). This is required by the FCC and ensures the IMEI number is visible.




Figure 5-40FCC ID label on modem and location of label on the bottom of Signature case

1.Remove line power from the Signature Flow Meter and open the case as previously described in Section3.2.




Figure 5-41 Cellular modem kit contents

- 2.Install the plug in the preferred port (far left most commonly used). Route the antenna plug cable under any other cabling, and install the plug in any open port.
- 3.Connect the three cables to the modem.
- 4.Remove the screw retainers and fasten the modem's mounting bracket against the connector case, as shown below, using the two mounting screws.
- 5.Plug the serial and power cables into their respective connectors on the board.

6.Place the diversity antenna in the location shown below by peeling the adhesive backing off the hook and loop fastener and sticking it to the top of the Signature case.



7. Plug the antenna into the antenna plug.




Figure 5-42 Cellular modem installation

5.10.5Cellular Modem Configuration	When installation is complete and power restored, wait one minute for the Signature to recognize the modem before pro- gr ammin g.When you select Modem Setup from the Hardware Setup menu, the type of modem installed determines what screen is displayed. To set up the Signature Flow Meter for cellular communication, select Verizon for VERIZON service or OTHER for AT&T, Bell,
	Telus or Roger.
	Steps to Change Modem Provider:
	1.Turn OFF data push
	2.Set call window equation to NONE.
	3.Power cycle the meter.
	4.When the Modem is detected after the power cycle, type in the new provider APN.
	5.Change provider in drop-down menu of Modem set up. (Verizon or Other)
	6.Select NEXT.
	7.It will take 30 seconds or so for the modem to recognize the change.
	8.Navigate back to the Modem Set-up screen and make sure the change has been made.
	9.Steps 6 - 8 may need to be repeated until the selected pro- vider remains in the pop-up window.
	10.Power down the meter and insert the new SIM card.
	11.Re-configure any call window or data push activity.
	For the LTE or GSM modem, an Access Point Name (APN) must
	be used. Enter the APN in the appropriate field.
	For portable applications the modem can be set up with the call
	in the time window. To conserve power, the time window does not effect the push/outgoing connections. The time window restricts when the meter can be accessed via a modem connection.




Figure 5-43Cellular modem setup: Communication settings


5.10.6Antenna Placement

1.Antenna needs to be placed in Vertical orientation. *It does* NOT *radiate out of the ends of the antenna.*



2.The best performance will be with the antenna placed on a large metal ground plane, above ground and without large obstructions between the antenna and the tower. This is not always possible but in instances where signal strength is low, this may be necessary.

3.Any metal surrounding the antenna will degrade performance! Placing the antenna 4-8" lower than the metal ring the manhole cover sits on will provide better signal quality. Dirt and concrete lower signal strength less than metals which cause the signal to attenuate.



- 4.Do NOT kink the coax! *The coaxial cable that* feeds the antenna should never be in a loop tighter that the size of a fist. A coax that has been kinked will degrade the signal even after being straightened back out.
- 5.Antennas near strong radio towers or other sources of RF interference can jam the signal even though it is on a different frequency.

5.10.7Modem Frequency Ban ds The following frequency chart shows the frequency bands of each Teledyne ISCO modem. The user must ensure that the frequency band of the service plan matches the frequency band of the modem being used.

ISCO Part Number	Туре	4G LTE Bands	Fallback	Applicable Networks	Location
604307101	GSM	B1, B2, B4, B5, B8	2G: GSM 900, DCS 1800	Many	Global
604307105	Cat 4	LTE-FDD: B2, B4, B5, B12, B13 B14, B66, B71	3G HSPA+: B2, B4, B5	AT&T, Verizon, Bell, Telus and Bogers	North America
604307106	Cat 4	LTE-FDD: B1, B3, B7, B8, B20	3G: B1, B8 2G: GSM 900, DCS 1800	Orange, Telstra, Telus, Vodafone and More	Europe

Signature® Flow Meter

Section 6Maintenance and Servicing

6.1 Maintenance

The following tables are recommended maintenance checks to ensure proper operation. As site conditions may vary, increase the frequency of inspections as needed.

Table 6-1Recommended Maintenance (Accessible Locations)			
Action	ency	Fre qu Location	
Check desiccant for appropriate colora	Monthly or followin humidity error	g On site	
	Monthly		
Check bubble line for plugs or obstructions	Monthly	On-site	
Check bubble line for kinks	Monthly	On-site	
Check pump run time during manual purgeb	Weekly	On-site	
Check for level measurement errors		Via Flowlink application	

a. When dry, the desiccant appears orange in color.

b. If the run time is >15 seconds, replace the intake gore filter.

Table 6-2Recommended Maintenance (Difficult-to-Access Locations)			
Action Check desiccant for appropriate colora	Recommended Fre qu ency Every 6 months or	Location	
	following humidity error Every 6 months	On-site	
Check bubble line for plugs or obstructions	Every 6 months	On-site On-site On-site	
Check bubble line for kinks	Every 6 months	Via Flowlink application	
Check pump run time during manual purgeb	Weekly		
Check for level measurement errors			

a. When dry, the desiccant appears orange in color.I

b. If the run time is >15 seconds, replace the intake gore filter.

6.2 Cleaning

6.3Firmware Updates

The Signature flow meter may be cleaned with water and a mild detergent. For hard to remove stains, isopropyl alcohol may be used. If the instrument is in an isolated area and the case is sealed closed, it may be cleaned using a water hose.

Signature and TIENet device firmware updates are provided in

the form of .bin files, which will be available for download from the Teledyne ISCO website. Note that firmware updates do not remove any program settings or delete data.

To install an update:

- 1.Create a folder in the top directory of a flash drive, and name it BINFILE.
- 2.Download the .bin file to be installed. To find your correct .bin file, go to www.isco.com and click on *Software/Firm-ware Updates* in the lower left corner. Select *Open Channel Flow Measurement*.



Figure 6-1Locating firmware updates

3.Save the new .bin file(s) to the BINFILE folder you created on the flash drive.

4.Using the flash drive adaptor cable provided with the Signature, connect the flash drive to the micro-USB assembly on the flow meter's front panel.



Figure 6-2USB Micro adaptor cable (flash drive not included)

- 5.The USB Options menu appears on the display. Select option #3, Update Firmware.
- 6.You will be prompted to select either Signature or TIENet firmware. Select the appropriate .bin file from the pull down menu and press NEXT.

a. Update Signature Firmware

The update will load for approximately three minutes. During this time, do not make any changes to the Signature. When the firmware load is complete, the Signature will prompt you to remove the USB drive. An automatic reboot then occurs over a period of approximately five minutes, during which the green LED signals that an internal operation is in progress. Do not unplug the flow meter or press any keys until the Home screen appears. In the event that the upload fails, contact Teledyne ISCO

b.Update TIENet (Smart Sensor) Firmware

Select the radio button next to each device to be updated and press NEXT. The progress of the sensor firmware update(s) will be displayed. A confirmation screen will appear when the update is complete.

c. Bootcode

This option is only used when the update(s) failed and the sensor is no longer responding. Select the "Bootcode" option, then select the appropriate file from the drop-down menu to be updated. All other updates are inactive when this option is selected.

6.4Accessing the Interior

Some maintenance or servicing tasks require opening the Signature housing to access the interior. Always refer to this section prior to doing so.

DANGER

Before opening the case, first ensure that mains power is disconnected from the unit.

CAUTION

Before opening the case, disconnect the optional battery backup power, if used (refer to Figure 5-8 **Backup** battery, installed).

Note

Before restoring mains power, ensure that the flow meter's USB connector does not have a cable attached.

Open the door to access the two large screws holding the front panel on the connector case. Remove the two screws, then reinsert them in the front panel and latch the lid so they will not be misplaced.




Figure 6-30pen door and front panel to access interior

6.5 Desiccant	The inside of the flow meter housing must be kept dry at all times to prevent moisture damage to the internal components. All Signature flow meters have an internal desiccant bag to absorb moisture. Signature flow meters using a 330 bubbler also require an external desiccator.
	If increased humidity is indicated by either the humidity reading of the flow meter or the color of the external desiccant, the des- iccant must be renewed or replaced before damage occurs.
	If this occurs more frequently than expected, inspect the seals of cord-grip fittings and conduit, if used.
Humidity alarm	The humidity of the case interior, reference (ambient) air, and bubble intake air (if a 330 bubbler is installed) are all param- eters that can be selected as conditions to trigger an alarm, noti- fying you when it is time to renew or replace your desiccant.
	The suggested alarm setting is a threshold condition of 40%. For detailed instructions about setting up conditions and alarms, refer to Sections <i>Equation/Trigger Setup</i> , on page 2-25, and <i>Inputs/Outputs/Alarms Setup</i> , on page 2-27.
6.5.1Internal Desiccator	Saturated internal desiccant bags must be replaced; unlike the external desiccant, they are not renewable.
	The desiccant bag is held in place by a metal bracket. Remove
	the two screws holding the bracket.



Figure 6-4Removing the internal desiccant bag

6.5.2External Desiccator

The desiccator vents the reference port for a pressure transducer, and the air intake port for the bubbler system air pump, keeping the interior of the flow meter case dry.




Figure 6-5External desiccator, installed

When dry, the loose silica gel desiccant inside the chambers is orange or yellow. When the desiccant becomes saturated with moisture, it turns green or blue, indicating that the intake air and reference line are no longer protected from humidity.




Figure 6-6Desiccant indicating saturation

The desiccant cartridge is held in place by a spring tab on the side of the flow meter. Press against the front of the cartridge to disengage it from the unit.




Figure 6-7Removing the external desiccant cartridge

Unscrew the two black caps and carefully pour the desiccant out.

If removal is difficult, screw the caps back in and unscrew again.

Gently knock the caps and the cartridge against a hard surface to free any small particles in the threads, as these can hinder proper sealing and cause wear.

Using a funnel, fill both chambers with dry desiccant, replace the caps, ensuring that they are fully engaged. Press the cartridge back into place on the side of the flow meter.



Note

If this is a new desiccant cartridge, remove the two red protective end caps from the ports before installing a new cartridge.




Figure 6-80pening the desiccant cartridge chambers

Renewing loose desiccant

To renew the desiccant, spread it in a single layer on a flat metal tray. Place in a vented, circulating forced air, conventional oven in a well ventilated room, and heat at 100 - 175°C (212 - 350°F) for about three hours, or until the color has returned to orange or yell ow .

MSDS (Material Safety Data Sheets) for silica gel chemicals are provided in AppendixC.

desiccator.

6.6 Troubleshooting

The tables in the following section provide troubleshooting information to help in determining the causes of problems that may occur with the Signature flow meter or TIENet devices.

The troubleshooting tables cover the flow meter and each TIENet device separately. Note that the 300 TIENet device (Table6-4) is the internal connector case.

Note

Any time a circuit board is replaced or a sensor disconnected, you MUST perform a hardware scan and SDI-12 scan (if connected) before resuming operation.

6.6.1Signature Flow Meter

	Table 6-3Troubleshooting: Signature Flow Meter			
Symptom	Cau se	Action	Parts	
Display repeatedly goes blank	Power setting is set to turn display off	If key is not pressed within 5 minutes, press any key to turn the display on.		
Blank Display but audi- ble beep when a key is	Contrast is out of adjustment Faulty Display	Adjust the display contrast by repeatedly press arrow while holding down the +/- key.	sing the up or down	
pressed		Replace with known good display.	Display 130-0602-06	

		ng: Signature Flow Meter (Continu	<i></i>
Symptom	Cau se	Action	Parts
Blank display and no beep when a key is pressed	Open Fuse F3	Replace 4A/250V/5X20mm Slo Blo fuse (Figure3-2 <i>Connector case, connectors</i> , <i>and fuses</i> , Item L). If the fuse opens again check for devices that may be shorting the supply, such as an external connection modem or option card.	4A Fuse 411-9901-84
	Dead Lead-Acid Battery	Replace or recharge the main battery con- nected to the internal "Lead-Acid" terminals.	60-3004-106 Model 946 Lead-Acid Battery
	DC power supply not	Check for proper AC voltage. If proper AC voltage is present, replace DC power supply.	DC Power Supply 60-4304-037
	supplying 12.8 VDC output.	Service check: Disconnect the internal power supply wires (Red +/pos, Black –/neg) from the power terminals (Figure3-2 <i>Connector</i> <i>case, connectors, and fuses</i> , Item F). Con- nect an Isco adaptor cable to the power termi- nals (Black +/pos, White –/neg). Then connect an Isco power supply (Model 913, 914, 923 or 924) to the adaptor cable. If the Signature then functions properly, replace the interna power supply.	ISCO Adaptor Cable 60-4304-086
	Broken or loose wire from power supply module to the connec- tor case.	Repair connections (Red +/pos, Black –/neg).	

Table 6	5-3Troubleshootin	g: Signature Flow Meter (Continu	ed)
Symptom	Cau se	Action	Parts
Blank display and no beep when a key is	Defective keypad	Substitute a known working keypad.	69 ⁻⁴ 303-809
pressed (Con't.)	Faulty or missing SD card	Reinstall or replace SD card on Main CBA.	SD Card Main CBA
	Main CBA faulty	Substitute with known good Main CBA.	60-4304-094
	Programming error - Zero flow rate or aster- isk (*)	Check measurement configuration of level, flo input for the Total Flow parameter.	w rate, and volume
Nonresettable totalizer does not advance	Broken wire connection	Check wire connections for the totalizer on the	Main CBA.
	Defective totalizer	Replace totalizer	Mechanical Totali zer 60-4304-015
	Flash drive encrypted or defective	Try a different USB Flash drive	
•	Adaptor cable defectiveF	eplace cable	USB Adaptor Cable 480-2946-02
screen	Micro-USB Assembly damaged	Replace port	Micro-USB Assembly 60-9004-468
	The necessary files are not on the flash drive.	Load the firmware from our website onto the flash drive, into a folder named BINFILE.	teledyneisco.com
Cannot update soft-	SD Card not functional	verify that the SD card includes a BINFILE	Micro-USB Card
ware / Read flash drive	or missing files.	folder with the appropriate bin file(s) inside.	250-300-066
	Faulty Main CBA	Replace the Main CBA.	Main CBA 60-4304-094

6.6.2TIENet 300 Connector

Case

Т	able 6-4Troubleshooting	g: TIENet 300 Connector Case	
Symptom	Cau se	Action	Part
	Device not configured for display on the Home Display.	Add the parameters to the Home Display. Section2.7.1 <i>Site Setup</i> .	Refer to
	Device has not been scanned.	Perform a hardware scan from TIENet Se Setup. Refer to Sections 2.6.1 <i>Smart Set</i> (<i>TIENet</i>) and 2.6.2 <i>SDI-12 Setup</i> .	
	Device is not wired correctly.	Rewire connector following label on the c	ase circuit board.
TIENet or SDI12 devices not appear- ing on display for configuration Refer to Section 2.6.1& 2.6.2.	Open Fuse	Check fuse FU-T 3.15A (F1, F4, F5). Replace if open. Refer to Figure3-2 <i>Connector case, connectors, and fuse</i> Item K.	3.15A Fuse 411-0212-70
	Defective TIENet or SDI12 device.	Substitute a known working device and re works, replace the faulty device.	escan. If it now
	Case circuit board faulty.	Substitute with known working board.	300 Connector Case CBA 60-4304-093
	Main CBA faulty.		Main CBA 60-4304-094

6.6.3TIENet 301 pH/Temp

Table	Table 6-5Troubleshooting: TIENet 301 pH/Temperature Device			
Symptom	Cau se	Action	Part	
	No sensor connected to the 301	Connect pH probe		
		Rescan device in Hardware Setup		
pH Will not calibrate	301 module not recognized	Check TIENet wire connections. Follow wi silk-screened on circuit board.	ring code	
	TIENet connection fuse open	Replace if open	3.15A Fuse	
		411-0212-70		
	Probe defective	Replace probe	pH Probe	
			60-9004-126	

Table 6-5Tr	Table 6-5Troubleshooting: TIENet 301 pH/Temperature Device (Continued)		
Symptom	Cau se	Action	Part
	Buffers contaminated or wrong buffer used.	Use new/correct pH buffer solution.	
Incorrect pH read-	Temperature is not being read.	Replace probe Clean probe and recalibrate. If readings	pH Probe
ings / slow response	Probe bulb is contaminated	are still incorrect, replace probe.	60-9004-126
	Calibrated before reading stabi- lized.	Recalibrate and allow the readings to stab tinuing with calibration.	ilize before con-

6.6.4TEINet 304 Contact Output Card

	Table 6-6Troubleshooting: TIENet 304 Contact Output Card		
S ymp to m	Cau se	Action	
The 304 card is for not a selectable option in the software after	A TIENET scan must be pre- prmed after the card is physi- cally installed.	Preform a TIENet scan.	
the card is	In the HARDWARE SETUP SM SENSOR SETUP CONFIGURE MEASUREMENTS, no options a selected.	ART In the HARDWARE SETUP SMART SENSOR SE Tରାମ ¢ଏହ re MEASUREMENTS, select one or more of the options.	
Contact closure is not being made (verified with an ohm meter)	The Contact Output card is not configured correctly in the software.	See section 2.7.7 to configure the 304 card properly.	

6.6.5TIENet 307 Analog Input Card

		ng: TIENet 307 Analog Input Card
S ymp to m	Cau se	Action
The 307 card is for not a selectable option in the software after	A TIENet scan must be pre- prmed after the card is physi- cally installed.	Preform a TIENet scan.
the card is installed.	In the HARDWARE SETUP SM SENSOR SETUP CONFIGURE MEASUREMENTS, no options a selected.	ART In the HARDWARE SETUP SMART SENSOR SETUP CONFIGI re MEASUREMENTS, select one or more of the options.
The 307 card is not reading 4-201	The analog input card is not configured correctly in the soft-ware.	See section 2.7.7 to configure the 307 card properly. Use the green and yellow LED lamps to verify the hardware using the set-up menus.
	The passive/active setting is incorrect or indeterminate.	Verify the setting your device requires and change the active or passive settings on the 307 card. Verify the setting from the set-up menus.
	mproper connection.	Verify the wires are attached to the correct channels and in the correct polarity. Use the labels and LED lamps to verity the hard-ware using the setup menus. The green LED lamp will light when proper current is flowing in the analog circuit.
	External device is faulty or incor- rectly configured.	To verify, check the output with an ampmeter.
	Over-current protection device in the 307 has been tripped.	Disconnect power from the 307 card, the Signature, and the external analog loop. Wait 30 seconds.

6.6.6TIENet 306 Sampler In te r fac e

	Table 6-8Troubleshooting: TIENet 306 Sampler Interface		
S ymp to m	Cau se	Action	
Incorrect pacing interval	ncorrect flow total selected for pacing	Assign the correct sensor to the correct flow rate to the correct total flow. Example: Needed to pace from the 330 bubbler, but programmed to pace from the 310 USLS.	
No sampler pac-s	Sampler's flow pulse input not working	Connect a different sampler, or test the existing sampler by short- ing pins A and C on the sampler's Flow Meter port, while the pro- gram is running. The displayed pulse count should count down.	

6.6.7TIENet 308 Analog Output

Table 6-9Troubleshooting: TIENet 308 4-20mA Analog Output			
Symptom	Ca use	Ac ti on	
	Incorrect wiring	Rewire per connector diagram	
4-20 output is missing, or zero current output	Excessive load	Disconnect external equipment and test the output with VOM. If OK then reduce load resistance (maximum 9002) or add isolated power to the current loop.	
	Analog circuit board failure	Use the other output channel on the 308 circuit board. If current is still 0 mA, replace circuit board. If the VOM reads 4mA or greater, reprogram to use that output or replace the circuit board. Part #60-4304-006	
4-20 only reads 4mA	Wires on incorrect output (wired to output 2 instead of out-l put 1)	Mane confidential introations intro and desity privation the	
	the TIENet HARDWARE SETUP SMART SENSOR SETUP CON (JTHENAE) ABURE MEMBERS/OUTPU	-	COI
	Vapily/shapsa.thetsestings/range tertput.	to the proper parame-	

Table 6-9Trou	bleshooting: TIENet 308	4-20mA Analog Output (Continued)
Symptom	Ca use	Ac ti on
	Excessive load	Disconnect external equipment and test the output with VOM. If OK then reduce load resistance (maximum 900 ^[2]) or add isolated power to the current loop.
4-20 reading incorrectly	Improper module/parameter set V for the output	/erify/change the settings/range to the correct mod- ule/parameter.
	Connected to incorrect output; e.g., wired to output 2 instead of output 1	yeve wou to the principal construction and ever if you are guine
The 308 option card is not a selectable option in the software after the card is installed.	IENet 308 is not properly con- figured	Verify the TIENet configuration contains analog percent readings
Measurement error for analog current	No load applied to the output cir- cuit, or open circuit wiring.	The output must have a load resistance (maximum 9002). For verification, this can be accomplished by connecting the current meter leads to the terminals of the 308 card.
External device not reading 4-20	Over-current protection device in the 307 has been tripped.	Disconnect power from the 307 card, the Signature, and the external analog loop. Wait 30 seconds.

6.6.8TIENet 310 USLS

Table 6-10Troubleshooting: TIENet 310 Ultrasonic Level Sensor						
Symptom	Cause	Ac ti on				
Invalid level, display has asterisk (*) by level reading	Not scanned	Perform a smart sensor scan				
	Not able to achieve signal lock (misalignment, loose mounting, turbulence, foam, or debris in the water)					
	Level outside of the Blanking distances	Adjust min/max blanking distances				
	Not wired correctly	Check/repair wiring				
	Open fuse	Replace fuse FU-T 3.15A and rescan. Part #411-0212-70. Refer to Figure 3-2 Item K.				
	Failed sensor	Replace with known good sensor				
No level reading on the dis- play	Parameter not selected to be displayed on Home Display	Add the parameter to the Home Display. Refer to Section2.7.1 <i>Site Setup</i> .				

Table 6-10Troubleshooting: TIENet 310 Ultrasonic Level Sensor (Continued)					
Symptom	Cause	Ac ti on			
Incorrect level reading	Level not adjusted properly	Readjust level			
	Sensor misaligned	Realign sensor			
	Objects in the path of the signal	Adjust min/max blanking distances and/or reposition sensor.			
	Sensor exposed to direct sunlight	Install sunshade. Refer to AppendixB Options and Accessories .			

6.6.9TIENet 330 Bubbler

Air Supply of Bubbler	The bubbler's air supply is brought into the air pump thru a des- iccator, filter, humidity sensor, and into the intake of the air pump.	
Output of Air Pump	Past the output of the air pump is a check valve that allows pres- surized air from the air pump to enter the air tank. The air pump is programmed to maintain a pressure in the air tank measured by a pressure transducer (P4 referenced thru P3 vented to ref- erence air).	
Normal Operation	During normal operation, the air purge solenoid is shut as air passes thru the filter, bubble orifice, and to the bubble out. Air passes thru the autozero valve to the pressure transducer P1(ref- erenced to P2 which is vented to reference air). The pressure measurement taken at P1 is used to calculate the level reading. During the purge cycle, the purge valve is opened allowing all the pressure in the tank to vent though the bubble out.	
Purge Cycle		
Autozero	The Signature automatically performs an autozero. During an autozero, the autozero valve is activated tying P1 and P2 together so an autozero of the pressure transducer can be	
	per- formed.	




Figure 6-9Plumbing diagram of bubbler

- •P1 is the pressure measurement for the bubble line.
- •P2 is the atmopheric reference for the bubble line.
- •P4 is the pressure measurement for tank pressure.
- •P4 is the atmopheric reference for the bubble line.
- •Autozero Valve normally has the bottom port going to P2 open and top port going to the 4-way manifold (closed) during the autozero cycle.

S ymp to m	Cau se	Error Type (How to Clear)	Action	Additional Information
Measurement error (Level)	Bubble Pressure <0.4PSI or >12 PSI	Flag error, no actions prevented Flag error, no actions		
Measurement error	Temp/Humidity	prevented		
(Temp/Humid.)	reading failed	Flag error, no actions		
Measurement out of	Measured Level >	prevented		
range High	3.2m	'		
Measurement out of	Measured Level <	Flag error, no actions		
range Low	0.002m	prevented Clears when Tank		
Plugged Bubble Line	Tank Pressure	Pressure <6.5PSI		
	>12PSI after purge	Continue level		
Pump/Pressure Error	Recharge time > 4s	readings if bubbling		
Pump Motor Error	Motor current sensed too high or low	Flag error, no actions prevented		
Level not reading	Blocked inlet/outlet		Bubbler Basic check	See section XXXX
correctly	line not connected		procedure	
No Bubble out	Blocked inlet/outlet		Bubbler Basic check	See section XXXX
	line not connected		procedure	

6.7330 Bubbler I ns ta llati on

The TIENet 330 bubbler device is factory-installed for Signature bubbler flow meters. It can also be installed by the user to convert a Signature flow meter into a bubbler, or to replace an old 330 device.

Preparation steps are provided in Section6.7.1 (converting a non-bubbler unit) and Section6.7.2 (replacing an existing bubbler device). Instructions for installing the new bubbler are in Section6.7.3.

Before opening the case, first ensure that mains power is disconnected from the unit.

Before opening the case, disconnect the optional battery backup power, if used.

Mote

In order to work with the 330 Bubbler module, the Signature must have an external desiccator installed. Refer to *External Desiccator*, on page 5-12.

External Desiccator, on page 5-12. Open the case, as described in Section3.2. If no bubbler was

previously installed, remove the cover shield over the main CBA. This will not be used again, since the 330 bubbler assembly includes its own cover shield.




Figure 6-10Remove non-bubbler shield

6.7.1 Preparation: Non-Bubbler **6.7.2 Preparation: Existing** Bubbler Open the case, as described in Section3.2. When replacing an existing 330 bubbler, to ensure that the

existing 330 bubbler, to ensure that the bubble line tubing is reconnected correctly, **label the tubing ends**, then remove the four mounting screws holding the 330 bubbler module in place (see Figure6-11).




Figure 6-11Remove bubbler module

6.7.3 Installation Procedure Referring to Figures6-12,and6-14, perform the following steps.

- 1.Place the bubbler assembly on top of the main CBA, ensuring that the four screw holes line up in the case, and the 10-pin connector engages correctly in its socket.
- 2.Attach the bubbler board to the control panel using the four self-tapping screws previously. Do not overtighten.




Figure 6-12 330 Bubbler assembly installation

Mote

There are three pieces of tubing on the bubbler that must be correctly connected for operation.

If any tubing is damaged, please purchase 1 meter of part #60-2003-104 and cut to the length needed for replacement. For additional information about tubing connections, refer to SectionA.2 **330 Bubbler** in AppendixA **Replacement Parts**.

- 3.Replace the port plug in the bottom of the case (usually second from the left) with the bubble line fitting.
- 4.Route the reference line tubing (with fitting on the end) through the bushing and press the fitting into the reference connector on the connector case.
- 5.Route the intake tubing (the shorter of the two open-ended tubes) through the bushing and behind the ribbon cable, and connect it to the intake port in the case wall.
- 6.Route the other end of the short tubing through the bushing and connect it to the humidity connector on the board.
- 7.Connect the bubble tubing (the longer of the two open-ended tubes) to the bubble line port in the bottom of the case.

Some Signature flow meters have a 'Y' fitting connecting both the reference and intake ports to the humidity connector. When installing a 330 bubbler in a unit with this tubing configuration, remove the 'Y' fitting and two shorter pieces of tubing. Bring the reference port tubing out from behind the ribbon and reroute it directly to the humidity connector.




Figure 6-13 Remove extra tubing and fitting (if applicable)




Figure 6-14 Routing and connections of 330 bubbler tubing

6.8Front Cover Replacement

A replacement front cover (door) comes with latches attached, and two new hinge pins.

Align the hinges of the front cover front panel. Press the pins into the hinge barrels, with each flange facing inward (refer to Figure6-15), until it is flush against the hinge surface.

Using a vice grip or other tool, spread and flatten the outward facing ends of the pins so they cannot be removed from the h inge s .




Figure 6-15 Front cover (door) replacement

6.9System Reset

In the event that the Signature Flow Meter becomes unresponsive, operation may be restored by removing and then restoring line power.

If the problem persists, operation may be restored by performing a hard reset.



A hard reset erases site data and restores the program to factory default settings.

To perform a hard reset, first remove line power and any external battery power and wait 30 seconds. Then, while holding down both the Home key and the Delete key, restore line power.

6.10Service and Repair Service tasks described in this manual may be performed on site by properly trained personnel. Other service and repairs must be performed at the factory. If your Teledyne ISCO equipment requires repair, contact Teledyne ISCO technical support.

Teledyne ISCO

Technical Service Dept. P.O. Box 82531 Lincoln, NE 68501 USA Phone: 866 298-6174 402 464-0231 FAX: 402 465-3085

E-mail: iscowatersupport@Teledyne.com

Speaking with a Teledyne ISCO Technical Service representative can often resolve the problem without the need to return the item. If the issue cannot be resolved by phone or email, you will receive a Return Authorization Number (RAN) and information on returning the equipment to the factory.

Signature[®] Flow Meter

Appendix A Replacement Parts

Replacement parts are called out in illustrations in this section. Reference the call-outs in the accompanying tables to determine the part number for the item.

A.1How to Order

Replacement parts can be purchased by contacting Teledyne ISCO's Customer Service Department.

Teledyne ISCO

Customer Service Dept. P.O. Box 82531 Lincoln, NE 68501 USA Phone: 800 228-4373 or 402 464-0231

FAX: 402 465-3022 E-mail: iscowatersupport@Teledyne.com **Signature Flow Meter**

PHOTO NOT AVAILABLE


Front Cover Assembly For Signature Flowmeter #6043 04038



Signature Flow Meter Front Panel Case #60430 8006



Front Panel Label/Keypad Assembly For Signature Flowmeter #69 430300 9



Case Assembly For Signature Flowmeter #60 430403 9



Cord Grip Fitting for Cable Diameters From 0.250 to 0.375 Inches, #209007311



Cord Grip Fitting for TIENet Cables and Cable Diameters From 0.375 to 0.438 Inches, #209007312

Lock Nut For Conduit (3/4 Inch) #23299 9700

PHOTO NOT AVAILABLE

Bottom Connector Plug For Signature Flowmeter #60430 3031



Antenna Connector Plug #60200 3568

Signature USB Hub Replacement parts

PHOTO NOT AVAILABLE

USB drive for data download and firmware updates # 805000 439



Replacement Usb Hub Kit for Signature #609004 468



Usb Micro a To Usb A Cable for Usb Flash Drive Connection to Signature Meter (3 In.) #480294602



Usb A to Usb Micro B Cable for Connection to Signature Meter (6.5 Ft), #480294601

Signature Power Supply Replacement parts



Power Supply Assembly for Signature Flowmeter #604304 037

Fuse (3.15 Amp / 250 Vac / Sb) #411021 270

Fuse (4.0 Amp / 250 Vac / T) #411990 184



Fuse Cover (5 Mm) #103000 000

PHOTO NOT AVAILABLE

Signature Flowmeter Voltage Stabilizer #60532 4161

Signature Circuit Board Replacement parts



Main Circuit Board Assembly for Signature Flowmeter # 6043040 94



Liquid Crystal Display Module #13 006020 6



Connector Case Circuit Board Assembly for Signature Flowmeter, #604304093



Flash Card for Signature Flowmeters #250 300066



Lithium Coin Cell Battery (3 Volt / 220 Mah) #340 503001

Signature Wiring related Replacement parts

PHOTO NOT AVAILABLE

Power Cable for 2103ci / 2103gi / 2105ci / 2105gi / Signature #6920 04670

PHOTO NOT AVAILABLE

Serial Cable Assembly for Signature (Db9-db9) #6943 04028

PHOTO NOT AVAILABLE

Power Cable for 2103ci / 2103gi / 2105ci / 2105gi / Signature #69200 4670





Header Socket With Screw Clamps (6 Pin) #69430 3102

TIENet Noise Reduction Service Kit #60532 4204

Signature Desiccant Related Replacement parts

PHOTO NOT AVAILABLE

Desiccant Cap Assembly For Signature Flowmeter #60430 4090



Air Fitting For Signature Flowmeter Desiccant Cartridge #60430 3130



Desiccant (8 Oz. Bag) #0990 00200



Desiccant (16 Oz. Bottle) #6020 04233

Signature Seals and Gaskets Replacement parts



O-ring (0.301 I.d., 0.070 Cross Section) # 2021000 11

PHOTO NOT AVAILABLE

O-ring (0.926 l.d., 0.070 Cross Section) #202100 021



Dust Cover #14 # 1491001 00 PHOTO NOT AVAILABLE

Inline Air Filter For 25 Mm Tubing #2090 09225

PHOTO NOT AVAILABLE

Barb Fitting Used On Reference Port Tubing # 6043030 75

TIENet 330 Bubbler Replacement Parts



Air Pump Replacement Kit For Signature Bubbler Flowmeter #604337 002



Inline Filter For 1/8 Inch Tubing (5 Micron) #2 090092 04



Solenoid Valve, 12 Vdc (0-125 Psig) #2 090095 03



Solenoid Valve, 12 Vdc (0-100 Psig) #2090 09504



High Flow Check Valve #209 009612



Threaded Hose Barb (1/8 Inch I.d.) #2090 16592




White Nylon Tube Fitting #10-32 To 1/8 Inch Barbed #2090 16637



Orifice Assembly (0.1568 O.d.) #20901 6703

PHOTO NOT AVAILABLE

Male Swivel Elbow (1/8 Inch X 10-32) #20901 6705



Orifice Insert (0.0020 Diameter) #209 016763



Hydrophobic Filter #209 009303

Signature[®] Flow Meter

Appendix B Options and Accessories

B.10rdering Information

Options and accessories can be purchased by contacting Teledyne ISCO's Customer Service Department.

Teledyne ISCO

Customer Service Dept. P.O. Box 82531 Lincoln, NE 68501 USA Phone: 800 228-4373 or 402 464-0231 FAX: <u>402 465-3022</u> E-mail: iscowatersupport@Teledyne.com

Note

For options and accessories exclusive to the external TIENet devices, refer to the appropriate TIENet user manuals (found at www.teledyneisco.com and listed in SectionB.7 *Sensor Mounting Rings*).

B.2Signature Flow Meter Accessories

Cord grip fitting for TIENet cable	
³ /4" NPT .375/.437" OD	
Cord grip fitting for Battery backup cable	209-0073-11
³ /4" NPT .250/.375" OD	
Cord grip fitting with flexible strain protection	60-4307-022
Cord grip fitting for rain gauge and option card circuits, 3 hole	
Exterior desiccator - Required for use with 330 and 350 TIENet devices	
Silica gel desiccant, 1.5-lb container	
Model 674 rain gauge connect cable for Signature	60-4304-055
TIENet connection cable for Signature	60-4304-056
TIENet connection cable for Signature, cut to length	60-4304-068
TIENet 'Y' connection cable	
TIENet Header 6 screw clamp plug	69-4303-102
Analog Output 3 screw clamp header clip	60-4304-085
Analog Input 3 screw clamp header clip	60-4304-083
Contact Output 3 screw clamp header clip	
Power Supply Assembly with wiring harness	60-4304-037
TIENet Expansion Box w/ 10 ft cable	60-4307-023
TIENet Expansion Box w/ 10 ft cable and reference air support60-4357-018Bulk	TIENet Cable, cut to
Length	60-4304-050

Adaptor cable, USB Micro to USB-A	480-2946-02 USB
connect cable, Signature to PC	480-2946-01
ProHanger SST Suspension bracket for 18 - 24in. manhole shaft	69-2003-599
Spreader bar for suspension of sensor or flow meter in manhole shaft	60-3004-110
7-Digit, non-resettable mechanical totalize	60-4304-015
Portable Stand Assembly	60-4304-079
Cord Grip 3-Hole for option wiring	60-4304-080
Rain Gauge 0.1in	60-3284-001 Rain
Gauge 0.1 mm	60-3284-006 Model
674 rain gauge connect cable for Signature	60-4304-055 8oz.
Desiccant bag	99-0002-00
External Desiccator Assembly	60-4304-092

B.3Power Accessories

Battery Backup: 946 Lead-acid battery pack, connect cable, and battery mounting hardware60-4307-015
DC Power Cable with cord grip60-4304-086
117V Power cord kit60-4304-044
Includes strain relief cord-grip fitting
240V Power cord kit60-4304-045
Includes strain relief cord-grip fitting
946 Lead Acid Battery60-3004-106 948
Lead Acid Battery 45A-H68-3000-948 948
Batttery Charger 12V 6A
Power Pack 117V60-1684-088 914
Power Pack w/ Battery Backup 117 V68-3004-130 923
Power Pack 240V60-3004-190 924
Power Pack w/ Battery Backup 240 V68-3004-160 Cord grip
w/protection60-4307-022 965 Battery
Charger 5 station 117V68-3000-965 966 Battery
Charger 5 station 117V68-3000-966 963 Battery
Charger 1 station 117/240V68-3004-198

B.4TIENet Accessories

B.4.1 Internal to Signature

Analog	Outpu	t Optio	n Cai	[.] d60-4304-006
Analog	Input	Option	Card	
Contact	Output	Card		

B.4.2 Sensor and Cabling

TIENet connection	n cable fo	or Signature	
TIENet connectio	າ cable for S	ignature, cut	to length60-4304-068

CA Assembly TIENet Y w/ connector	60-4304-066
TIENet Expansion Box (includes 10 ft TIENet cable and 2 cord grips)	60-4307-023
TIENet Expansion Box with reference line support	60-4357-018
Cord grip fitting, 3/4" NPT, for TIENet cable	209-0073-12
Bulk TIENet Cable, cut-to-length, order by the foot	60-4304-050

Connection Ending in Unterminated Leads	Includes cord grip, combination pH probe with built-in exposed temperature probe and 25 ft. probe cable, and one package of each buffer and rinse solution for probe calibration.
10 m cable*	
cable*	
length cable*	
	*Cable lengths from Signature to TIENet 301 device
B.4.4301 pH/Temperature Device with Signature Connection Ending in TIENet Plug	For use with portable Signature TIENet receptacle. <i>Includes combination pH probe with built-in exposed temperature</i> <i>probe and 25 ft. probe cable and one package of each buffer and</i> <i>rinse solution for probe calibration</i>
10 m cable*	
length cable*	
	*Cable lengths from Signature to TIENet 301 device
B.4.5306 Sampler Interface Cable with Signature	For use with Signature 6 position plug-in (green) terminal strip.
Connection Ending in Unterminated Leads	Includes cord grip and sensor with cable. (See cable lengths below).
306 Sampler Interface w/ 10 m (32	.8 ft) cable60-4304-007 306
•	t) cable60-4304-008 306
Device with Signature Connection Ending in TIENet Plug 10 m cable* cable* length cable* B.4.5306 Sampler Interface Cable with Signature Connection Ending in Unterminated Leads	Includes combination pH probe with built-in exposed temperatur probe and 25 ft. probe cable and one package of each buffer and rinse solution for probe calibration 60-4307-070 23 60-4307-071 Cut- 60-4307-072 *Cable lengths from Signature to TIENet 301 device For use with Signature 6 position plug-in (green) terminal strip. Includes cord grip and sensor with cable. (See cable length below). 8 ft) cable

Sampler Interface w/ CTL cable	60-4304-088 Assembly
Model 306 10m (5800/4700 OLNY)	
Model 306 23m (5800/4700 OLNY)	

B.4.6306 Sampler Interface For use with portable Signature TIENet receptacle. Cable with Signature Connection Ending in TIENet Plug.

306 Sampler Interface w/ connector and 10m (32.8 ft) cable	60-4304-076
306 Sampler Interface w/ connector and 23 m (75 ft) cable	60-4304-077
306 Sampler Interface w/ connector and CTL cable	60-4304-078

4700/5800 Sampler Interface Adapter cable

B.4.7310 Ex Ultrasonic Level	For use with Signature 6 position plug-in (green) terminal
Sensor with Signature	strip.
Connection Ending in	Includes cord grip and sensor with cable. (See cable lengths
Unterminated Leads.	be low.)
310 Ultrasonic sensor w/ 10m cable	e
310 Ultrasonic sensor w/ 23m cable	e

. *Cable lengths can go up to 150 m with an expansion box.

B.4.8310 Ex Ultrasonic Level
Sensor with Signature
Connection Ending in
TIENet Plug.For use with portable Signature TIENet receptacle.Includes cord grip and sensor with cable. (See cable lengths
below).

B.5330 Bubble Options and Accessories

330 Bubbler internal sensor	60-4334-003 Bubble
line, vinyl, 1/8" x 100ft	60-1700-003 SST Bubble
tube, 4ft long - for PTFE, 1/8" Line	60-1873-043 Bubble line carrier -
attach to ISCO Mounting Ring	

B.5.1 350 Area Velocity Sensor with Signature Connection Ending in Unterminated Leads.	For use with Signature 6 position plug-in (green) terminal strip. Includes cord grip and sensor with cable. (See cable lengths below).
350 AV Sensor w/ 10m Cable	
AV Sensor w/ 23m Cable	
Sensor Cut-to-length	

B.5.2 350 Area Velocity For use with portable Signature TIENet receptacle. Sensor with Signature Connection Ending in TIENet Plug.

350 AV Sensor w/ connector and 2ft connector	60-4354-117 350
AV Sensor w/ connector and 10m cable	60-4354-123 350 AV
Sensor w/ connector and 23m cable	60-4354-124

350 AV Sensor w/ connector Cu	ut-to-length 60-4354-125
B.5.3360 LaserFlow Velocity Sensor with Signature connection ending in unterminated leads.	For use with Signature 6 position plug-in (green) terminal strip. Includes cord grip and sensor with cable. (See cable lengths below).
360 Laserflow sensor w/ 10m cable	

*Cable lengths can go up to 150 m

B.6 Modems

GSM Digital cellular modem (Global) (Cellular service not included.)	60-4307-101 LTE
Digital cellular modem (North America) (Cellular service not included)	
cellular modem (Europe) (Cellular service not included)	
antenna for CDMA, GSM, LTE	60-4804-035 Ethernet
modem	60-4307-016

B.7Sensor Mounting Rings

B.7.1 Spring Rings

Probe Mounting Ring for 6"	pipe	
	pipe	
)" pipe	
	2" pipe	
	ре	

B.7.2 Scissor Rings

Base Section (with tabs for mounting up to five probes). Scissors Assembly			60-3004-	169
Extension 1 (9.0")			60-3004-	172
Extension 2 (21.5") Extension 3 (31.5")			60-3004-	174
Extension 4 (41.5") 24" Pipe ID				
Pipe İD		0-043	38-44" Pipe	ID
	68-3000-045	44-48 60"	Pipe	ID
	68-3000-046 68-3000-047	72" 16-60"	Pipe ID Pipe	 D
		10 00	Tipe	īD

V Note

Scissor Mounting Ring Assemblies will require a base and scissors section for all sizes. Each scissors ring includes a base section, scis- sors mechanism, extensions, plastic ties, and a manual). Sizes from 16" to 80" will also require two or more extension sections.

Signature® Flowmeter

Appendix C Modbus Output Protocol

	Sections C.1 through C.3 give an overview of the basic capabil- ities and operation of Modbus output protocol as it applies to the Teledyne ISCO Signature Flowmeter. For a Glossary of Terms and Common Acronyms, see Section C.4.
C.1 Introduction	Modbus is a simple command/response mechanism to read
	from and write to specific memory locations called <i>registers</i> . A register is a holding place for a piece of digital information within the equipment. The Signature uses Modbus ASCII and Modbus RTU protocols, providing a standard protocol for real-time data retrieval. The data can be sent to a central computer for display, data collection, or process control. Modbus cannot be used
C.2 Operation	to retrieve historical data from the Signature's memory. This section describes the overall capabilities and operation of Modbus.
	There are many standard, third party Modbus drivers and OPC servers that may be used to link a remote Modbus device, such as the Signature Flowmeter, to SCADA or process control software, such as Wonderware®1 or Intellution®2. The OPC server commu- nicates with the Flowmeter and accesses registers. The definition of what information is contained and where (the register number, or address) is set by Teledyne ISCO.
	The Signature register addresses, and what parameters are held where, are available in TableC-1 in Section C.6.1.
	By accessing these registers you can obtain the current value of whatever parameter you desire. The reading(s) can then be dis- played or stored wherever you designate as a destination; for example, a process control computer.
	Not all registers are limited to read-only data storage. You can
	also use two of the registers for control purposes. For example, writing a "1" value to register 25 ("TakeReadingFlag" register), tells the Signature to update its readings.

^{1.}Wonderware® is a registered trademark of Wonderware Software Development Corporation.

^{2.}Intellution® is a registered trademark of Intellution, Inc.

C.3 Configurations

A variety of configurations can be made with Modbus, either through direct connection or through a modem.

In the example shown in Figure C-1, you are direct-connecting a server PC to two individual Signature sites through Modbus, using the COM ports on the OPC Server, which are directly connected to the remote sites.

Connection to the Flowmeter is made via the RS-485 terminal on

the Signature case board (refer to Figure3-2 *Connector case, connectors, and fuses*).




Figure C-1Configuration example

The operation sequence for the example above can be summarized in the following steps:

- 1.Signatures take readings from sensors.
- 2.Signatures store readings (level, velocity, flow rate, etc.) in their specified registers.
- 3. The user requests data through Process Control.
- 4.Process Control asks the OPC server to gather information.
- 5.OPC connects to the specified Signature Flowmeter through the cable (direct connection), retrieves site data and populates the OPC server's holding index.
- 6.Process Control takes the data from the OPC server's holding index and gives the data to the user.

Note that Process Control can be either manual or automated in this example, and that the OPC server and Process Control may be located physically on the same computer. **C.4Glossary of Terms** Address-An address is a digital location specified for a device (such as the Signature Flowmeter).

ASCII–Short for American Standard Code for Information Interchange, ASCII is a code that represents English characters with numbers. Most computers represent text with ASCII code, making it possible for one computer or device to share data with another.

DCS-Distributed Control Systems

Dedicated Line-A telecommunications path reserved for communication between two specified points and not shared among multiple points.

Modbus Protocol-Modbus Protocol is a messaging structure used to establish master-slave/client server communications between intelligent devices. Modbus is a simple command/response mechanism to read from and write to reg-

ist e rs.

MTU-Master Terminal Unit

OPC -OPC (OLE for Process Control) means open connectivity via open (free for use) standards. It is a series of software standards specifications that fill a need in automation (like printer drivers did for Windows), acting as a translator for data transmission and process control.

The specification defines a standard set of objects, interfaces, and methods for use in process control and manufacturing automation applications to facilitate interoperability. There are hundreds of OPC Data Access servers and clients.

PLC-Programmable Logic Controller

Registers-A register is a location in memory for a specific data type. The definition of what data is contained and where (the registry number, or address) is set by the equipment manufacturer (in this case Teledyne ISCO). **RTU**-Short for Remote Terminal Unit

(or Remote Telemetry

Unit), RTU is a code that represents data using a compact binary format. **SCADA** –SCADA (Supervisory Control And Data

Acquisition)

is a computer system for gathering and analyzing real-time data. SCADA systems are used to monitor and control plant operation, or equipment in industries.

The SCADA system transfers the information (for example,

where a leak has occurred in a pipeline), back to a central site, alerting the home station of the leak, performing necessary analysis and control (such as determining if the leak is critical), and displaying the information in a logical and organized manner.

SCADA systems can be relatively simple, such as one that mon-

itors the environmental conditions of a small office building, or very complex, such as a system that monitors all the activity in a nuclear power plant or a municipal water system.

TCP/IP-Transmission Control Protocol/Internet Protocol

C.5Signature ASCII or RTU Address	The Signature's address (Device ID) is user-programmable between 2 and 247.
	Be careful not to assign the same address to more than one F lowm ete r.
C.6Register Definitions	The register definitions for the Signature Flowmeter are pro- vided in the following table.
	Where no other Unit Of Measure exists for a parameter, percent (%) can be used in most situations.
C.6.1Modbus Registers	Modbus tables are available through the front panel of the Sig- nature or the USB drive.

Table C-1 Output Registers for Signature Flowmeter

Register	Name	Data Type	Units of	Read/W	Description
Number			Measure	rite	
4 0025	TakeReadingFlag	Word		R/W	Set to 1 to update readings, 2 for
					automatic update
4 0026	UpdateInterval	Word	Seconds	R/W	The reading update interval in
					seconds
4 0027	Activeflags	Word		R	The bit fields to indicate which
					sensors are active
40040 40041	Level	Float	Meters	R Lev	el
4 0042	Levelstatus	Word		R	Non-zero is an error
40043 - 48	Leveltime	Word		R	The last level reading time,
					sec-min-hour-day-month-year
40055 40056	Level1	Float	Meters	R	Level 1
4 0057	Level1status	Word		R	Non-zero is an error
40058 - 63	Level1time	Word		R	The last level 1 reading time,
				-	sec-min-hour-day-month-year
40070 40071	Level2	Float	Meters	R	Level 2
4 0072	Level2status	Word		R	Non-zero is an error
40073 - 78	Level2time	Word		R	The last level 2 reading time,
					sec-min-hour-day-month-year
40085 40086	Level3	Float	Meters	R	Level 3
4 0087	Level3status	Word		R	Non-zero is an error
40088 - 93	Level3time	Word		R	The last level 3 reading time,
					sec-min-hour-day-month-year

40100 40101	Level4	Float	Meters	R	Level 4
4 0102	Level4status	Word		R	Non-zero is an error
40103 - 08	Level4time	Word		R	The last level 4 reading time,
			-		sec-min-hour-day-month-year
40115 40116	Level5	Float	Meters	R	Level 5
4 0117	Level5status	Word		R	Non-zero is an error
40118 - 23	Level5time	Word		R	The last level 5 reading time, sec-min-hour-day-month-year
40130 40131	Level6	Float	Meters	R	Level 6
4 0132	Level6status	Word		R	Non-zero is an error
40133 - 38	Level6time	Word		R	The last level 6 reading time, sec-min-hour-day-month-year
40145 40146	Level7	Float	Meters	R	Level 7
4 0157	Level7status	Word		R	Non-zero is an error
40158 - 63	Level7time	Word		R	The last level 7 reading time, sec-min-hour-day-month-year
40160 40161	Velocity	Float	Meters/Sec	R	Velocity
4 0162	Velo cit yst atus	Word		R	Non-zero is an error
40163 - 68	Velocitytime	Word		R	The last velocity reading time, sec-min-hour-day-month-year
40175 40176	Velocity1	Float	Meters/Sec	R	Velocity 1
4 0177	Velocity1status	Word		R	Non-zero is an error
40178 - 83	Ve loc it y1 ti me	Word		R	The last velocity 1 reading time, sec-min-hour-day-month-year
40190 40191	Velocity2	Float	Meters/Sec	R	Velocity 2
4 0192	Velocity2status	Word		R	Non-zero is an error
40193 - 98	Ve loc it y2 ti me	Word		R	The last velocity 2 reading time, sec-min-hour-day-month-year
40205 40206	Velocity3	Float	Meters/Sec	R	Velocity 3
4 0207	Velocity3status	Word		R	Non-zero is an error
40208 - 13	Ve loc it y3 ti me	Word		R	The last velocity 3 reading time, sec-min-hour-day-month-year
40220 40221	Velocity4	Float	Meters/Sec	R	Velocity 4
4 0222	Velocity4status	Word		R	Non-zero is an error

40223 - 28	Ve loc it y4 ti me	Word		R	The last velocity 4 reading time,
					sec-min-hour-day-month-year
40235 40236	Velocity5	Float	Meters/Sec	R	Velocity 5
4 0237	Vel oci ty 5stat us	Word		R	Non-zero is an error
40238 - 43	Ve loc it y5 ti me	Word		R	The last velocity 5 reading time,
		-			sec-min-hour-day-month-year
40250 40251	Velocity6	Float	Meters/Sec	R	Velocity 6
4 0252	Vel oci ty 6stat us	Word		R	Non-zero is an error
40253 - 58	Ve loc it y6 ti me	Word		R	The last velocity 6 reading time, sec-min-hour-day-month-year
40265 40266	Velocity7	Float	Meters/Sec	R	Velocity 7
4 0267	Vel oci ty 7stat us	Word		R	Non-zero is an error
40268 - 73	Ve loc it y7 ti me	Word		R	The last velocity 7 reading time,
					sec-min-hour-day-month-year
40280 40281	Flowrate	Float	Cubic	R	Flow rate
			Meters/Sec		
4 0282	Flowratestatus	Word		R	Non-zero is an error
40283 - 88	Flowratetime	Word		R	The last flow rate reading time,
40295 40296	Flowrate1	Float	Cubic	R	sec-min-hour-day-month-year
40233 40230	Howrater	liout	Meters/Sec	IX.	Flow rate 1
4 0297	Flo wrat e1 status	Word		R	Non-zero is an error
40298 - 303	Flowrate1time	Word		R	The last flow rate 1 reading time,
					sec-min-hour-day-month-year
40310 40311	Flowrate2	Float	Cubic	R	Flow rate 2
			Meters/Sec		
4 0312	Flo wrat e2 status	Word		R	Non-zero is an error
40313 - 18	Flowrate2time	Word		R	The last flow rate 2 reading time,
40225 40226	Claumate 2	Flast			sec-min-hour-day-month-year
40325 40326	Flowrate3	Float	Cubic	R	Flow rate 3
4 0327	Flo wrat e3 status	Word	Meters/Sec	R	Non-zero is an error
40328 - 33	Flowrate3time	Word		R	The last flow rate 3 reading time, sec-min-hour-day-month-year
40340 40341	Flowrate4	Float	Cubic	R	Flow rate 4
			Meters/Sec		
4 0342	Flo wrat e4 status	Word		R	Non-zero is an error
40343 - 48	Flowrate4time	Word		R	The last flow rate 4 reading time,
· · · ·					sec-min-hour-day-month-year
40355 40356	Flowrate5	Float	Cubic	R	Flow rate 5
			Meters/Sec		

4 0357	Flo wrat e5 status	Word		R	Non-zero is an error
40358 - 63	Flowrate5time	Word		R	The last flow rate 5 reading time,
					sec-min-hour-day-month-year
40370 40371	Flowrate6	Float	Cubic	R	Flow rate 6
			Meters/Sec		
4 0372	Flo wrat e6 status	Word		R	Non-zero is an error
40373 - 78	Flowrate6time	Word		R	The last flow rate 6 reading time,
10005 10005					sec-min-hour-day-month-year
40385 40386	Flowrate7	Float	Cubic	R	Flow rate 7
4 0387	Flo wrat e7 status	Word	Meters/Sec	R	Non-zero is an error
			-		
40388 - 93	Flowrate7time	Word		R	The last flow rate 7 reading time,
40400 40401	Temperature	Float	Degrees	R	sec-min-hour-day-month-year
			Celsius		Temperature
4 0402	Temperaturestatus	Word		R	Non-zero is an error
40403 - 08	Temperaturetime	Word		R	The last temperature reading
	· · · · · · · · · · · · · · · · · · ·				time,
					sec-min-hour-day-month-year
40415 40416	Temperature1	Float	Degrees	R	Temperature 1
			Celsius		
4 0417	Temperature1status	Word		R	Non-zero is an error
40418 - 23	Temperature1time	Word		R	The last temperature 1 reading
					time,
					sec-min-hour-day-month-year
40430 40431	Temperature2	Float	Degrees	R	Temperature 2
			Celsius		
4 0432	Temperature2status	Word		R	Non-zero is an error
40433 - 38	Temperature2time	Word		R	The last temperature 2 reading
					time,
					sec-min-hour-day-month-year
40445 40446	Temperature3	Float	Degrees	R	Temperature 3
			Celsius		
4 0447	Temperature3status	Word	-	R	Non-zero is an error
40448 - 53	Temperature3time	Word		R	The last temperature 3 reading
					time,
10100 10101	\/-1		Cubis Martin		sec-min-hour-day-month-year
40460 40461	Vol ume	Float	Cubic Meters	R	Vol ume
4 0462	Volumestatus	Word		R	Non-zero is an error
40463 - 68	Vol um et im e	Word		R	The last volume reading time,
					sec-min-hour-day-month-year
	Volume1				

4 0477	Vol ume1st atus	Word		R	Non-zero is an error
40478 - 83	Volume1time	Word		R	The last volume 1 reading time,
		_			sec-min-hour-day-month-year
40490 40491	Volume2	Float	Cubic Meters	R	Volume 2
4 0492	Vol ume2st atus	Word		R	Non-zero is an error
40493 - 98	Volume2time	Word		R	The last volume 2 reading time,
40505 40500		EL			sec-min-hour-day-month-year
40505 40506	Volume3	Float	Cubic Meters	R	Volume 3
4 0507	Vol ume3st atus	Word		R	Non-zero is an error
40508 - 13	Volume3time	Word		R	The last volume 3 reading time,
					sec-min-hour-day-month-year
40520 40521	Volt age	Float	Vol ts	R	Voltage
4 0522	Voltagestatus	Word		R	Non-zero is an error
40523 - 28	Vol tag et im e	Word		R	The last voltage reading time,
					sec-min-hour-day-month-year
40535 40536	Voltage1	Float	Vol ts	R	Voltage 1
4 0537	Voltage1status	Word		R	Non-zero is an error
40538 - 43	Voltage1time	Word		R	The last voltage 1 reading time,
					sec-min-hour-day-month-year
40550 40551	Voltage2	Float	Vol ts	R	Voltage 2
4 0552	Voltage2status	Word		R	Non-zero is an error
40553 - 58	Voltage2time	Word		R	The last voltage 2 reading time,
					sec-min-hour-day-month-year
40565 40566	Voltage3	Float	Vol ts	R	Voltage 3
4 0567	Voltage3status	Word		R	Non-zero is an error
40568 - 73	Voltage3time	Word		R	The last voltage 3 reading time,
					sec-min-hour-day-month-year
40580 40581	A nalo g/ %	Float	4-20mA/	R	Analog output or percentage
			0-1 00%		
4 0582	Analog/status	Word		R	Non-zero is an error
40583 - 88	Analog/time	Word		R	The last Analog output or
					percentage reading time,
					sec-min-hour-day-month-year
40595 40596	Analog/1	Float	4-20mA/	R	Analog output 1 or percentage
			0-1 00%		
4 0597	Analog/1status	Word		R	Non-zero is an error

40598 -608	Analog/1time	Word		R	The last Analog output 1 or
					percentage reading time,
					sec-min-hour-day-month-year
40610 40611	Analog/2	Float	4-20mA/	R	Analog output 2 or percentage
			0-1 00%		
4 0612	Analog/2status	Word		R	Non-zero is an error
40613 -18	Analog/2time	Word		R	The last Analog output 2 or
					percentage reading time,
					sec-min-hour-day-month-year
40625 40626	Analog/3	Float	4-20mA/	R	Analog output 3 or percentage
			0-1 00%		
4 0627	Analog/3status	Word		R	Non-zero is an error
40628 -33	Analog/3time	Word		R	The last Analog output 3 or
					percentage reading time,
					sec-min-hour-day-month-year
40640 40641	Analog/4	Float	4-20mA/	R	Analog output 4 or percentage
			0-1 00%		
4 0642	Analog/4status	Word		R	Non-zero is an error
40643 -48	Analog/4time	Word		R	The last Analog output 4 or
	-				percentage reading time,
					sec-min-hour-day-month-year
40655 40656	Analog/5	Float	4-20mA/	R	Analog output 5 or percentage
			0-1 00%		
4 0657	Analog/5status	Word		R	Non-zero is an error
40658 -63	Analog/5time	Word		R	The last Analog output 5 or
					percentage reading time,
					sec-min-hour-day-month-year
40670 40671	Analog/6	Float	4-20mA/	R	Analog output 6 or percentage
			0-1 00%		
4 0672	Analog/6status	Word		R	Non-zero is an error
40673 -78	Analog/6time	Word		R	The last Analog output 6 or
					percentage reading time,
					sec-min-hour-day-month-year
40685 40686	Analog/7	Float	4-20mA/	R	Analog output 7 or percentage
			0-1 00%		
4 0687	Analog/7status	Word		R	Non-zero is an error
40688 -93	Analog/7time	Word		R	The last Analog output 7 or
					percentage reading time,
					sec-min-hour-day-month-year
40700 40701	Analog/8	Float	4-20mA/	R	Analog output 8 or percentage
			0-1 00%		
4 0702	Analog/8status	Word		R	Non-zero is an error

40703 -08	Analog/8time	Word		R	The last Analog output 8 or
					percentage reading time,
					sec-min-hour-day-month-year
40715 40716	Analog/9	Float	4-20mA/ 0-1 00%	R	Analog output 9 or percentage
4 0717	Analog/9status	Word	0-1 00%	R	Non-zero is an error
40718 -23	Analog/9time	Word		R	The last Analog output 9 or
					percentage reading time,
					sec-min-hour-day-month-year
40730 40731	Analog/10	Float	4-20mA/	R	Analog output 10 or percentage
			0-1 00%		
4 0732	Analog/10status	Word		R	Non-zero is an error
40733 -38	An al og /1 Oti me	Word		R	The last Analog output 10 or
					percentage reading time,
					sec-min-hour-day-month-year
40745 40746	Analog/11	Float	4-20mA/	R	Analog output 11 or percentage
			0-1 00%		
4 0747	Analog/11status	Word		R	Non-zero is an error
40748 -53	An al og /1 1ti me	Word		R	The last Analog output 11 or
					percentage reading time,
					sec-min-hour-day-month-year
40760 40761	Analog/12	Float	4-20mA/ 0-1 00%	R	Analog output 12 or percentage
4 0762	Analog/12status	Word		R	Non-zero is an error
40763 -68	An al og /1 2ti me	Word		R	The last Analog output 12 or
					percentage reading time,
					sec-min-hour-day-month-year
40775 40776	Analog/13	Float	4-20mA/	R	Analog output 13 or percentage
			0-1 00%		
4 0777	Analog/13status	Word		R	Non-zero is an error
40778 -83	An al og /1 3ti me	Word		R	The last Analog output 13 or
					percentage reading time,
					sec-min-hour-day-month-year
40790 40791	Analog/14	Float	4-20mA/	R	Analog output 14 or percentage
			0-1 00%		
4 0792	Analog/14status	Word		R	Non-zero is an error
40793 -98	An al og /1 4ti me	Word		R	The last Analog output 14 or
					percentage reading time,
					sec-min-hour-day-month-year
40805 40806	Analog/15	Float	4-20mA/	R	Analog output 15 or percentage
			0-1 00%		
4 0807	Analog/15status	Word		R	Non-zero is an error

40808 -13	An al og /1 5ti me	Word		R	The last Analog output 15 or percentage reading time, sec-min-hour-day-month-year
40880 40881	Fl uore sen ce	Float	%	R	sec-min-nour-day-month-year
4 0882	Fluoresencestatus	Word		R	
40883 - 88	Fluoresencetime	Word		R	
40895 40896	Fluoresence1	Float	%	R	
4 0897	Fluoresence1status	Word		R	
40898 - 903	Fluoresence1time	Word		R	
40910 40911	Fluoresence2	Float	%	R	
4 0912	Fluoresence2status	Word		R	
40913 - 18	Fluoresence2time	Word		R	
40925 40926	Fluoresence3	Float	%	R	
4 0927	Fluoresence3status	Word		R	
40928 - 33	Fluoresence3time	Word		R	
40940 40941	Battery	Float	Vol ts	R	
4 0942	Batterystatus	Word		R	
40943 - 48	Batterytime	Word		R	
40955 40956	Battery1	Float	Vol ts	R	
4 0957	Battery1status	Word		R	
40958 - 63	Battery1time	Word		R	
40970 40971	Battery2	Float	Vol ts	R	
4 0972	Battery2status	Word		R	
40973 - 78	Battery2time	Word		R	
40985 40986	Battery3	Float	Vol ts	R	
4 0987	Battery3status	Word		R	
40988 - 93	Battery3time	Word		R	
41000 41001	Dissolved Gas	Float	mmHg	R	
4 1002	Dissolved Gasstatus	Word		R	
41003 - 08	Dissolved Gastime	Word	-	R	
41015 41016	Dissolved Gas1	Float	mmHg	R	
4 1017	Dissolved Gas1status	Word		R	
41018 - 23	Dissolved Gas1time	Word		R	

· · · · ·	1		1 1		
41030 41031	Dissolved Gas2	Float	mmHg	R	
4 1032	Dissolved Gas2status	Word		R	
41033 - 38	Dissolved Gas2time	Word		R	
41045 41046	Dissolved Gas3	Float	mmHg	R	
4 1047	Dissolved Gas3status	Word		R	
41048 - 53	Dissolved Gas3time	Word		R	
41120 41121	Photosyn Rad	Float	umol s1 m2	R	
4 1122	Photosyn Radstatus	Word		R	
41123 - 28	Photosyn Radtime	Word		R	
41135 41136	Photosyn Rad1	Float	umol s1 m2	R	
4 1137	Photosyn Rad1status	Word		R	
41138 - 43	Photosyn Rad1time	Word		R	
41150 41151	Photosyn Rad2	Float	umol s1 m2	R	
4 1152	Photosyn Rad2status	Word		R	
41153 - 58	Photosyn Rad2time	Word		R	
41165 41166	Photosyn Rad3	Float	umol s1 m2	R	
4 1167	Photosyn Rad3status	Word		R	
41168 - 73	Photosyn Rad3time	Word		R	
41180 41181	Transmissivity	Float	%	R	
4 1182	Transmissivitystatus	Word		R	
41183 - 88	Transmissivitytime	Word		R	
41195 41196	Transmissivity1	Float	%	R	
4 1197	Transmissivity1status	Word	2	R	
41198 - 203	, Transmissivity1time	Word		R	
41210 41211	Transmissivity2	Float	%	R	
4 1212	Transmissivity2status	Word		R	
41213 - 18	Transmissivity2time	Word		R	
41225 41226	Transmissivity3	Float	%	R	
4 1227	Transmissivity3status	Word		R	
41228 - 33	Transmissivity3time	Word		R	
41240 41241	C onduct iv it y	Float	uS/cm	R	
4 1242	C onduct iv it yst atus	Word		R	
41243 - 48	Conductivitytime	Word		R	

44255 44256	Constructivity 1	Fleet	C / a s	D	
41255 41256	Conductivity1	Float	uS/cm	R	
41257	Conductivity1status	Word		R	
41258 - 63	Conductivity1time	Word		R	
41270 41271	Conductivity2	Float	uS/cm	R	
41272	Conductivity2status	Word		R	
41273 - 78	Conductivity2time	Word		R	
41285 41286	Conductivity3	Float	uS/cm	R	
41287	Conductivity3status	Word		R	
41288 - 93	Conductivity3time	Word		R	
41300 41301	Specific Conductance	Float	uS/cm	R	
41302	Specific Co nductanc e st atus	Word		R	
41303 - 08Sr	pecific Conductancetime	Word		R	
41315 41316	Specific Conductance1	Float	uS/cm	R	
41317	Specific	Word		R	
	C onduct ance1stat us	15			
41318 - 23	Specific	Word		R	
	Co nductanc e1 ti me	1.			
41330 41331	Specific Conductance2	Float	uS/cm	R	
41332	Specific	Word		R	
	C onduct ance2stat us				
41333 - 38	Specific	Word		R	
	Co nductanc e2 ti me	t.			
41345 41346	Specific Conductance3	Float	uS/cm	R	
41347	Specific	Word		R	
	C onduct ance3stat us				
41348 - 53	Specific	Word		R	
	Co nductanc e3 ti me				
41360 41361	Dissolved Solid	Float	mg/l	R	
41362	Dissolved Solidstatus	Word		R	
41363 - 68	Dissolved Solidtime	Word		R	
41375 41376	Dissolved Solid1	Float	mg/l	R	
41377	Dissolved Solid1status	Word		R	
41378 - 83	Dissolved Solid1time	Word		R	
.1070 00	Sister conditine		h		

41390 41391	Dissolved Solid2	Float	mg/l	R	
41392	Dissolved Solid2status	Word		R	
41393 - 98	Dissolved Solid2status	Word		R	
41405 41406		Float	mg/l	R	
41405 41400	Dissolved Solids	FIUAL	iiig/i		
41407	Dissolved Solid3status	Word		R	
41408 - 13	Dissolved Solid3time	Word		R	
41420 41421	Salinity	Float	mg/l	R	
41422	Salinitystatus	Word		R	
41423 - 28	Salinitytime	Word		R	
41435 41436	Salinity1	Float	mg/l	R	
41437	Salinity1status	Word	-	R	
41438 - 43	Salinity1time	Word		R	
41450 41451	Salinity2	Float	mg/l	R	
41452	Salinity2status	Word		R	
41453 - 58	Salinity2time	Word		R	
41465 41466	Salinity3	Float	mg/l	R	
41467	Salinity3status	Word		R	
41468 - 73	Salinity3time	Word		R	
41480 41481	Dissolved Oxygen	Float	mg/l	R	
41482	Dissolved Oxygenstatus	Word		R	
41483 - 88	Dissolved Oxygentime	Word		R	
41495 41496		Float	mg/l	R	
41497	Dissolved Oxygen1status	Word		R	
41498 - 503	Dissolved Oxygen1time	Word	6.	R	
41510 41511	Dissolved Oxygen2	Float	mg/l	R	
41512	Dissolved Oxygen2status	Word	7	R	
41513 - 18	Dissolved Oxygen2time	Word		R	
41525 41526	Dissolved Oxygen3	Float	mg/l	R	
41527	Dissolved Oxygen3status	Word		R	

41528 - 33	Dissolved Oxygen3time	Word		R	
41540 41541	рН	Float	рН	R	
	pri	riout	P		
41542	pHstatus	Word		R	
41543 - 48	pHtime	Word		R	
41555 41556	pH1	Float	рН	R	
41557	pH1status	Word		R	
41558 - 63	pH1time	Word		R	
41570 41571	pH2	Float	рН	R	
41572	pH2status	Word		R	
41573 - 78	pH2time	Word		R	
41585 41586	рН3	Float	рН	R	
41587	pH3status	Word	-	R	
41588 - 93	pH3time	Word		R	
41600 41601	ORP	Float	Vol ts	R	
41602	ORPstatus	Word		R	
41603 - 08	ORPtime	Word		R	
41615 41616	ORP1	Float	Vol ts	R	
41617	ORP1status	Word	-	R	
41618 - 23	ORP1time	Word		R	
41630 41631	ORP2	Float	Vol ts	R	
41632	ORP2status	Word		R	
41633 - 38	ORP2time	Word		R	
41645 41646	ORP3	Float	Vol ts	R	
41647	ORP3status	Word		R	
41648 - 53	ORP3time	Word		R	
41660 41661	NH4 Nitrogen	Float	mg/l	R	
41662	NH4 Nitrogenstatus	Word		R	
41663 - 68	NH4 Nitrogentime	Word		R	
41675 41676	NH4 Nitrogen1	Float	mg/l	R	
41677	NH4 Nitrogen1status	Word		R	
41678 - 83	NH4 Nitrogen1time	Word		R	
41690 41691	NH4 Nitrogen2	Float	mg/l	R	
41692	NH4 Nitrogen2status	Word		R	

					1
41693 - 98	NH4 Nitrogen2time	Word		R	
41705 41706	NH4 Nitrogen3	Float	mg/l	R	
4 1707	NH4 Nitrogen3status	Word		R	
41708 - 13	NH4 Nitrogen3time	Word		R	
41720 41721	NO3 Nitrogen	Float	mg/l	R	
4 1722	NO3 Nitrogenstatus	Word		R	
41723 - 28	NO3 Nitrogentime	Word		R	
41735 41736	NO3 Nitrogen1	Float	mg/l	R	
4 1737	NO3 Nitrogen1status	Word		R	
41738 - 43	NO3 Nitrogen1time	Word		R	
41750 41751	NO3 Nitrogen2	Float	mg/l	R	
4 1752	NO3 Nitrogen2status	Word	4	R	
41753 - 58	NO3 Nitrogen2time	Word		R	
41765 41766	NO3 Nitrogen3	Float	mg/l	R	
			0,		
4 1767	NO3 Nitrogen3status	Word		R	
41768 - 73	NO3 Nitrogen3time	Word		R	
41780 41781	T urbidi ty	Float	NTU	R	
4 1782	Turbi dit y st atus	Word		R	
41783 - 88	Turbid ity ti m e	Word		R	
41795 41796	Turbidity1	Float	NTU	R	
4 1797	T urbidi ty1stat us	Word		R	-
41798 - 803	Turbi dit y 1ti me	Word		R	
41810 41811	Turbidity2	Float	NTU	R	
				_	
4 1812	T urbidi ty2stat us	Word		R	
41813 - 18	Turbi dit y 2ti me	Word		R	
41825 41826	Turbidity3	Float	NTU	R	
4 1827	T urbidi ty3stat us	Word		R	
41828 - 33	Turbi dit y 3ti me	Word		R	
41840 41841	Chloride	Float	mg/l	R	
4 1842	Chl oridestatu s	Word		R	
41843 - 48	Chloridetime	Word		R	
41855 41856	C hlori de1	Float	mg/l	R	
4 1857	Chl ori de1 st atus	Word		R	
41858 - 63	Chloride1time	Word		R	

41870 41871	C hlori de2	Float	mg/l	R	
4 1872	Chl ori de2 st atus	Word		R	
41873 - 78	Chloride2time	Word		R	
41885 41886	C hlori de3	Float	mg/l	R	
4 1887	Chl ori de3 st atus	Word		R	
41888 - 93	Chloride3time	Word		R	
41900 41901	Resistivity	Float	Ohm-cm	R	
4 1902	Resistivitystatus	Word		R	
41903 - 08	Resistivitytime	Word		R	
41915 41916	Resistivity1	Float	Ohm-cm	R	
4 1917	Resistivity1status	Word		R	
41918 - 23	Resistivity1time	Word		R	
41930 41931	Resistivity2	Float	Ohm-cm	R	
4 1932	Resistivity2status	Word		R	
41933 - 38	Resistivity2time	Word		R	
41945 41946	Resistivity3	Float	Ohm-cm	R	
4 1947	Resistivity3status	Word		R	
41948 - 53	Resistivity3time	Word		R	
41960 41961	Pressure	Float	mmHg	R	
4 1962	Pressurestatus	Word		R	
41963 - 68	Pressuretime	Word		R	
41975 41976	Pressure1	Float	mmHg	R	
4 1977	Pressure1status	Word		R	
41978 - 83	Pressure1time	Word		R	
41990 41991	Pressure2	Float	mmHg	R	
4 1992	Pressure2status	Word		R	
41993 - 98	Pressure2time	Word		R	
42005 42006	Pressure3	Float	mmHg	R	
4 2007		Word		R	
42008 - 13	Pressure3time	Word		R	
42020 42021	Reserved	Float		R	
4 2022	Reservedstatus	Word		R	
42023 - 28	Reservedtime	Word		R	

42037GenericstatusWordR42038 - 43GenerictimeWordR42054 - 43Generic1FloatR42050Generic1FloatR42052Generic1statusWordR42053 - 58Generic2FloatR42054 - 2066Generic2FloatR42067Generic2statusWordR42068 - 73Generic2timeWordR42080 42081Generic3FloatR42082Generic3tatusWordR42083 - 88Generic3timeWordR42095 - 103Generic4FloatR42095 - 103Generic4timeWordR42110 42111Generic5FloatR42112Generic5timeWordR42112Generic5timeWordR42113 - 18Generic5timeWordR42124Generic7FloatR42125 - 33Generic6FloatR42124 - 48Generic7FloatR42125 - 43Generic7FloatR42125 - 43Generic7FloatR42125 - 44Generic7FloatR42127Generic6 statusWordR42128 - 48Generic7FloatR42127Generic8FloatR42127Generic8FloatR42127Generic8FloatR42127Wireless PowertF	· · · · · ·			1	1
42038 - 43 Generic1 Float R 42050 42051 Generic1 Float R 42052 Generic1status Word R 42053 - 58 Generic2time Word R 42064 7066 Generic2 Float R 42067 Generic2status Word R 42068 - 73 Generic2time Word R 42082 Generic2status Word R 42084 02081 Generic3status Word R 42082 Generic3time Word R 42095 42096 Generic4 Float R 42097 Generic4time Word R 42097 Generic4time Word R 42097 Generic4time Word R 42097 Generic5 Float R 42109 Generic5 Float R 42110 Generic5 Float R 42111 Generic5 Float R 42112 Generic6 Float R 42113 - 18 Generic6 Float R 42127 Generic6 Float R 42128 - 33 Generic7 Float	42035 42036	Generic	Float	R	
42050 42051Generic1FloatR42052Generic1statusWordR42053 - 58Generic1timeWordR42065 42066Generic2FloatR42067Generic2statusWordR42068 - 73Generic2timeWordR42080 42081Generic3FloatR42082Generic3statusWordR42083 - 88Generic3timeWordR42097Generic4timeWordR42097Generic4timeWordR42098 - 103Generic5FloatR42110 42111Generic5FloatR42112Generic6timeWordR42127Generic6timeWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7FloatR42154 42156Generic8FloatR42154 4216Generic7FloatR42142Generic7FloatR42154 4216Generic7FloatR42154 4216Generic7FloatR42154 4216Generic7FloatR42154 4216Generic7FloatR42154 4216Generic7FloatR42154 4216Generic7FloatR42154 4216Generic8FloatR42154 4216Generic8FloatR42154 4216Generic8<	42037	Genericstatus	Word	R	
42052Generic1statusWordR42053-58Generic1timeWordR42065 42066Generic2FloatR42067Generic2statusWordR42068 - 73Generic2timeWordR42080 - 73Generic2statusWordR42081Generic3FloatR42082Generic3statusWordR42083 - 88Generic4FloatR42097Generic4timeWordR42097Generic4timeWordR42098 - 103Generic5timeWordR42104 2111Generic5FloatR42112Generic5timeWordR42113 - 18Generic6timeWordR42127Generic6timeWordR42128 - 33Generic6timeWordR42124 - 48Generic7FloatR42140 42141Generic7FloatR42155 42156Generic8FloatR42127Generic6timeWordR42128 - 63Generic7FloatR42158 - 63Generic8FloatR42172 - 78Wireless PowertFloatR42187Wireless PowertsatusWordR42187Wireless PowertFloatR42187Wireless PowertsatusWordR42187Wireless PowertsatusWordR42187Wireless PowertsatusWordR </td <td>42038 - 43</td> <td>Generictime</td> <td>Word</td> <td>R</td> <td></td>	42038 - 43	Generictime	Word	R	
42053 - 58Generic1timeWordR42065 42066Generic2FloatR42067Generic2statusWordR42068 - 73Generic2timeWordR42080 42081Generic3FloatR42082Generic3tatusWordR42083 - 88Generic4FloatR42095 42096Generic4FloatR42097Generic4tatusWordR42098 - 103Generic5FloatR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic6FloatR42127Generic6statusWordR42128 - 33Generic7FloatR42140 42141Generic7FloatR42143 - 48Generic7FloatR42153 - 63Generic8FloatR42154 - 73Generic8FloatR42157Generic8statusWordR42147Wireless PowertFloatR42157Generic8FloatR42157Generic8FloatR42157Generic8statusWordR42157Generic8statusWordR42157Generic8statusWordR42157Generic8statusWordR42157Generic8statusWordR42157Generic8statusWordR42157Generic8statu	42050 42051	Generic1	Float	R	
42065 42066 Generic2 Float R 42067 Generic2status Word R 42068 -73 Generic3 Float R 42080 42081 Generic3 Float R 42082 Generic3status Word R 42083 - 88 Generic3time Word R 42083 - 88 Generic4 Float R 42095 42096 Generic4 Float R 42097 Generic4status Word R 42098 - 103 Generic5 Float R 42104 2111 Generic5 Float R 42112 Generic5status Word R 42113 - 18 Generic6 Float R 42125 42126 Generic6 Float R 42127 Generic6status Word R 42128 - 33 Generic7 Float R 42140 42141 Generic7 Float R 42143 - 48 Generic7 Float R 42155 42156 Generic8 Float R	42052	Generic1status	Word	R	
42067Generic2statusWordR42068 - 73Generic2timeWordR42080 42081Generic3FloatR42082Generic3tatusWordR42083 - 88Generic4FloatR42097Generic4FloatR42097Generic4FloatR42098 - 103Generic5FloatR4211042111Generic5FloatR42112Generic5FloatR42113 - 18Generic6FloatR42127Generic6FloatR42128 - 33Generic7FloatR4214042141Generic7FloatR42142Generic7FloatR42143 - 48Generic7FloatR42154 - 63Generic8FloatR42157Generic8FloatR42157Generic8timeWordR42157Generic8timeWordR42157Generic8timeWordR4217042171Wireless PowertFloat42187Wireless Power1FloatR42187Wireless Power11FloatR	42053 - 58	Generic1time	Word	R	
42068 - 73Generic2timeWordR42080 42081Generic3FloatR42082Generic3statusWordR42083 - 88Generic3timeWordR42083 - 88Generic4FloatR42095 42096Generic4FloatR42097Generic4statusWordR42098 - 103Generic4timeWordR4210 42111Generic5FloatR42112Generic5timeWordR42113 - 18Generic5timeWordR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic7FloatR42140 42141Generic7FloatR42142Generic7FloatR42143 - 48Generic7FloatR42155 42156Generic8FloatR42157Generic8tatusWordR42157Generic8timeWordR42158 - 63Generic8FloatR42172Wireless PowerFloatR42172Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42065 42066	Generic2	Float	R	
42080 42081Generic3FloatR42082Generic3statusWordR42083 - 88Generic3timeWordR42083 - 88Generic4FloatR42097Generic4statusWordR42097Generic4statusWordR42098 - 103Generic4timeWordR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5FloatR42125Generic66FloatR42127Generic6statusWordR42128 - 33Generic7FloatR42140 42141Generic7FloatR42154 - 48Generic7FloatR42155Generic8FloatR42154Generic7statusWordR42155Generic8FloatR42154Generic7timeWordR42155Generic8FloatR42154Generic8FloatR42157Generic8statusWordR42154Generic8timeWordR42170Wireless PowerFloatR42172Wireless Power1FloatR42187Wireless Power1atusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42067	Generic2status	Word	R	
42082Generic3statusWordR42083 - 88Generic3timeWordR42095 42096Generic4FloatR42097Generic4statusWordR42098 - 103Generic4timeWordR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5FloatR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6FloatR42140 42141Generic7FloatR42142Generic7FloatR42143 - 48Generic7FloatR42155 42156Generic8FloatR42154 - 48Generic7FloatR42155 42156Generic8FloatR42170 42171Wireless PowerFloatR42172Wireless Power1FloatR42172 - 78Wireless Power1FloatR42184 - 18Wireless Power1FloatR42172Wireless Power1FloatR42174Wireless Power1FloatR42175Wireless Power1RR42176Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR <td>42068 - 73</td> <td>Generic2time</td> <td>Word</td> <td>R</td> <td></td>	42068 - 73	Generic2time	Word	R	
42083 - 88Generic3timeWordR42095 42096Generic4FloatR42097Generic4statusWordR42098 - 103Generic4timeWordR42098 - 103Generic5tatusWordR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5timeWordR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic7FloatR42140 42141Generic7FloatR42142Generic7FloatR42143 - 48Generic7FloatR42155 42156Generic8FloatR42157Generic8tatusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172 - 78Wireless PowertimeWordR42172 - 78Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1 <t< td=""><td>42080 42081</td><td>Generic3</td><td>Float</td><td>R</td><td></td></t<>	42080 42081	Generic3	Float	R	
42095 42096Generic4FloatR42097Generic4statusWordR42098 - 103Generic4timeWordR42010 42111Generic5FloatR42110 42111Generic5statusWordR42112Generic5statusWordR42113 - 18Generic5timeWordR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155Generic8FloatR42157Generic8tatusWordR42157Generic8titusWordR42157Generic8titusWordR42170Wireless PowerFloatR42172Wireless PowerstatusWordR42172 - 78Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42082	Generic3status	Word	R	
42097Generic4statusWordR42098 - 103Generic4timeWordR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5timeWordR42113 - 18Generic6FloatR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic7FloatR42140 42141Generic7FloatR42143 - 48Generic7timeWordR42154Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42157Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless Power1atusWordR42172 - 78Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR <td>42083 - 88</td> <td>Generic3time</td> <td>Word</td> <td>R</td> <td></td>	42083 - 88	Generic3time	Word	R	
42098 - 103Generic4timeWordR42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5timeWordR42113 - 18Generic6FloatR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7timeWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8tatusWordR42158 - 63Generic8timeWordR42172Wireless PowerFloatR42172Wireless PowertimeWordR42172Wireless PowertimeWordR42172Wireless PowertimeWordR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42095 42096	Generic4	Float	R	
42110 42111Generic5FloatR42112Generic5statusWordR42113 - 18Generic5timeWordR42113 - 18Generic6FloatR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7FloatR42143 - 48Generic7FloatR42155 42156Generic8FloatR42157Generic8tatusWordR42158 - 63Generic8tatusWordR42170 42171Wireless PowerFloatR42172Wireless PowertimeWordR42172 - 78Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR	42097	Generic4status	Word	R	
42112Generic5statusWordR42113 - 18Generic5timeWordR42113 - 18Generic6FloatR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic742143Generic7FloatR42143 - 48Generic7FloatR42154Generic8FloatR42155Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170Wireless PowertFloatR42172Wireless PowertimeWordR42172 - 78Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42098 - 103	Generic4time	Word	R	
42113 - 18Generic5timeWordR42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR4217042171Wireless PowerFloat42172Wireless PowertimeWordR42172 - 78Wireless Power1FloatR42185 42186Wireless Power1FloatR42187Wireless Power1KordR42187Wireless Power1KordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42110 42111	Generic5	Float	R	
42125 42126Generic6FloatR42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170Wireless PowerFloatR42172Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42112	Generic5status	Word	R	
42127Generic6statusWordR42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42170Generic8timeWordR42172Wireless PowerFloatR42172Wireless PowertimeWordR42185 42186Wireless Power1FloatR42172Wireless Power1statusWordR42187Wireless Power1FloatR42187Wireless Power1statusWordR42187Wireless Power1statusWordR42187Wireless Power1statusWordR	42113 - 18	Generic5time	Word	R	
42128 - 33Generic6timeWordR42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42125 42126	Generic6	Float	R	
42140 42141Generic7FloatR42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1statusWordR	42127	Generic6status	Word	R	
42142Generic7statusWordR42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42185 42186Wireless Power1FloatR42187Wireless Power1FloatR42187Wireless Power1FloatR	42128 - 33	Generic6time	Word	R	
42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42140 42141	Generic7	Float	R	
42143 - 48Generic7timeWordR42155 42156Generic8FloatR42157Generic8statusWordR42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42142	Generic7status	Word	R	
42157Generic&statusWordR42158 - 63Generic&timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 - 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR					
42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 - 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42155 42156	Generic8	Float	R	
42158 - 63Generic8timeWordR42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 - 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42157	Generic8status	Word	R	
42170 42171Wireless PowerFloatR42172Wireless PowerstatusWordR42172 - 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR					
42172 - 78Wireless PowertimeWordR42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42170 42171				
42185 42186Wireless Power1FloatR42187Wireless Power1statusWordR	42172	Wireless Powerstatus	Word	R	
42187 Wireless Power1status Word R	42172 - 78	Wireless Powertime	Word	R	
	42185 42186	Wireless Power1	Float	R	
42188 - 93 Wireless Power1time Word R	42187	Wireless Power1status	Word	R	
	42188 - 93	Wireless Power1time	Word	R	

	· · · · · · · · · · · · · · · · · · ·		1	1
42200 42201	Wireless Power2	Float	R	
42202	Wireless Power2status	Word	R	
42203 - 08	Wireless Power2time	Word	R	
42215 42216	Wireless Power3	Float	R	
42217	Wireless Power3status	Word	R	
42218 - 23	Wireless Power3time	Word	R	
42230 42231	Wireless Power4	Float	R	
42232	Wireless Power4status	Word	R	
42233 - 38	Wireless Power4time	Word	R	
42245 42246	Wireless Power5	Float	R	
42247	Wireless Power5status	Word	R	
42248 - 53	Wireless Power5time	Word	R	
42260 42261	Wireless Power6	Float	R	
42262	Wireless Power6status	Word	R	
42263 - 68	Wireless Power6time	Word	R	
42275 42276	Wireless Power7	Float	R	
42277	Wireless Power7status	Word	R	
42278 - 83	Wireless Power7time	Word	R	
42290 42291		Float	R	
42292	Humiditystatus	Word	R	
42293 - 98	Humiditytime	Word	R	
42305 42306	Humidity1	Float	R	
42307	Humidity1status	Word	R	
42308 - 13	Humidity1time	Word	R	
42320 42321	Humidity2	Float	R	
42322	Humidity2status	Word	R	
42323 - 28	Humidity2time	Word	R	
42335 42336		Float	R	
42337	Humidity3status	Word	R	

42338 - 43	Humidity3time	Word	R	
42350 42351	A ngl e	Float	R	
4 2352	Anglestatus	Word	R	
42353 - 58	Angletime	Word	R	
42365 42366	Angle1	Float	R	
4 2367	A ng le1stat us	Word	R	
42368 - 73	A ngl e1 ti me	Word	R	
42380 42381	Angle2	Float	R	
4 2382	A ng le2stat us	Word	R	
42383 - 88	A ngl e2 ti me	Word	R	
42395 42396	Angle3	Float	R	
4 2397	A ng le3stat us	Word	R	
42398 - 403	A ngl e3 ti me	Word	R	

Signature[®] Flow Meter

Appendix D Material Safety Data Sheets

This appendix provides Material Safety Data Sheets for the desiccant used by the Signature Flow Meter.

Teledyne ISCO cannot guarantee the accuracy of the data. Specific questions regarding the use and handling of the products should be directed to the manufacturer listed on the MSDS.

SORB-IT®isaregisteredtrademarkofN.T.GatesCompany.

	MATERIAL SAFETY DATA SH	EET	
	sSORB®		Analos L Gue D Reactivity D Freezensin E
Section	1. CHEMICAL PRODUCT & COMPAN	VY IDENTIFICATION	
roduct Name: sSORB® hemical Name: Yellow Indi ynonyms: Orange Indicatin		371 Edgemon Park Ridge, IL	
mergency Assistance USA Outside USA	+ 1.847.292.8600 + 1.847.292.8600	USA Telephone: Fax:	+ 1.847.292.8600 + 1.847.292.8601
Section AS Numbers: 1343-98-2, 7	n 2: COMPOSITION & INFORMATION 7-09-8	N ON INGREDIENTS	
Aolecular Formula: SiO ₂ · n		_	
Ingestion: No adverse e			
Ingestion: No adverse e Skin Contact: May cause Eye Contact: May cause Chronic Exposure: Repu			ted for acute effects.
Ingestion: No adverse e Skin Contact: May cause Eye Contact: May cause Chronic Exposure: Repu Synthetic amorphous si Eye Contact: Check for and plenty of water for at least Skin Contact: Wash with so attention if irritation develo Ingestion: Give several glas advice.	effects expected. e irritation with dryness and abrasion e irritation, redness and pain. eated exposure may cause symptoms ilica does not produce silicosis. Section 4: FIRST AID MEASE remove any contact lenses. In case 15 minutes. Get medical attention il pap and water. Cover the irritated ski	s similar to those lis <u>JRES</u> of contact, immedi f irritation occurs. in with an emollien ge amounts were so	ately flush eyes wth t. Get medical wallowed, get medical
Ingestion: No adverse e Skin Contact: May cause Eye Contact: May cause Chronic Exposure: Repo Synthetic amorphous si Eye Contact: Check for and plenty of water for at least Skin Contact: Wash with so attention if irritation develo Ingestion: Give several glass advice. Inhalation: If inhaled, remo Fire: Not considered to be Explosion: Not considered Fire Fighting Media and Im	effects expected. e irritation with dryness and abrasio e irritation, redness and pain. eated exposure may cause symptoms ilica does not produce silicosis. Section 4: FIRST AID MEASU remove any contact lenses. In case 15 minutes. Get medical attention il oap and water. Cover the irritated ski ops. ises of water to drink to dilute. If larg ove to fresh air. If breathing is difficul Section 5: FIRE & EXPLOSION	s similar to those lis URES of contact, immedi F irritation occurs. in with an emollien ge amounts were so It, get medical atten V DATA	ately flush eyes wth t. Get medical wallowed, get medical ntion.

MATERIAL SAFETY DATA SHEET

Section 6: ACCIDENTAL RELEASE MEASURES

Small Spill: Use appropriate tools to put the spilled solid in a convenient waste disposal container. Use respiratory protection and eye protection.

Large Spill: Use a shovel to put the material into a convenient waste disposal container. Vacuuming or wet sweeping may be used to avoid dust dispersal. Use respiratory protection and eye protection.

Section 7: HANDLING & STORAGE

Storage: Keep container tightly closed. Suitable for any general chemical storage area. Containers of this material may be hazardous when empty since they retain product residues (dust, solids); observe all warnings and precautions listed for the product.

Section 8: EXPOSURE CONTROLS / PERSONAL PROTECTION

Engineering Controls: Use process enclosures, local exhaust ventilation, or other engineering controls to keep airborne levels below recommended exposure limits. If user operations generate dust, fume or mist, use ventilation to keep exposure to airborne contaminants below the exposure limit. Personal Protection: Safety glasses. Lab coat. Respirator (NIOSH Approved). Gloves.

		Section 9 PHYSICAL & CHE	MICAL PROPERTIES		
-	Physical state:	Solid	Boling Point:	2230C (4046F)	
	Color:	Yellow/Orange-Dry:Green-Saturated	Melting Point:	1610C (2930F)	
	Odor:	Odorless	Vapor Pressure:	Not applicable.	
	Solubility:	Insoluble	Vapor Density:	Not applicable.	
	Specific Gravity:	2.1 (Water=1)	Evaporation Rate:		
5	pH:	3 - 8 (in 5% slurry)	% Volatiles by volu	me @ 21C (70F): 0	

Section 10: STABILITY & REACTIVITY

Stability: The product is stable.

Hazardous Decomposition Products: Oxides of carbon and silicon may be formed when heated. Hazardous Polymerization: Will not occur.

Incompatibility with powerfull oxiders: Reacts with hydrogen flouoride, fluorine, oxygen difluoride, chlorine trifluoride, strong acids, strong bases, and oxidizers.

Conditions to Avoid: Moisture, extreme heat, and incompatibles.

Section 11⁻ TOXICOLOGICAL INFORMATION

Routes of Entry: Absorbed through skin. Eye contact. Inhalation. Ingestion.

Toxicity to Animals:

LD50: Not available.

LC50: Not available.

ction 12: ECOLOGICAL INFORMATIO

Ecotoxicity: This material is not expected to be toxic to aquatic life.

INTERRA Global Corporation

msds sSORB

p2

	Section 13: DISPOSAL CONSIDERATIONS
aste Disposal: Wa	iste must be disposed of in accordance with federal, state and local environmental
ntrol regulations.	
	Section 14: TRANSPORT INFORMATION
entification: Not a	Not a DOT controlled material (United States).
entineation. Not	pproduc.
	Section 15: OTHER REGULATORY INFORMATION
MIS (U.S.A.):	
Health Hazard:	1
Fire Hazard:	0
Reactivity:	0
Personal Protec	
	ction Association (U.S.A.):
Health:	1
Flammability:	0
Reactivity:	0
	Section 16: OTHER INFORMATION
eferences:	Not available.
ther Special Consi	iderations: Not available.
	/03/2009 11:20 AM
ast Updated: 03,	/25/2010 10:40 AM
believed to be accur erchantability or any sulting from its use. articular purposes. In	ety Data Sheet is to describe the products in terms of their safety requirements. The information above rat and represents the bet information currently available to us. However, we make no warrant of other warranty, express or implied, with respect of such information, and we assume no iability Users should make their own investigations to determine the suitability of the information for their no event shal interra Global Corporation be liable for an claims, losses, or damages of any third party y special, indirect, incidental, consequential or exemplary damages, howsoever arising, even if Interra

INTERRA Global Corporation

msds sSORB

p3

03/21/2012 14:04 FAX 14137368257

Ø 002

Page 1 of 5

MATERIAL SAFETY DATA SHEET

SÜD-CHEMIE

Desi Pak®

Date Issued: 07/06/2004 MSDS No: 5008 Date-Revised: 11/28/2011 Revision No: 3

1. PRODUCT AND COMPANY IDENTIFICATION

PRODUCT NAME: Desi Pak® GENERAL USE: Desiccant

MANUFACTURER

Süd-Chemie Performance Packaging 101 Christine Drive Rio Grande Industrial Park Belen, NM 87002 Customer Service: 505-864-6691 24 HR. EMERGENCY TELEPHONE NUMBERS CHEMTREC : (800) 424 - 9300 Outside the U.S. Call Collect : 001 (703) 527-3887

2. HAZARDS IDENTIFICATION

EMERGENCY OVERVIEW

PHYSICAL APPEARANCE: Performance packaging product, size and type vary.

IMMEDIATE CONCERNS: Poses little or no immediate hazard.

POTENTIAL HEALTH EFFECTS

EYES: Roure of exposure unlikely. Dust may cause a mechanical irritation which can scratch the eye.

SKIN: No idverse effects expected.

INGESTION: Non-toxic by ingestion. Packets or canisters may pose a choking hazard. Keep away from children and pets.

INHALATION: Route of exposure unlikely. This material is normally packaged and contained in a pouch, bag or canister. If the container is opened, prolonged or repeated inhalation of high dust concentrations may cause lung damage.

3. COMPOSITION / INFORMATION ON INGREDIENTS

INGREDIEN"(S)	CAS	Wt.%
Pouch, Bag, Canister, Stopper, or Cap	0.05	1 - 75
Clay	1302-78-9	
Silica, quartz	14808-60-7	< 0.5

See Section 8 for Exposure Limits

4. FIRST AID MEASURES

EYES: Do not rub eyes. Flush with lukewarm, gently flowing water for 5 minutes or until the particle/dust is removed, while holding the eyelid(s) open. Obtain medical attention. SKIN: Wash with soap and water. 03/21/2012 14:04 FAX 14137368257

003

Page 2 of 5 :

Desi Pak®

INGESTION: Normally not needed. If large quantities are ingested, call your local Poison Control Center (1-800-222-1222 in the U.S.)

INHALATION: Normally not needed. If exposed to excessive levels of dust or fumes, remove to fresh air and seek medical attention of cough or other symptoms develop or persist.

5. FIRE FIGHTING MEASURES

FLASHPOINT AND METHOD: Material is not flammable

EXTINGUISHING MEDIA: Use extinguishing agent applicable to surrounding fire.

FIRE FIGHTING PROCEDURES: As in any fire, wear celf-contained breathing apparatus operated in pressure-demand mode, (NIC 5H approved or equivalent) and full protective gear.

6. ACCIDENTAL RELEASE MEASURES

SMALL SPILL: No special precautions required.

LARGE SPILL: With shovel or scoop, place material into appropriate container.

7. HANDLING AND STORAGE

- HANDLING: Use of proper hygiene practices in the workplace is recommended.
- STORAGE: Store in a dry area.

8. EXPOSURE CONTROLS / PERSONAL PROTECTION

XPOSURE GUIDELINES HA	ZARDOUS COMPONENTS			-	-
			EXPOSUR	E LIMITS	;
		OSH	A PEL	ACG	(H TLV
Chemical Name		ppm	mg/m ³	ppm	mg/m ³
	TWA	[1]	[1]	[1]	[1]
Clay	TWA	[2]	[2]	[3]	0.025 [3]

SHA TABLE COMMENTS

- 1. Exposure limits not established.
- 2. Total Du :t = (30 mg/m3)/(%SiO2+2)

3. Respirab e

犼

ENGINEERING CONTROLS: If user operations generate dust, fume or mist, use ventilation to keep exposure to airborne contamina its below the exposure limit.

PERSONAL PROTECTIVE EQUIPMENT

EYES AND FACE: Follow facility guidelines.

SKIN: Use of proper hygiene practices in the workplace is recommended.

RESPIRATORY: Use local exhaust if dusting occurs. Good general ventilation is adequate in the absence of dusts.

COMMENTS: All inert or nuisance dusts, whether mineral, inorganic, or organic, not listed specifically by substance name are covered by the Particulates Not Otherwise Regulated (PNOR) limit which is 5 mg/m3 for respirable fraction and 15 mg/m3 fo total dust. ACGIH exposure guidelines of less than 3 mg/m3 (respirable) and 10 mg/m3 (inhalable) have been established for particles (insoluble/poorly soluble) not otherwise specified (PNOS). 03/21/2012 14:05 FAX 14137368257

Desi Pak®

Page 3 of 5

Ø 004

9. PHYSICAL AND CHEMICAL PROPERTIES

PHYSICAL STATE: Solid ODOR: None pH: Not Determined PERCENT VOLATILE: None VAPOR PRESISURE: Not Applicable VAPOR DENSITY: Not Applicable. EVAPORATION RATE: Not Applicable VISCOSITY: Not Applicable OXIDIZING PROPERTIES: None

10. STABILITY AND REACTIVITY

STABLE: Yes

HAZARDOUS POLYMERIZATION: No

11. TOXICOLOGICAL INFORMATION

ACUTE

Chemical Name	ORAL LD ₅₀	DERMAL LD ₅₀	INHALATION
	(rat)	(rabbit)	LC ₅₀ (rat)
Сіау	> 5000 gm/kg(b.w.)		> 200 mg/L/1H
Silica, qua tz	500	No Data	No Data
	gm/kg(b.w.)	Available	Available

CARCINOGENICITY

Chemical Name	NTP Status	IARC Status	OSHA Status
Clay	Not listed.	Not listed.	Not listed.
Silica, qua tz	Known Carcinogen	Group I	Not listed.

SENSITIZAT (ON: Not sensitizing

GENERAL COMMENTS: Crystalline silica present is contained within a pouch, canister or bag. No exposure to airborne particles of respirable size is expected under normal conditions of use.

12. ECOLOGICAL INFORMATION

ENVIRONMENTAL DATA: Low hazard for usual industrial or commercial handling. CHEMICAL FATE INFORMATION: This material is of mineral origin. It is not biodegradable.

13. DISPOSAL CONSIDERATIONS

DISPOSAL METHOD: This product, if discarded as sold, is not a Federal RCRA hazardous waste. Processing, use or

1000

0	Desi Pak®		Page 4
	contamination of this product may change the waste management options. State and local d from federal disposal regulations.	isposal reg	ulations may
1	4. TRANSPORT INFORMATION		
7			
182	DOT (DEPARTMENT OF TRANSPORTATION)		
	PROPER SHIPPING NAME: Not regulated		
	ROAD AND RAIL (ADR/RID)		
1	PROPER SHIPPING NAME: Not regulated		
9	AIR (ICAO/IATA)		
2.34	SHIPPIN G NAME: Not regulated		
÷	VESSEL (IMO/IMDG)		
	SHIPPING NAME: Not regulated		
2	CANADA TRANSPORT OF DANGEROUS GOODS SHIPPING NAME: Not regulated		
	on the transmission of regulated		
15	. REGULATORY INFORMATION		
5	RESIDENT INFORMATION		
Ľ	INITED STATES		
	SARA TITLE III (SUPERFUND AMENDMENTS AND REAUTHORIZATION ACT)		
	FIRE: No PRESSURE GENERATING: No REACTIVITY: No ACUTE: No CHRONIC: Y	22	
	SIS REFORTABLE INGREDIENTS: Not listed.	es	
	CERCLA (COMPREHENSIVE RESPONSE, COMPENSATION, AND LIABILITY ACT)		
	CERCLA REGULATORY; Not listed.		
	TSCA (TOXIC SUBSTANCE CONTROL ACT)		
	TSCA STATUS: All components are listed on the TSCA Inventory or are excluded or exempt REGULATIONS		
	STATE REGULATIONS: California		
	CALIFORN (A PROPOSITION 65, This product does not		
	CALIFORN (A PROPOSITION 65: This product does not contain chemical(s) known to the sta cancer, birth defects, or reproductive harm.	ete of Califo	ornia to cause
	Crystalline silica present is contained within a pouch, canister or bag. There is no exposure to respirable size under normal conditions of use.	airborno n	auticlas of
	respirable size under normal conditions of use.		articles or
	Silica, quartz	Wt.%	Listed
	RCRA STATUS: This product, if discarded as sold is each find to sold	<0.5	Cancer
	RCRA STATUS: This product, if discarded as sold, is not a Federal RCRA hazardous waste. Pro contamination of this product may change the waste management options. State and local dis differ from federal disposal regulations.	cessing, us	e or
	differ from federal disposal regulations.	posariegu	lations may
	WHMIS HAZARD SYMBOL AND CLASSIFICATION		
	Does not meet classification or teria oursuppt to the Greation of		
3	Does not meet classification criteria pursuant to the Canadian Hazardous Products Act.		
	WHMIS (WORKPLACE HAZARDOUS MATERIALS INFORMATION SYSTEM): This MSDS has according to the hazard criteria of the Controlled Products Regulations (CPR) and the MSDS co information required by the CPR.	ntains all c	of the
	CANADA IN GREDIENT DISCLOSURE LIST: Contains component(s) listed on the Canadian Ha Ingredient Disclosure List.	zardous Pr	oducts Act
(Ingredient Disclosure List. CANADIAN ENVIRONMENTAL PROTECTION ACT: All ingredients are listed on the Canadian List inventory.		

/21/2012 14:06 FAX 14137368257	2006 Page 5 of 5
esi Pak®	
EUROPEAN COMMUNITY EEC LABEL SYMBOL AND CLASSIFICATION	
Not classified as dangerous	
6. OTHER INFORMATION APPROVED EY: Prepared and approved by SHE Depr INFORMATION CONTACT: E-mail - MSDS_US@sud-	t. Sud-Chemie Inc. -chemie.com
DEVICED A CUMMARY This MSDS replaces the 01/2	1/2009 MSDS. Revised: Section 1: INFORMATION HYSICAL HAZARD, HMIS RATINGS NOTES, CHRONIC).
HMIS RATING HEALTH * 1 0 PHYSICAL HAZARD 0 PERSONAL PROTECTION	
HMTE BATINGS NOTES: Personal Protection should	be determined based on workplace conditions. resented herein is believed to be accurate but is not warranted.

	Hazardous Substances or Elements						
Component Name	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)	
Circuit Boards	О	0	0	0	0	0	
Display	0	0	0	0	0	0	
Wiring	0	0	0	0	0	0	
Internal Cables	0	0	0	0	0	0	
DC Motor	0	0	0	0	0	0	
Connectors	0	0	0	0	0	0	
Battery	Х	Х	Х	0	0	0	
Solenoid valve	0	0	0	0	0	0	

Name and amount of Hazardous Substances or Elements in the product

Name and amount of Hazardous Substances or Elements in

)

the product O: ST/

O: Represent the concentration of the hazardous substance in this component's any homogeneous pieces is lower than the ST/ standard limitation. X ST/

(

"X"

X: Represent the concentration of the hazardous substance in this component's at least one homogeneous piece is higher than the ST/ standard limitation.

(Manufacturer may give technical reasons to the "X"marks)

The Environmentally Friendly Use Period (EFUP) was determined through experience. $(207 \quad 2007)$

A B

The date of Manufacture is in code within the serial number. The first three numbers are the year of manufacture (207 is year 2007) followed by a letter for the month. "A" is January, "B" is February and so on.



DECLARATION OF CONFORMITY



Application of Council Directive:	2014/30/EU–The EMC Directive 2014/35/EU–The Low Voltage Directive 2012/19/EU –The WEEE Directive 2011/65/EU –The RoHS Directive				
	Teledyne ISCO				
Manufacturer's Name:	4700 Superior, Lincoln, N Mailing Address: P.O. Bo	Nebraska 68504 USA ox 82531, Lincoln, NE 68501			
Manufacturer's Address:	Laboratory Equipment for	r Light Industrial/Commercial Environments			
Equipment Type/Environment:		C or DC power) with 350, 360, 301 sensors, 306 Bubbler, RS485 and Ethernet Modem options			
Trade Name/Model No:	2017				
	EN 61326-1:2013				
Year of Issue:	EN 61010-1:2010 EN605	529 EN 61000-3-2:2014			
Standards to which Conformity is Declared:	EN 61000-3-3:2013	EMC Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use Special Protection offered by the Signature's Enclosure: IP-66 Limits for harmonic current emissions (equipment Limitation of voltage changes, voltage fluctuations aottatigetsarpiplosty steams;			

We, the undersigned, hereby declare that the design of the equipment specified above conforms to the above Directive(s) and Standards as of July 17, 2017.

USA Representative



Edward J. Carter Director of Engineering Teledyne ISCO 4700 Superior Street Lincoln, Nebraska 68504 Phone: (402) 464-0231 Fax: (402) 464-3799

> 60-4302-021 RevE